```
Bus Types
```

Definition

```
struct bus_type {
        char
                                 * name:
        struct subsystem
                                 subsys;
        struct kset
                                 drivers:
        struct kset
                                 devices;
        struct bus attribute
                                 * bus attrs;
        struct device_attribute * dev_attrs;
        struct driver attribute * drv attrs;
        int
                         (*match) (struct device * dev, struct device_driver *
drv);
        int
                         (*hotplug) (struct device *dev, char **envp,
                                     int num_envp, char *buffer, int
buffer_size);
                         (*suspend) (struct device * dev, pm_message_t state);
        int
                         (*resume) (struct device * dev);
        int
};
int bus register(struct bus type * bus);
```

Declaration

Each bus type in the kernel (PCI, USB, etc) should declare one static object of this type. They must initialize the name field, and may optionally initialize the match callback.

The structure should be exported to drivers in a header file:

extern struct bus type pci bus type;

Registration

When a bus driver is initialized, it calls bus_register. This initializes the rest of the fields in the bus object and inserts it into a global list of bus types. Once the bus object is registered, the fields in it are usable by the bus driver.

Callbacks

match(): Attaching Drivers to Devices

~~~~~~~~

The format of device ID structures and the semantics for comparing them are inherently bus-specific. Drivers typically declare an array of device IDs of devices they support that reside in a bus-specific driver structure.

The purpose of the match callback is provide the bus an opportunity to determine if a particular driver supports a particular device by comparing the device IDs the driver supports with the device ID of a particular device, without sacrificing bus-specific functionality or type-safety.

When a driver is registered with the bus, the bus's list of devices is iterated over, and the match callback is called for each device that does not have a driver associated with it.

#### Device and Driver Lists

The lists of devices and drivers are intended to replace the local lists that many buses keep. They are lists of struct devices and struct device\_drivers, respectively. Bus drivers are free to use the lists as they please, but conversion to the bus-specific type may be necessary.

The LDM core provides helper functions for iterating over each list.

These helpers iterate over the respective list, and call the callback for each device or driver in the list. All list accesses are synchronized by taking the bus's lock (read currently). The reference count on each object in the list is incremented before the callback is called; it is decremented after the next object has been obtained. The lock is not held when calling the callback.

# $\underset{\sim}{\text{sysfs}}$

There is a top-level directory named 'bus'.

Each bus gets a directory in the bus directory, along with two default directories:

/sys/bus/pci/ |-- devices

第 2 页

```
`-- drivers
```

Drivers registered with the bus get a directory in the bus's drivers directory:

```
/sys/bus/pci/

|-- devices

-- drivers

|-- Intel ICH

|-- Intel ICH Joystick

|-- agpgart

|-- e100
```

Each device that is discovered on a bus of that type gets a symlink in the bus's devices directory to the device's directory in the physical hierarchy:

```
/sys/bus/pci/

-- devices

|-- 00:00.0 -> ../../root/pci0/00:00.0

|-- 00:01.0 -> ../../root/pci0/00:01.0

|-- 00:02.0 -> ../../root/pci0/00:02.0

-- drivers
```

## Exporting Attributes

```
struct bus_attribute {
    struct attribute attr;
    ssize_t (*show)(struct bus_type *, char * buf);
    ssize_t (*store)(struct bus_type *, const char * buf, size_t count);
};
```

Bus drivers can export attributes using the BUS\_ATTR macro that works similarly to the DEVICE\_ATTR macro for devices. For example, a definition like this:

static BUS ATTR (debug, 0644, show debug, store debug);

is equivalent to declaring:

static bus\_attribute bus\_attr\_debug;

This can then be used to add and remove the attribute from the bus's sysfs directory using:

int bus\_create\_file(struct bus\_type \*, struct bus\_attribute \*);
void bus\_remove\_file(struct bus\_type \*, struct bus\_attribute \*);