* Serial

```
Currently defined compatibles:
- fsl, cpml-smc-uart
- fsl, cpm2-smc-uart
- fsl, cpm1-scc-uart
- fsl, cpm2-scc-uart
- fsl, cpm2-scc-uart
- fsl, qe-uart
```

Modem control lines connected to GPIO controllers are listed in the gpios property as described in booting-without-of.txt, section IX.1 in the following order:

CTS, RTS, DCD, DSR, DTR, and RI.

The gpios property is optional and can be left out when control lines are not used.

Example: