This is a small guide for those who want to write kernel drivers for I2C or SMBus devices, using Linux as the protocol host/master (not slave).

To set up a driver, you need to do several things. Some are optional, and some things can be done slightly or completely different. Use this as a guide, not as a rule book!

### General remarks

Try to keep the kernel namespace as clean as possible. The best way to do this is to use a unique prefix for all global symbols. This is especially important for exported symbols, but it is a good idea to do it for non-exported symbols too. We will use the prefix `foo\_' in this tutorial.

### The driver structure

Usually, you will implement a single driver structure, and instantiate all clients from it. Remember, a driver structure contains general access routines, and should be zero-initialized except for fields with data you provide. A client structure holds device-specific information like the driver model device node, and its I2C address.

```
};
MODULE DEVICE TABLE (i2c, foo idtable);
static struct i2c_driver foo_driver = {
       .driver = {
                      = "foo",
               .name
       },
                      = foo_ids,
       .id_table
       .probe
                      = foo probe,
       .remove
                      = foo remove,
       /* if device autodetection is needed: */
                      = I2C_CLASS SOMETHING,
       .class
       . detect
                      = foo detect.
       .address list
                      = normal i2c,
       . shutdown
                      = foo shutdown, /* optional */
                                    /* optional */
       . suspend
                      = foo suspend,
                                     /* optional */
       .resume
                      = foo_resume,
                      = foo command,
                                     /* optional, deprecated */
       . command
```

The name field is the driver name, and must not contain spaces. It should match the module name (if the driver can be compiled as a module), 第  $1\ \overline{\text{p}}$ 

although you can use MODULE\_ALIAS (passing "foo" in this example) to add another name for the module. If the driver name doesn't match the module name, the module won't be automatically loaded (hotplug/coldplug).

All other fields are for call-back functions which will be explained below.

# Extra client data

Each client structure has a special `data' field that can point to any structure at all. You should use this to keep device-specific data.

```
/* store the value */
void i2c_set_clientdata(struct i2c_client *client, void *data);
/* retrieve the value */
void *i2c_get_clientdata(const struct i2c_client *client);
```

Note that starting with kernel 2.6.34, you don't have to set the `data' field to NULL in remove() or if probe() failed anymore. The i2c-core does this automatically on these occasions. Those are also the only times the core will touch this field.

# Accessing the client

Let's say we have a valid client structure. At some time, we will need to gather information from the client, or write new information to the client.

I have found it useful to define foo\_read and foo\_write functions for this. For some cases, it will be easier to call the i2c functions directly, but many chips have some kind of register-value idea that can easily be encapsulated.

The below functions are simple examples, and should not be copied literally.

```
int foo read value(struct i2c client *client, u8 reg)
        if (reg < 0x10) /* byte-sized register */
                return i2c smbus read byte data(client, reg);
        else
                        /* word-sized register */
                return i2c smbus read word data(client, reg);
}
int foo write value (struct i2c client *client, u8 reg, u16 value)
                                /* Impossible to write - driver error! */
        if (reg == 0x10)
                return -EINVAL:
        else if (reg < 0x10)
                                /* byte-sized register */
                return i2c smbus write byte data(client, reg, value);
                                /* word-sized register */
        else
                                     第 2 页
```

# writing-clients..txt return i2c\_smbus\_write\_word\_data(client, reg, value);

### Probing and attaching

}

The Linux I2C stack was originally written to support access to hardware monitoring chips on PC motherboards, and thus used to embed some assumptions that were more appropriate to SMBus (and PCs) than to I2C. One of these assumptions was that most adapters and devices drivers support the SMBUS\_QUICK protocol to probe device presence. Another was that devices and their drivers can be sufficiently configured using only such probe primitives.

As Linux and its I2C stack became more widely used in embedded systems and complex components such as DVB adapters, those assumptions became more problematic. Drivers for I2C devices that issue interrupts need more (and different) configuration information, as do drivers handling chip variants that can't be distinguished by protocol probing, or which need some board specific information to operate correctly.

### Device/Driver Binding

System infrastructure, typically board-specific initialization code or boot firmware, reports what I2C devices exist. For example, there may be a table, in the kernel or from the boot loader, identifying I2C devices and linking them to board-specific configuration information about IRQs and other wiring artifacts, chip type, and so on. That could be used to create i2c\_client objects for each I2C device.

I2C device drivers using this binding model work just like any other kind of driver in Linux: they provide a probe() method to bind to those devices, and a remove() method to unbind.

Remember that the i2c\_driver does not create those client handles. The handle may be used during foo\_probe(). If foo\_probe() reports success (zero not a negative status code) it may save the handle and use it until foo remove() returns. That binding model is used by most Linux drivers.

The probe function is called when an entry in the id\_table name field matches the device's name. It is passed the entry that was matched so the driver knows which one in the table matched.

### Device Creation

If you know for a fact that an I2C device is connected to a given I2C bus, you can instantiate that device by simply filling an i2c\_board\_info structure with the device address and driver name, and calling

第 3 页

i2c\_new\_device(). This will create the device, then the driver core will take care of finding the right driver and will call its probe() method. If a driver supports different device types, you can specify the type you want using the type field. You can also specify an IRQ and platform data if needed.

Sometimes you know that a device is connected to a given I2C bus, but you don't know the exact address it uses. This happens on TV adapters for example, where the same driver supports dozens of slightly different models, and I2C device addresses change from one model to the next. In that case, you can use the i2c\_new\_probed\_device() variant, which is similar to i2c\_new\_device(), except that it takes an additional list of possible I2C addresses to probe. A device is created for the first responsive address in the list. If you expect more than one device to be present in the address range, simply call i2c\_new\_probed\_device() that many times.

The call to i2c\_new\_device() or i2c\_new\_probed\_device() typically happens in the I2C bus driver. You may want to save the returned i2c\_client reference for later use.

### Device Detection

Sometimes you do not know in advance which I2C devices are connected to a given I2C bus. This is for example the case of hardware monitoring devices on a PC's SMBus. In that case, you may want to let your driver detect supported devices automatically. This is how the legacy model was working, and is now available as an extension to the standard driver model.

You simply have to define a detect callback which will attempt to identify supported devices (returning 0 for supported ones and -ENODEV for unsupported ones), a list of addresses to probe, and a device type (or class) so that only I2C buses which may have that type of device connected (and not otherwise enumerated) will be probed. For example, a driver for a hardware monitoring chip for which auto-detection is needed would set its class to I2C\_CLASS\_HWMON, and only I2C adapters with a class including I2C\_CLASS\_HWMON would be probed by this driver. Note that the absence of matching classes does not prevent the use of a device of that type on the given I2C adapter. All it prevents is auto-detection; explicit instantiation of devices is still possible.

Note that this mechanism is purely optional and not suitable for all devices. You need some reliable way to identify the supported devices (typically using device-specific, dedicated identification registers), otherwise misdetections are likely to occur and things can get wrong quickly. Keep in mind that the I2C protocol doesn't include any standard way to detect the presence of a chip at a given address, let alone a standard way to identify devices. Even worse is the lack of semantics associated to bus transfers, which means that the same transfer can be seen as a read operation by a chip and as a write operation by another chip. For these reasons, explicit device instantiation should always be preferred to auto-detection where possible.

第4页

#### Device Deletion

Each I2C device which has been created using i2c\_new\_device() or i2c\_new\_probed\_device() can be unregistered by calling i2c\_unregister\_device(). If you don't call it explicitly, it will be called automatically before the underlying I2C bus itself is removed, as a device can't survive its parent in the device driver model.

# Initializing the driver

When the kernel is booted, or when your foo driver module is inserted, you have to do some initializing. Fortunately, just registering the driver module is usually enough.

```
static int __init foo_init(void)
{
         return i2c_add_driver(&foo_driver);
}

static void __exit foo_cleanup(void)
{
         i2c_del_driver(&foo_driver);
}

/* Substitute your own name and email address */
MODULE_AUTHOR("Frodo Looijaard <frodol@dds.nl>"
MODULE_DESCRIPTION("Driver for Barf Inc. Foo I2C devices");

/* a few non-GPL license types are also allowed */
MODULE_LICENSE("GPL");

module_init(foo_init);
module exit(foo cleanup);
```

Note that some functions are marked by `\_\_init'. These functions can be removed after kernel booting (or module loading) is completed. Likewise, functions marked by `\_\_exit' are dropped by the compiler when the code is built into the kernel, as they would never be called.

### Power Management

If your I2C device needs special handling when entering a system low power state — like putting a transceiver into a low power mode, or activating a system wakeup mechanism — do that in the suspend() method. The resume() method should reverse what the suspend() method does.

These are standard driver model calls, and they work just like they would for any other driver stack. The calls can sleep, and can use I2C messaging to the device being suspended or resumed (since their

parent I2C adapter is active when these calls are issued, and IRQs are still enabled).

#### System Shutdown

\_\_\_\_\_

If your I2C device needs special handling when the system shuts down or reboots (including kexec) — like turning something off — use a shutdown() method.

Again, this is a standard driver model call, working just like it would for any other driver stack: the calls can sleep, and can use I2C messaging.

#### Command function

\_\_\_\_\_

A generic ioctl-like function call back is supported. You will seldom need this, and its use is deprecated anyway, so newer design should not use it.

#### Sending and receiving

If you want to communicate with your device, there are several functions to do this. You can find all of them in linux/i2c.h>.

If you can choose between plain I2C communication and SMBus level communication, please use the latter. All adapters understand SMBus level commands, but only some of them understand plain I2C!

#### Plain I2C communication

\_\_\_\_\_

These routines read and write some bytes from/to a client. The client contains the i2c address, so you do not have to include it. The second parameter contains the bytes to read/write, the third the number of bytes to read/write (must be less than the length of the buffer, also should be less than 64k since msg.len is u16.) Returned is the actual number of bytes read/written.

This sends a series of messages. Each message can be a read or write, and they can be mixed in any way. The transactions are combined: no stop bit is sent between transaction. The  $i2c_msg$  structure contains for each message the client address, the number of bytes of the message 第 6 页

and the message data itself.

You can read the file `i2c-protocol' for more information about the actual I2C protocol.

#### SMBus communication

s32 i2c\_smbus\_xfer(struct i2c\_adapter \*adapter, u16 addr, unsigned short flags, char read\_write, u8 command, int size, union i2c\_smbus\_data \*data);

This is the generic SMBus function. All functions below are implemented in terms of it. Never use this function directly!

```
s32 i2c smbus read byte(struct i2c client *client);
s32 i2c smbus write byte(struct i2c client *client, u8 value);
s32 i2c smbus read byte data(struct i2c client *client, u8 command);
s32 i2c smbus write byte data(struct i2c client *client,
                              u8 command, u8 value);
s32 i2c_smbus_read_word_data(struct i2c_client *client, u8 command);
s32 i2c_smbus_write_word_data(struct i2c_client *client,
                              u8 command, u16 value);
s32 i2c_smbus_process_call(struct i2c client *client,
                           u8 command, u16 value);
s32 i2c smbus read block data(struct i2c client *client,
                              u8 command, u8 *values);
s32 i2c_smbus_write_block_data(struct i2c_client *client,
                               u8 command, u8 length, const u8 *values);
s32 i2c smbus read i2c block data(struct i2c client *client,
                                  u8 command, u8 length, u8 *values);
s32 i2c smbus write i2c block data(struct i2c client *client,
                                   u8 command, u8 length,
                                   const u8 *values):
```

These ones were removed from i2c-core because they had no users, but could be added back later if needed:

All these transactions return a negative errno value on failure. The 'write' transactions return 0 on success; the 'read' transactions return the read value, except for block transactions, which return the number of values read. The block buffers need not be longer than 32 bytes.

You can read the file `smbus-protocol' for more information about the actual SMBus protocol.

# General purpose routines

Below all general purpose routines are listed, that were not mentioned 第 7 页

before.

/\* Return the adapter number for a specific adapter \*/ int i2c\_adapter\_id(struct i2c\_adapter \*adap);