
## LDR (LPgrr dupendent responses)

- \* Light dipendint reststars are also known as them dependent yesi Photo responsible.
- + LDR and legat sensitive durries most often used to andicate the presence of absence of light of to measure the leght Entinsity.

## Applications of LOR

- \* LDR ou used in along clocks, street lights, light entensity mitors, burglan alarm aroult.
- \* smoke dutectors, Entravid astronomy, Street light control ctracts, camera lightmotors.

## PINOUT of LOR Dragram



PINNO	V CC	Power supply & V
2	Gno	Ground PI N
3	po	sign al on thut

```
LOR sengo Buta Ento Serpal Hongron.
Put LORSenson =2
 vopol setup ()
     PIROHOOL (LORSENES), DONPUT);
     serPail.begen (9600);
word look ()
    serbul. prombo (dry fra Riad (LOR sensar));
    deday (1000);
 2
DARK & LIGHT Retrotor Ardustro Code
thr corsenson = 2
vord sorup ()
  pinHodi (LARsenson, OtoTPOT) à
    PENHODI (13, OWTRUT)
    serfal. begen (9600);
 ropy pooper
    mi data z digital Rad(consenson);
    serPal. printin (data);
    96 (data == 0) // dutects light
          degetal cum (13, $1614)
     else of (data ==1) 11 dited doork
          deg to was (13, LOW);
```

