

IPTV Dexing Set Top Box User Guide

For Dexin ABV017CA-SMC

Contents

1	Product Overview	1-1
2	Product Features	2-1
3 3.1	Appearance	
3.2	RearPanel	3-2
4	Working States of the Dexin ABV017CA-SMC	4-1
5	Remote Control	5-1
6	How to Use the DEXIN ABV017CA-SMC STB	
for th	he First Time	6-1
6.1	Connecting Cables	6-1
6.2	Starting the DEXIN ABV017CA-SMC	
7	Common Operations	
7.1	Adjusting the Audio Output	7-1
7.1.1	Switching Between Audio Channels or	
Betwe	een Audio Tracks	7-1
7.1.2	Adjusting the Volume	7-1
7.1.3	Muting the Audio	7-1
7.2	Watching TSTV Programs	7-1 7.3
7.3	Fast Forwarding or Rewinding VOD Programs	7-2 7.4
7.4	Switching Between the Standby State and the	
	Working State	. 7-2
7.5 Sv	witching Between Character Input Methods	7-2
8	Safety Suggestions	8-1
9	Troubleshooting	9-1

Figures

Figure 3-1 Front panel of the DEXIN ABV017CA-SMC STB	3-1
Figure 3-2 Uncovered front panel of the DEXIN ABV017CA-SMC STB	3-2
Figure 3-3 Rear panel of the DEXIN ABV017CA-SMC STB	3-2
Figure 3-4 Right-Side Panel of the DEXIN ABV017CA-SMC STB	3-3 Figure
4-1 Switching between the states	-1
Figure 5-1 Remote control of the DEXIN ABV017CA-SMC STB	5-2
Figure 6-1 Cable connection of the DEXIN ABV017CA-SMC STB	6-1

Tables

Table	5-1	Functions	of	the	buttons	on	the	remote	control	of	the
DEXIN	ARV	117CA-SMC	STB							5-3	

1

Product Overview

Thank you for choosing the DEXIN ABV017CA-SMC IP Set Top Box (hereinafter referred to as the DEXIN ABV017CA-SMC STB), which will bring you a brandnew entertainment experience.

The DEXIN ABV017CA-SMC STB is a digital information electronic device provided for household subscribers. It is a terminal that provides streaming services through a TV set on a VDSL or FTTH connection. The DEXIN ABV017CA-SMC STB provides a new solution for operators to launch fee-based IPTV services on a broadband network.

The DEXIN ABV017CA-SMC STB is a cost-effective product. It provides a variety of external interfaces, and can decode high-definition (HD) and standard-definition (SD) MPEG-2 and H.264 content. It runs on an embedded real-time operating system and provides the functions of remote configuration, remote monitoring, and remote upgrade.

Product Features

The DEXIN ABV017CA-SMC STB has the following features:

- High reliability and stability
- Support for three access modes: PPPoE, DHCP, and static IP address
- Easy-to-use remote control
- Simple menus, which facilitate operations
- Support for HD decoding
- Compliance with MPEG standards
- High compatibility
- Powerful network management capabilities implemented through the embedded real-time operating system
- Multiple control modes: terminal control and remote control
- Modular design, which facilitates upgrade
- Support for online upgrade
- Support for HTML, JavaScript, and Cookies
- Multiple audio and video output ports
- OSD flicker prevention
- Quick startup
- Cost-effectiveness

2-1

Downloaded from www.Manualslib.com manuals search engine

3 Appearance

3 Appearance

3.1 Front Panel

Figure 3-1 shows the front panel of the DEXIN ABV017CA-SMC STB.

Figure 3-1 Front panel of the DEXIN ABV017CA-SMC STB



No.	Name	Description
1	Power	• When the DEXIN
	indicator	ABV017CA-SMC STB
		is working, the
		indicator is green. ●
2 010-01-05)	Dexing Proprietary and Co	When the DEXIN

Issue 01 (2010-01-05) Dexing Proprietary and Confidential

Copyright © Dexing Technologies Co., Ltd.

		ABV017CA-SMC STB is standby, the indicator is red.
2	Link indicator	 When the DEXIN ABV017CA-SMC STB is properly connected to a network cable, the indicator is on. When the DEXIN ABV017CA-SMC STB is disconnected from a network cable, the indicator is off.
3	IR indicator	When the DEXIN ABV017CA-SMC STB is receiving signals from the remote control, the indicator blinks.
4	LED Monitor	The working status of the DEXIN ABV017CA-SMC STB is displayed on the LED monitor.

Figure 3-2 shows the uncovered front panel of the DEXIN ABV017CA-SMC STB.



3 Appearance

Figure 3-2 Uncovered front panel of the DEXIN ABV017CA-SMC STB



No.	Name	Description
5	MENU	You can press the key to access the main menu.
6	LEFT/RIGH T ◀▶	You can press the keys to adjust volume, or move the cursor leftward or rightward on the EPG.
	UP/DOWN ▲▼	You can press the keys to switch between channels, or move the cursor upward or downward on the EPG.
7	OK	You can press the key to confirm an operation.


3.2 Rear Panel

Figure 3-3 shows the rear panel of the DEXIN ABV017CA-SMC STB. Figure 3-4 shows the right-side panel of the DEXIN ABV017CA-SMC STB.

Figure 3-3 Rear panel of the DEXIN ABV017CA-SMC STB

Issue 01 (2010-01-05)

Dexing Proprietary and Confidential Copyright © Dexing Technologies Co., Ltd.



3-2 Dexing Proprietary and Confidential Issue 01 (2010-01-05) Copyright © Dexing Technologies Co., Ltd.

Downloaded from www.Manualslib.com manuals search engine

3 Appearance

Figure 3-4 Right-Side Panel of the DEXIN ABV017CA-SMC STB

4

Working States of the DEXIN ABV017CA-SMC STB

The DEXIN ABV017CA-SMC STB has the following working states:

Off

There is no power supply and the DEXIN ABV017CA-SMC STB does not work.

Booting

The DEXIN ABV017CA-SMC STB is starting after being powered on.

Standby

When the DEXIN ABV017CA-SMC STB is working, press the Power button (blue button) on the remote control to change the status of the DEXIN ABV017CA-SMC STB to standby. The video output of the DEXIN ABV017CA-SMC STB is disabled.

Working


The working state is divided into video playing state and EPG browsing state. The video playing state is further divided into the VOD and live TV states.

Upgrade

The DEXIN ABV017CA-SMC STB is upgrading its software. Do not power off the DEXIN ABV017CA-SMC STB when it is in this state.

Figure 4-1 shows the switching between the states.

Figure 4-1 Switching between the states



EC2108E STB User Guide

5

Remote Control

Figure 5-1 shows the remote control of the DEXIN ABV017CA-SMC STB.




Figure 5-1 Remote control of the DEXIN ABV017CA-SMC STB

5-2

5 Remote Control

No.	Name	Function
1	Power (Blue button)	Shifts a TV set between the working state and the standby state.
2	Scan	Studies the functions of the remote control of a TV set.
3	TV/AV	Shifts the video output of a TV set.
4	VOL- /VOL+	Adjusts the volume of a TV set.
5	Power (Red button)	Shifts the DEXIN ABV017CA-SMC STB between the working state and the standby state.
6	Live TV	Shortcut to the live TV function.
7	I-mode	Shortcut to the interactive function.
8	VOD	Displays the EPG page of VOD programs.
9	Menu	Shortcut to the menu homepage.
10	Info	Displays the information about the current program.

11	Exit	Exits the current page.
12	Guide	Shortcut to EPG.
13	I-II (Audio)	Switches between audio channels or audio tracks.
14	(Sub)	Provides subtitles for programs.
15/1 6	CH+/CH- ▲▼	 Switches between channels. Moves the cursor upward or downward on the EPG.
17/1 8	VOL- /VOL+ ◀▶	 Adjusts the volume. Moves the cursor leftward or rightward on the EPG.
19	OK ▶	Confirms an operation.
20	Ø	Mutes or resumes the audio.
21	BACK	 Returns to the previous-level menu on the EPG. Quits the playback of a VOD program. Quits the playback of a live TV program. Returns to the live TV state when a subscriber

		is watching a TSTV program.
22	PgUp/PgDn	Goes to the previous or next page.
23	≪ REW	 Fast rewinds a VOD program. Fast rewinds a TVOD or TSTV program. Switches a live TV program to the time-shift mode.
24	*	Fast forwards a VOD program.

5 Remote Control

No.	Name	Function
	FFW	• Fast
		forwards
		a TVOD
		program.
		• Fast
		forwards
		a TSTV
		program.
25	NI	• In VOD mode: Press
	Play/Pause	this button once to pause a
		playing VOD program. Press
		this button again to resume the
		program.
		• In IPTV mode: Press
		this button once to switch a
		playing live TV program to the

5-3

		time-shift mode. Press this button again to play the time-shift program. Refer to the messages displayed on the TV screen.
26	Red	Starts or stops PIP.
	Green	Switches between PIP channels.
	Yellow	Switches to the next PIP channel.
	Blue	Switches to the previous PIP channel.
27	Numeric buttons	Selects channels or enters digits and characters.
28	*/HELP	Shortcut to Help.
29	#техт	Switches between character input methods.



The functions of some buttons depend on the services provided by the carrier. If there is no response when you press a button, contact the service provider for more information.

5-4

6 How to Use the DEXIN ABV017CA-SMC STB for the First


Time

This chapter describes how to connect cables and configure the DEXIN ABV017CA-SMC STB when the DEXIN ABV017CA-SMC STB is used for the first time.

6.1 Connecting Cables

Connect the cables of the DEXIN ABV017CA-SMC STB according to Figure 6-1.

Figure 6-1 Cable connection of the DEXIN ABV017CA-SMC STB



The procedure for connecting cables is as follows:

6-1

6 How to Use the DEXIN ABV017CA-SMC STB for the First Time

Step 1

Connect the audio output ports (the Audio L and Audio R ports) of the DEXIN ABV017CA-SMC STB to the corresponding audio input ports of a TV set. If use HDMI cable for video output, this step can be ignored.

Step

2

Use one of the following methods to connect a video cable:

- Use an HDMI cable to connect the HDMI port of the DEXIN ABV017CA-SMC STB to the HDMI input port of the TV set. If the TV set can decode the audio from the HDMI, you do not need to connect the audio cable from the STB to the TV set in step 1.
- Use a Y, Pb, and Pr cable to connect the Y, Pb, and Pr ports of the DEXIN ABV017CA-SMC STB to the Y, Pb, and Pr input ports of the TV set.
- Use a RCA cable to connect the CVBS port of the DEXIN ABV017CA-SMC STB to the CVBS input port of the TV set.
- Use an S-Video cable to connect the S-Video port of the DEXIN ABV017CA-SMC STB to the S-Video input port of the TV set.

Step 3

Connect the RJ45 port of the DEXIN ABV017CA-SMC STB with CAT5 or CAT 6 UTP cable to the RJ45 port of either these equipments:

- Residential Gateway
- **OLT**
- VDSL2 Modem
- Layer 3 Switch

Step

Insert the power plug of the DEXIN ABV017CA-SMC STB into the power socket.

NOTE

HDMI cable increases the quality of video especially HD.

----End

6.2 Starting the DEXIN ABV017CA-SMC STB

The procedure for starting the DEXIN ABV017CA-SMC STB is as follows:

Step Make sure that the network has been correctly connected

1 and is properly working.

Step Turn on the TV set and change the TV signal input mode

to a correct mode such as HDMI, component, AV, or S-2

Video.

Step Turn on the power switch on the rear panel of the DEXIN 3 ABV017CA-SMC STB.

NOTE

The method of selecting the AV mode is different varies according to TV set vendor and model. For details, see the corresponding instructions in the user guide of the TV set. ----End

6-2

7 Common Operations

7 Common Operations

The chapter describes the common operations of the DEXIN ABV017CA-SMC STB.

M NOTE

All the operations described in this user guide are performed through the remote control of the DEXIN ABV017CA-SMC STB, unless otherwise specified.

7.1 Adjusting the Audio Output

7.1.1 Switching Between Audio Channels or Between Audio Tracks

- Press the **Audio** button to switch between the left audio channel, right audio channel, and stereo.
- Press the Audio button to switch between audio tracks.

7.1.2 Adjusting the Volume

Press the **VOL**+/- button or the Left/Right Arrow button to adjust the volume. You can also use the remote control of a TV set to adjust the volume.

7.1.3 Muting the Audio

Press the **Mute** button to mute the audio. Press it again to resume the audio.

7.2 Watching Live TV Programs

When watching live TV programs, you can use the time-shift function to watch the program content that has been played a certain period ago. This function is called Time Shift TV or TSTV

The method of watching a TSTV program is as follows:

When watching a live TV program, press the button repeatedly. The program will be fast rewound at a speed of 2X, 4X, 8X, 16X, and 32X. At this time, a TSTV icon is displaying at the upper-left corner of the screen. When the program fast rewinds to the point you want, press the button to watch the program from that point. Then, you can press the button to fast forward the program or press the button to return to the

7	Common	Operations
---	--------	------------

live TV program. At this time, the live TV icon is displayed at the upper-left corner of the screen.

The time-shift duration is defined by the carrier. Contact your carrier for details.

Currently TM IPTV does not offer Time Shifted TV.

7.3 Fast Forwarding or Rewinding VOD Programs

When watching a VOD program, press the $\blacktriangleright \blacktriangleright$ or the \blacktriangleleft button to fast forward or rewind the program at a speed of 2X, 4X, 8X, 16X, or 32X.

When the program is fast forwarded or rewind to the point you choose, press the **>** button to play the program.

7.4 Switching Between the Standby State and the Working State

The procedure for switching the DEXIN ABV017CA-SMC STB between the standby state and the working state is as follows:

Step When the DEXIN ABV017CA-SMC STB is in the working state, press the **Power** button on the front panel or press the **Power** (Blue) button on the remote control to switch it to the

standby state.

Step When the DEXIN ABV017CA-SMC STB is in the standby state, press the **Power** button on the front panel or press the **Power** (Blue) button on the remote control to switch it to the

working state.

----End

Dexing Proprietary and Confidential Copyright © Dexing Technologies Co., Ltd.

Issue 01 (2010-01-05)

7.5 Switching Between Character Input Methods

During local STB configuration, you need to enter English characters. At this time, you need to select the input box and press the **IME** button repeatedly to switch between the following character input methods:

- Numbers
- English letters (lower case)
- English letters (upper case)
- English letters (both lower case and upper case)

M NOTE

After switching to the required input method, stop pressing the **IME** button. 7-2

8 Safety Suggestions

Safety Suggestions

The DEXIN ABV017CA-SMC STB complies with international safety rules and regulations. Nevertheless, subscribers must be careful when using the DEXIN ABV017CA-SMC STB:

- Place the DEXIN ABV017CA-SMC STB in a stable place.
- Do not place any heavy object on the DEXIN ABV017CA-SMC STB.
- Avoid plugging the HDMI cord and hard disk when power is on.
- Use the DEXIN ABV017CA-SMC STB only indoors to prevent fire or electrical shock. Keep the DEXIN ABV017CA-SMC STB far away from heat sources.
- Use the accessories specified by the STB vendor.
- Only use the dedicated power adapter. Input power supply must be in range as stated on the label of power adaptor.
- Make sure that all required devices are properly connected to the DEXIN ABV017CA-SMC STB.

Do not connect to power supply before finishing connecting other devices to the DEXIN ABV017CA-SMC STB.

- Do not extend a power cable or make a power cable overloaded, which may result in a fire accident. A worn power adaptor must be replaced with a new one.
- Do not trample on or forcibly pull the power cable. Unplug the power cable if you do not use the DEXIN ABV017CA-SMC STB for a long time.
- Do not block exhaust vents. Place the DEXIN ABV017CA-SMC STB in a ventilated and dry place instead of a hot, cold, wet, or dusty place.

- Do not use and store the DEXIN ABV017CA-SMC STB near anything with strong magnetic field, such as a magnet or electric motor. For example microwave oven. Also do not use and store it near anything with strong radio waves emitting, such as a large antenna.
- Keep the DEXIN ABV017CA-SMC STB far away from water sources. Do not place any container that is filled with liquid on the DEXIN ABV017CA-SMC STB.
- It is normal that the top cover and rear panel of the DEXIN ABV017CA-SMC STB become hot after you use it for a long time.
- Do not disassemble and repair the DEXIN ABV017CA-SMC STB yourself.
- Unplug the power cable and network cable of the DEXIN ABV017CA-SMC STB during thunder and lightning weather to prevent electrical shock, damage, or fire.
- Use only dry cloth to clean the DEXIN ABV017CA-SMC STB. Do not use water or any other liquid to clean it.

9

Troubleshooting

This chapter describes the common problems that may occur during the use of the DEXIN ABV017CA-SMC STB and the solutions to the problems.

Problem 1: The indicators of the DEXIN ABV017CA-SMC STB are off and the DEXIN ABV017CA-SMC STB cannot be powered on after you press the **Power** button on the rear panel.

Possible cause:

The DEXIN ABV017CA-SMC STB is powered off.

Solution:

Check whether the power cable is properly connected and the **Power** button on the rear panel is in the ON position.

Problem 2: No video is displayed on the TV screen.

Possible causes:

- The video cable is not properly connected.
- The DEXIN ABV017CA-SMC STB is powered off.
- The TV set is turned off or in the standby state.

Solutions:

- Check whether the video cable and network cable are properly connected. For details, see 6.1 Connecting Cables.
- Check whether the DEXIN ABV017CA-SMC STB is powered on.
- Check whether the TV set is turned on and switch it to the AV mode.

Problem 3: No audio is audible.

Possible causes:

- The audio cable is not properly connected.
- The TV set or the DEXIN ABV017CA-SMC STB is in mute mode or the volume is very low.

Solutions:

- Check whether the audio cable is properly connected. For details, see 6.1 Connecting Cables.
- Switch the TV set and the DEXIN ABV017CA-SMC STB to the audible mode and increase the volume.

9-1 DEXIN ABV017CA-SMC STB User Guide

9 Troubleshooting

Problem 4: The remote control of the DEXIN ABV017CA-SMC STB does not work properly.

Possible causes:

• The remote control is far away from the DEXIN ABV017CA-SMC STB. • The batteries of the remote control need to be replaced.

Solutions:

- Move the remote control to a workable distance.
- Replace the batteries.

Problem 5: The message "The set top box is not in the service area" is displayed on the TV screen.

Possible cause:

You are in arrears or the corresponding service expires.

Solution:

Contact your carrier.

Problem 6: No EPG page is displayed on the TV screen.

Possible causes:

- The network connection is incorrect.
- The configuration of the DEXIN ABV017CA-SMC STB is incorrect.

Solutions:

• Check the network connection. For details, see 6.1 Connecting Cables." • Contact maintenance personnel to re-configure the DEXIN ABV017CA-SMC STB.

Problem 7: Black-and-white images are displayed after startup.

User Guide

Possible causes:

- The video cable is in poor quality or is not properly connected.
- The TV standard of the TV set does not match the TV standard set on the DEXIN ABV017CA-SMC STB. The default output TV standard of the DEXIN ABV017CA-SMC STB is PAL.

Solutions:

- Reconnect or replace the video cable.
- Use the remote control of the TV set to change the TV standard of the TV set to **AUTO**. For details, see the corresponding instructions in the user guide of the TV set.



If the problem that you encounter persists after you follow the preceding steps or if the problem is not mentioned in this chapter, contact IPTV Operation.

Dexing Proprietary and Confidential Copyright © Dexing Technologies Co., Ltd.

Issue 01 (2010-01-05)

9-2