PRODUCT DATA SHEET

DUROGUARD 900 TC

TWO PART, HEAVY DUTY, TRAFFICABLE, ABRASION RESISTANT, POLYURETHANE WATERPROOFING MEMBRANE

DUROTECH
Engineered Construction Chemicals
Made In Australia For Over 45 Years

DESCRIPTION

Duroguard 900 TC is a two part, elastomeric, heavy duty, trafficable, abrasion resistant, uv resistant, low VOC,polyurethane waterproofing membrane.

Duroguard 900 TC is formulated to provide a high tensile, puncture and tear resistant waterproofing membrane suitable for pedestrian and vehicular traffic.

Duroguard 900 TC is usually top coated with Duroguard 900 BC (aliphatic top coat), which is a tough, abrasion resistant, uv and colour stable top coat.

FEATURES

- Highly flexible - + 400% (meets CSIRO Class 111).
- Low VOC - meets Greenstar criteria.
- Seamless
- Fully bonded. Does not allow water to track between
- the substrate and the membrane.
- Puncture and tear resistant.
- Abrasion resistant.
- Suitable for pedestrian and vehicular traffic.
- Can be made non-slip.
- Resistant to ponded water.
- Chemically resistant
- Tolerates a wide temperature range (± -30°C to 120°C)
- Easy to apply

Suitable Surfaces

- Concrete and cementitious surfaces.
- Block-work, brick-work and Hebel block.
- Masonry
- Timber

Note: Surfaces must be dry or have a low moisture content (max. 5%), clean, free of dirt, friable matter, oils, grease, concrete release and curing agents, efflorescence and other contaminants.

USE AREA

- Exposed roofs
- Balconies, deck, podiums, terraces and concrete slabs.
- Car park decks and ramps
- Planters and landscape areas
- Plant rooms and wash rooms
- Laboratory and kitchen floors
- Sports stadiums
- Walk-ways, passage ways and pedestrian access areas.
- Impact resistant internal flooring.

SINCE 1977

SPECIFICATION

The information contained in this product data sheet is typical but does not constitute a full specification as conditions and specific requirements may vary from project to project. The instructions should be considered as a minimum requirement but the applicator or contractor must use their skill, knowledge and experience to carry out additional works as may be necessary to meet the requirements of the project. Specification for specific projects should be sought from the Company in writing.

LIMITATIONS

Duroguard 900 TC is a two part system and must be correctly mixed using the correct proportions. Deviations may result in a reduction in pot life or the product remaining partially uncured.

PRECAUTIONS IN USE

The product is not classifies as hazardous but good industrial practises and hygiene should be observed.
Impervious gloves, goggles (against splashes), coverall and boots should be worn.
Use in well ventilated areas. Avoid breathing in vapours.
Keep all sources of ignition away from uncured product.

PRIMING AND SURFACE PREPARATION

Good preparation is essential. Surfaces must be sound, stable, dry, clean and free of dust, loose, flaking, friable material and substances that may diminish adhesion.

Surfaces must be sound, stable, dry, free of dirt, dust, friable material, grease, oils, release and curing agents and contaminants that may diminish adhesion.

Mirror finished or glassy smooth concrete should lightly abraded or acid treated (then neutralised), flushed and allowed to dry.

Prior coatings and membranes should be removed to provide a surface as described above.

Surface defects must be rectified.

Priming
Apply a coat of Duram Primeseal SP at the rate of 7m² to 8m² per litre per coat. Highly porous areas may require an additional coat of primer.

Green or damp concrete and where there is a risk of water vapour transmission from out of the substrate apply two coats of Duram Primeseal SP at the rate of 7m² to 8m² per litre per coat. Allow each coat to dry (± 2 hours) before applying the next coat.

Important
Where detailed prepartion work is required, priming should be confined just to those areas. Do not prime areas that cannot bemembraned within 2 hours (best) or 24 hours (maximum).

The membrane should be applied as soon as the final coat of primer is dry (± 2 hours from last priming coat) and within 24 hours.

DETAILING PREPARATION

Corners
Prime as required.
Apply an adequate flexible polyurethane sealant such as , Duram Resiflex FC33 in accordance the manufacture's instruction and tool off to form a solid, coved or 45° fillet extending at least 10mm on to the adjacent surfaces. Allow sealant to cure. Apply the Durotech membrane directly over the cured sealant and on the adjacent surfaces.

Joins, Gaps and Cracks

General
Joins, gaps and cracks should be suitably filled and sealed with an appropriate elastomeric sealant, preferably a polyurethane sealant such as Duram Resiflex FC33, and allowed to cure.

Recommendation: The movement of small cracks should not be underestimated and should be at least covered with a flexible polyurethane sealant or additional coats of membrane.

Where movement of the joint is expected, lay a bond breaker tape over the filled crack and apply a 150mm wide good coat of Multithane Std over the crack and then embed a suitable reinforcing fabric into the wet coat, followed by a saturating coat of Multithane Std. Allow to cure and apply a further coat of Multithane Std. The dry flim thickness over these cracks should be at least 2mm.

Large or Live Cracks
Large cracks should be routed out to form a 'V' and then filled and sealed with a polyurethane waterproof joint sealant as per the manufacturer's instructions. The sealant should be finished slightly proud of the surface and allowed to cure.

Lay a bond breaker tape over the filled crack and apply a 150mm wide good coat of Multithane Std over the crack and then embed a suitale reinforcing fabric into the wet coat, followed by a saturating coat of Multithane Std. Allow to cure and apply a further coat of Multithane Std. The dry flim thickness over these cracks should be at least 2mm.

Joins - Particularly in CFC Sheeting and Timber Sheeting
Ideally the sides of the sheets should be fully coated with a flexible polyurethane waterproof joint sealant prior to butting the sheets together.

If not, the joins should be suitably filled and sealed with an appropriate elastomeric, construction grade, polyurethane waterproof sealant such as Duram Resiflex FC33 and finished flush with or preferably slightly proud of the surface and allowed to cure.

After priming as required, lay a strip of Duram Leak-SealTape over the join, pressing it firmly on to the substrate. The Durotech membrane is then as described under 'Large or Live Cracks'.

If the Duram Leak-Seal is not used then follow the procedure as described under 'Large or Live Cracks'.

Waste Outlets, Penetrations and Angles
Waste Outlets: Floor wastes and puddle flanges should be rebated in to the floor to allow water to readily drain. Gaps and perimeters should be sealed with a polyurethane sealant.

Plastic or metal angles: Where required by the Building Code such as internal hobs and exterior door barriers and also plastic corner angels under wall boards, they should be securely embedded in to a continuous, gap free bed of a polyurethane sealant /mastic.

APPLICATION

Product Preparation:
Given the pot life of the material, have all components ready. Before use, mix individual pails seprately (avoiding airation) with a clean and dry stirrer ensuring that there is no cross contamination between Parts A and Parts B.

It is recommended that the product be used in complete kits as supplied. If not, measure by weight strictly in the ratio of 23.1 grams of Hardener with 100 grams of Resin.

Measure individual Parts A and Parts B components accurately in required proportion in to a separate clean and dry container and mix thoroughly with a mechanical stirrer (avoiding aeration) periodically scraping the bottom and sides of the container. Ideally, use the products in complete kits as supplied.

Application
Apply to notched trowel, roller or brush as follows:

Non-Exposed Membrane System
Apply two coats of Multithane 2P-A80 at the minimum rate of 1kg per m^2 per coat allowing each coat to cure before applying the next. Following coats, including Duroguard 900 BC, must be applied as soon as the preceding coat is dry and within 24 hours to maximum of 48 hours. The minimum dry film thickness of the cured membrane must be 1.5mm.

Non-Exposed Anti-Slip Membrane System
Apply a coats of Duroguard 900 TC at the minimum rate of 1.5kg to 1.75kg per m^2. Allowing to cure. As soon as the preceding coat is dry and within 24 hours to a maximum of 48 hours apply a second coat of Duroguard 900 TC at the rate of 0.5kg per m^2 and while wet, broadcast the anti-slip grit to excess. Allow the membrane to cure and then remove loose grit. The minimum dry film thickness of the cured membrane must be 2.0mm.

Exposed Anti-Slip Membrane System
Apply a coats of Duroguard 900 TC at the minimum rate of 1.5kg to 1.75kg per m^2. Allowing to cure. As soon as the preceding coat is dry and within 24 hours to a maximum of 48 hours apply a second coat of Duroguard 900 TC at the rate of 0.5kg per m^2# and while wet, broadcast the anti-slip grit to excess. Allow the membrane to cure and then remove loose grit. The minimum dry film thickness of the cured membrane must be 2.0mm.

Apply a coat of Duroguard 900 BC to cured membrane at the rate of $3m^2$ per litre. The dry film thickness must be at least 0.3mm.

Important:
Pot Life: Depending upon ambient temperature and quantity of product mixed, the pot life of the mixed product is 20 to 30 minutes. Once thickened or set, the product is unusable and must not be thinned using solvents in an attempt to prolong the pot life or reconstitute the product.

COVERAGE

The stated average coverage rate may vary depending upon type, condition, porosity, texture of the surface and application technique.

Standard Membrane
- Duroguard 900 TC: 1kg per m^2 per coat. Minumim dry film thickness - 1.5mm
- Duroguard 900 BC: 0.5kg per m^2. Minumim dry film thickness - 0.3mm.

Anti-Slip Membrane
· Duroguard 900 TC:: 2kg per m² finished. Minumim dry film thickness - 2.0mm
· Duroguard 80A BC: 0.5kg per m². Minumim dry film thickness - 0.3mm.

PACKAGING

Primer: Duram Primeseal SP- 4 litre and 15 litre pails
Membrane: Duroguard 900 TC in 20kg kits
Top Coat: Duroguard 900 BC in 15 litre pails

COLOURS

Usually supplied in grey, but can be supplied in other colours. Minimum quantities may apply.

Durotech Industries Pty Ltd

Address	14 Essex Street, P.O Box 5092, Minto, NSW 2566
Phone	+61 2 9603 1177
Fax	+61 2 9475 5059
Email	sales@durotechindustries.com.au
Web	www.durotechindustries.com.au

"This document, including any attached files, is strictly confidential and intended solely for the use of the individual or entity to which it is addressed. Durotech Industries prohibits the right to publish, copy, distribute or disclose any information contained in this document, or its attachments, by any party other than the intended recipient. If you have received this document in error please notify the sender and delete it from your system immediately. no employee or agent is authorised to conclude any binding agreement or make any representation on behalf of Durotech Industries. The views or opinions presented in this document are solely those of the author and do not necessarily represent those of Durotech Industries, except where the sender expressly, and with clear authority, states them to be the views of Durotech Industries. Durotech Industries accepts no liability for any loss or damage (direct or indirect or consequential) arising from the use of or in connection with this document and any attacchments and suggests that the recipient check this document and any attached files for the presence of viruses."

JAS-ANZ ©

ISO 9001 Quality Certified System
ISO 14001 Environment Certified System
ISO 45001 Health and Safety Certified System