PRODUCT DATA SHEET

DUROPROOF NEP 900

SINGLE COMPONENT POLYURETHANE MEMBRANE

DUROTECH
Engineered Construction Chemicals
Made In Australia For Over 45 Years

DESCRIPTION

DUROPROOF™ NEP 900 is a high quality, superior performance single component liquid that cures to rapidly toform a polyurethane membrane that is tack-free, high modulus, tough, and flexible. For non exposed use only

FEATURES

- Excellent flexibility
- One component
- Good adhesion to a wide range of substrate
- Excellent chemical resistance
- Decrease in construction cost and time
- Can be applied as a single cost finish at 1mm thickness
- Tack-free cure & walkable overnight
- Excellent toughness
- Low odour, low VOC
- Complies with Green Star requirements
- Good abrasion and tear resistance
- Class III - elongation as per AS/NZ 4858 High build application is possible

USE AREAS

- Wet Areas
- Podiums
- Basements
- Walls and Floors
- Plant Rooms
- Planter Boxes
- Bathrooms
- Retaining Walls
- Balconies

TECHNICAL INFORMATION

Composition	Single-Pack moisture curing Polyurethane
Specific Gravity (g/cm³)	1.30 - 1.35
Service Temperature (°C)	- 20 to +80
Curing time (hours)	Cured overnight
Shelf life (months)	9
Non volatilies (%)	92
VOC content (g/L)	130
Odour	Light almond smell
Tensile Strength (MPa)	2.0
Elongation (%)	>300%
Hardness (Shore A)	45
Angle Tear Strength (Kg/cm)	11
Re-coating interval (days)	Maximum 2 days after application
Recommended substrate temperature(°C)	+5 to +35
Recommended substrate moisture (%)	Up to 5
Recommended relative humidity (%)	Between 20 and 90
Coverage Rate	Minimum 2 coats required, each at 1.0 Litre/m² [1.0m²/litre]

Tiling: DO NOT direct stick tiles to membrane. Use unbonded screed method in accordance with AS3958.1. Allow 24 hours to cure prior to covering with surface finishes.

SINCE 1977



COVERAGE

Internal Wet Area Walls 0.6mm Dry Film Thickness	1.0 litres/m², 15m² per pail
Internal Wet Area Floors 1.0mm Dry Film Thickness	1.5 litres/m², 10m² per pail
Bathrooms (internal walls & floor combined) Average	1.13 litres/m,²13m ² per pail
External Floors, Walls, Basements, Roofs & Decks 1.0mm Dry Film Thickness	1.5 litres/m,²10m ² per pail

SUBSTRATE PREPARATION

Ensure sheet surfaces are firmly fixed to manufacturer's directions. Surface must be free of dirt, dust, loose particles, oily contaminates, old membranes & coatings laitance, curing compounds and flaking concrete, etc. Grind, acid etch or sandblast concrete if necessary. Concrete must be a minimum strength of 20MPa and have cured a minimum of 28 days. Concrete should be fine broom finished. Surfaces must be dry with a moisture content below 5%. Fill all screw holes, cracks and voids with PU sealant. Install leak control flanges around all pipe penetrations. Build-up areas that are likely to cause ponding.

PRIMING

The preferred primer for general use is Duromix Hibuild WBE Primer. PU Primer is suitable where the condition of the concrete surface needs a primer with good penetration. Coat PU primer within 24 hrs. For wet areas, e.g. showers or where prolonged water contact is likely prime and completely seal the surface with Hibuild WBE beforehand. Refer to the Hibuild WBE technical data sheet for full instructions. PVC fittings should be etched primed.

DETAILING

Apply a 10-15mm fillet of PU Sealant between all horizontal to vertical joints. Apply to all horizontal to vertical junctions, and around pipe/column penetrations. Around water and floor waste outlets, and over fine shrinkage cracks, apply additional DUROPROOF™ NEP 900 to 0.75mm dry film thickness and dress up to penetrations and down into waste outlets. To joins in sheet flooring, tape and bandage over the PU sealant joint. Cut out cracks in concrete to 6mm minimum width by 6mm minimum depth and fill.

APPLICATION

To the prepared surface, apply DUROPROOF™ NEP 900 by notched squeegee, spreader, brush or roller within a maximum of 48 hours between coats to achieve an optimum intercoat bond. Turn membrane up at walls and penetrations and down into drainage outlets. When dry, check for pinholes or misses and rectify if necessary. If membrane becomes dirty between coats, clean with Xylene to ensure adhesion. Allow 24 hours to dry before covering.

PRECAUTIONS

Do not apply above 35°C or below 50°C ambient temperature, or if the Relative Humidity is greater than 90%. If applying more thanone coat externally, ensure before starting the job, that rain is not expected between coats. Do not apply mortar beds until the membrane is fully dry. Protect membrane against damage before and during covering with mortar. Protect membrane against the action of roots.

WARNING AND HAZARDS

Keep away from heat and flame. Use only with adequate ventilation.
Refer to MSDS prior to use.

HANDING AND STORAGE

DUROPROOF™ NEP 900 can be stored for 6 months at below 25ºC. Avoid prolonged exposure to humidity or high temperature, contamination with water or alcohols. The product is very sensitive to air and moisture. Once opened, use completely as soon as possible and do not reseal for future use.

Durotech Industries Pty Ltd

Address 14 Essex Street, P.O Box 5092, Minto, NSW 2566
Phone +61 2 9603 1177
Fax +61 2 9475 5059
Email sales@durotechindustries.com.au
Web www.durotechindustries.com.au

The information provided in this data sheet is correct at the time of printing (albeit is subject to change at any time) and is intended to give a simple description of the product and its capabilities. In practice, the substrate, intended surface to be treated and environmental conditions vary widely, making it essential for the user to determine the products suitability for a particular application and to ensure that the product is not used beyond its physical limitations. If in doubt contact the manufacturer. The product will perform as described herein provided it is applied in accordance with the manufacturer's instructions as stated in this data sheet and provided that the building and installation is structurally sound and the application is carried out competently. Durotech terms and conditions of sale apply.