
# Data Acquisition and Processing


## **Spring-Mass System**






## **Data Acquisition**


- 3 axis accelerometer
- Data acquisition device (LabJack):





# **Signal Processing: Basics**

• Sampling frequency












#### **Fast Fourier Transform (FFT)**

$$f(t) = 10\sin(2\pi 100t) + 5\sin(2\pi 500t) + 20\sin(2\pi 700t)$$






# Windowing




FFT of Recreated Signal




Modified FFT


# **Types of Windows**



#### • Moving average



Original Signal



Filtered Signal