



Comparator reads $V_{TOP_P} - V_{TOP_N}$; P/N switches and mismatch parameters are independent

P side



SAMPLE V_{INP} | CONVERT V_{REFP} / V_{CM} / V_{REFN}

N side



SAMPLE V_{INN} | CONVERT V_{REFP} / V_{CM} / V_{REFN}