


vcvs.ebe

Attributes

```
ebe name=vcvs  
nodes: p n cp cn  
rparms: alpha=1  
outparms: i v pwr
```

Description

`vcvs.ebe` is a voltage-controlled voltage source, with nodes and parameters as shown in the figure.



The branch current, branch voltage, and power absorbed are made available as output variables `i`, `v`, and `pwr`, respectively.