## LARUS Key Commands



While Boot	Loader is powered-on		
ESC	Force Interactive BootLoader Re	Start	
Button4	Jump to Application Without Che	eck (Good Luck !!)	)
Application Start / BackGround		Reboot	
<del> </del>		Button5	Toggle Mute – UnMute
		Button4	
Button3	Clear Logbook	Button3	
ESC	Set Configuration to Factory	ESC	Cancel Alarm
		SEL+Button5	
		SEL+Button4	Flash BL and Reboot
		SEL+Button3	Cold Restart of BL
		SEL+ESC	ReBoot
VarioValues		VarioWind	
Button5	Toggle Mute – UnMute	Button5	Toggle Mute – UnMute
Button4	Toggle Climb-Glide-Auto	Button4	Toggle Climb-Glide-Auto
Button3	Toggle ThermalFinder on-off	Button3	Toggle ThermalFinder on-off
ESC	Cancel Alarm	ESC	Cancel Alarm
SEL+Button5	Toggle Tune Test	SEL+Button5	Toggle Tune Test
SEL+Button4	Toggle Abs-Rel-WindInClimb	SEL+Button4	Toggle Abs-Rel-WindInClimb
SEL+Button3	Toggle ClimbInCruiseModes	SEL+Button3	Toggle ClimbInCruiseModes
SEL+ESC	Perform Altitude Correction	SEL+ESC	Perform Altitude Correction
i			
Horizont		Wendezeiger	
Button5	Toggle Mute – UnMute	Button5	Toggle Mute – UnMute
Button4	Toggle Climb-Glide-Auto	Button4	Toggle Climb-Glide-Auto
Button3		Button3	
ESC	Cancel Alarm	ESC	Cancel Alarm
SEL+Button5	Round-Robin Colors	SEL+Button5	
SEL+Button4	Toggle Vario Average Source	SEL+Button4	Toggle Vario Average Source
SEL+Button3	Toggle Drift-Track	SEL+Button3	Toggle Drift-Track
SEL+ESC	Toggle Scale	SEL+ESC	Toggle Scale
Logbook		G-Meter	
Button5	Toggle Mute – UnMute	Button5	Toggle Mute – UnMute
Button4	Toggle Climb-Glide-Auto	Button4	Toggle Climb-Glide-Auto
Button3		Button3	
ESC	Cancel Alarm	ESC	Cancel Alarm
SEL+Button5		SEL+Button5	
SEL+Button4		SEL+Button4	
SEL+Button3		SEL+Button3	
SEL+ESC	Clear Logbook	SEL+ESC	Clear High Values