



## How to import your Measuring Data from .txt into Excel

- 1) Connect your GLM to your PC (via USB)
- 2) Open Microsoft Excel
- Select 'File' → Select 'Open'






Search for your GLM → Select 'All Files' → Open 'Memory.txt'




Readme 2 | 4


## 5) Select 'Delimited' and click 'Next'



## 6) Select 'Comma' and click 'Next'




## 7) Select 'Advanced'




Readme 3 | 4


8) Select '.' for 'Decimal separator' and ',' for 'Thousands separator'



9) Select all (press ) and then select 'Format'




10) Select 'AutoFit Column Width'



Readme 4 | 4

11) Your data should now look like this:



Please be aware that only metric units (m, m², m³) and degree (°) are displayed, independent of the tool settings.