



USB Camera Quick Installation Guide

1. Package Contents



USB Camera




USB 3.0 Cable





Remote Control

2. Introduction of Product Functions



No.	Item	Function Descriptions
1	Lens Modules	8.5 megapixels, 4K wide-angle lens
2	IR Sensor	Receive IR signal
3	LED Indicator	Display light signals based on the camera status
4	Microphone	Capture sound while filming
5	USB 3.0 Type C Port	Connect to a computer for power
6	Tripod deck lock hole	1/4" lock hole for mounting the camera

3. Connecting the Product




- Place the camera on top of the screen and adjust the bracket to install the camera on the screen.
- Connect one end of the USB to the camera and the other end to the computer. The camera driver will be installed in the computer automatically.

4. View the camera image

- Please download Lumens USB PTZ Camera Controller software from the Lumens website for installation in order to view images and control the camera.
<https://www.MyLumens.com/support>
- Furthermore, use free video capture tools AMCap, PotPlayer, VLC to view the images.
- The factory default setting for the output resolution is 1920x1080.




5. Enable the smart viewfinder function




- The smart viewfinder function adopts Auto-Framing Technology. The camera can automatically detect positions of human bodies according to change in number of people on the spot, and position people in the center of the image in order to display the best image and enhance the meeting effectiveness.
- Press the Auto Frame button on the remote control to enable/disable the smart viewfinder function.

USB摄像机快速安装手册

1. 配件清单



USB
摄像机




USB 3.0
连接线





遥控器

2. 产品功能简介



项目	名称	功能说明
1	镜头模组	850万像素,4K广角镜头
2	红外接收传感器	接收红外信号
3	LED指示灯	依摄像机状态显示指示灯状态
4	麦克风	进行拍摄时收音
5	USB3.0 Type C连接埠	连接电脑供电使用
6	脚架锁孔	1/4"锁孔,用于固定摄像机

3. 产品连接说明




- 将摄像机放至荧幕上方，并调整支架将其固定于荧幕上。
- 将USB线一端连接至摄像机，另一端连接至电脑，电脑即会自动安装摄像机驱动程序。

4. 观看摄像机影像

- 请至Lumens网站下载并安装 Lumens USB PTZ Camera Controller软体，可观看影像及控制摄像机 <https://www.Lumens.cn/support>。
- 亦可使用AMCap、PotPlayer、VLC等免费视讯软体来撷取及观看摄像机影像。
- 出厂输出解析度设定为1920x1080。



5. 启用智能取景功能



- 智能取景功能采用 Auto-Framing技术，摄像机会依照会议场景人数变化，自动侦测人体位置，将人物置放在画面中央位置，以呈现最佳影像，提升会议效率。
- 按压遥控器Auto Frame按钮，即可开启/关闭智能取景功能。

