Protocol Description

DOC-000263





White Zelle Controller

Software Protocol Description

WHITE ZELLE CONTROLLER	
1. REVISION HISTORY	
2. GENERAL FUNCTION	
2.1. OPERATION MODE	
3. DATA TYPES	
4. COMMANDS PC ⇒ CONTROLLER BOARD	
4.1. COMMAND-STRUCTURE	
4.2. COMMAND-LIST CONTROLLER BOARD	
4.3. COMMAND DATA DETAILS	
4.3.1. SetValve	
4.3.2. SetRelay	Fehler! Textmarke nicht definiert
5. OPERATION DATA	
5.1. Data-Structure	
5.2. Data Details	
5.2.1. ControllerStatus	
5.2.2. ErrorCode	
5.2.3. Valves	
5.2.4. DigitalIn	Fehler! Textmarke nicht definiert
5.2.5 RelayStatus	Fehler! Textmarke nicht definiert

1. Revision History

Rev.	Date	Name	Comment	
00	09.10.2013	bm	Initial Revision.	
01	30.05.2014	ue/bm	Different changes because of redesign of White-Cell.	

Protocol Description

DOC-000263

01



2. General function

2.1. Operation Mode

To start Operation Mode the Software has to be sent a start command to the Controller Board. After this the Controller starts sending a full set of Operation Data every 100ms.

2.2. Connection Parameter (USB/RS232)

Baudrate	57600 Baud
Data	8 Bits
Stop	1 Stop Bit
Parity	None
Flow	None

2.3. Data Integrity

Communication between PC and Main Controller is verified by a CRC-Checksum (CRC-Standard CrcCCITT = $x^16+x^12+x^5+1$. The Start-value is 0).

3. Data Types

Following data types are used in the data protocols and commands.

	, p	acca in the data protection and community
Name	Bytes	Range
Byte	1	0255
Word	2	065535
Int16	2	-32.76832767
Longword	4	04294967295
Longint	4	-21474836482147483647

High-Byte is sent first.

Vorlage: Normal.dotm
Datei: DOC-000263_01_Protocol Description - Software Controller White Zelle.docx

Protocol Description

DOC-000263





4.1. Command-Structure

Byte:	0	1	2	3	4	5	6	7	8
	Start	CMD	Data	Data	Data	Data	Stop	CRC	CRC
	(02h)	ID	0	1	2	3	(03h)	(High)	(Low)

Byte No.	Name	Type	Value	Description
0	Start	Byte	02h	fix, Start-Byte
1	CMD	Byte	0255	Command Code, refer to table below
2	Data 0	Byte	0255	Data transfer, 1 st Byte, unused is zero
3	Data 1	Byte	0255	Data transfer, 2 nd Byte, unused is zero
4	Data 2	Byte	0255	Data transfer, 3 rd Byte, unused is zero
5	Data 3	Byte	0255	Data transfer, 4 th Byte, unused is zero
6	Stop	Byte	03h	Stop-Byte
78	CRC	Int16	065535	CheckSum of previous Bytes, CRC16-CCITT (1021h)

4.2. Command-List Controller Board

CMD	Name	Data- type	Value	Unit	Beschreibung	
1	StartCom	-	-	-	Start Operation Mode of GDS	
2	StopCom	-	-	-	Stop Operation Mode of GDS	
3	StartBootloader	-	-	-	Starts the bootloader mode for firmware update, normal communication is lost, a special bootloader program does the update	
4	SetValves	Byte	0255	-	Set valves	
5	SetPumpPower	Byte	0100	%	0 = stop pump 100 = pump max. power	
6	SetReserve	Byte	0, 1	-	0 = not active 1 = active	
10	SetTempHeater	Int16	20006000	°C*100	Set temperature heater 20,00°C60,00°C	
11	SetPressureSetpoint	Int16	12007000	mbar	Pressure setpoint (absolute)	
12	StartPres.Regulation	-	-	-	Start pressure regulation	
13	StopPres.Regulation	-	-	-	Stop pressure regulation	
14	StartHeat.Regulation	-	-	-	Start heater regulation	
15	StopHeat.Regulation	-	-	-	Stop heater regulation	

4.3. Command Data Details

4.3.1. SetValve

Bit	Function
DIT	
0	V1 (0 = close, 1 = open)
1	V2 (0 = close, 1 = open)
2	V3 (0 = close, 1 = open)
3	V4 (0 = close, 1 = open)
4	V5 (0 = close, 1 = open)
5	V6 (0 = close, 1 = open)
6	V7 (0 = close, 1 = open)
7	V8 (0 = close, 1 = open)

Vorlage: Normal.dotm
Datei: DOC-000263_01_Protocol Description - Software Controller White Zelle.docx Jüke Systemtechnik GmbH, Trumpenstiege 2, D-48341 Altenberge

DOC-000263



5. Operation Data

5.1. Data-Structure

Byte: 0 1 2 3 N-4 N-3 N-2 N-1 Ν Start Length Data Data Data Data Stop CRC CRC (03h) (02h) (N+1)0 (High) 1 n-1 n (Low)

N = 78

Length = N+1 = 79

Byte No.	Name	Туре	Value	Unit	Description	
0	Start	Byte	02h	-	fix, Start Byte, signals start of frame	
1	Length	Byte	N+1	-	Number of Bytes of complete protocol-frame, Byte 0N, incl. Start/Stop bytes and Checksum	
2	ControllerStatus	Word	065535	-	Controller White Zelle Controller	
4	ErrorFlags	Word	065535	-	Error Flags Controller	
6	ValveStatus	Byte	0255	=	Valve Status	
7	PowerHeater	Byte	0100	%	Heater Power 0100%	
8	TempHeater	Int16	06000	°C*100	Temperature Heater 0,0060,00°C	
10	SetpointHeater	Int16	06000	°C*100	Temperature Heater 0,0060,00°C	
12	ActualPressure	Int16	010000	mbar	Actual Pressure 010 000mbar	
14	PressureSetpoint	Int16	010000	mbar	Pressure Setpoint 010 000mbar	
16	Reserve	Byte				
17	PumpPower	Byte	0100	%	Pump Power	
18	TempPT100_1	Int16	012000	°C*100	Temperature Heater 0,00120,00°C	
20	TempPT100_2	Int16	012000	°C*100	Temperature Heater 0,00120,00°C	
22	Counter	Byte	0255	-	Dataset counter	
23	Stop	Byte	03h	-	fix, Stop Byte, signals end of frame	
24	CheckSum	Word	065535	-	CheckSum over all previous Bytes, CRC16-CCITT (1021h)	

All data bytes are sent as numeric format. So the Control Software is needed to decode this data structure.

5.2. Data Details

5.2.1. ControllerStatus

Bit	Nama	Function / Description	Bit-Status		
DIT	Name	Function / Description	False (0)	True (1)	
0	StatusPump	Status of pump	Off	Pump Power > 0	
1	StatusReserveOut	Status of Reserve Out	Off	on	
2	PressureRegl.	Pressure regulation active?	Not active	active	
3	TempHeatReady	Temperature of Heater ok (setpoint reached)	Not ready	Ready	
4	HeaterRegulation	Heater regulation active?	Not active	active	
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					

5.2.2. ErrorCode

Code	Description				
0	no error				
Genera	al Control of the Con				
1	μC Error				
Pressu	re				
50	Pressure sensor error (PIRC1)				
Tempe	rature				
100	Temperature sensor error				

QM-Dokument Doc-No.:

Protocol Description

DOC-000263



Rev.:

01

5.2.3. Valves

Bit	Function
0	State of valve V1 (0 = close, 1 = open)
1	State of valve V2 (0 = close, 1 = open)
2	State of valve V3 (0 = close, 1 = open)
3	State of valve V4 (0 = close, 1 = open)
4	State of valve V5 (0 = close, 1 = open)
5	State of valve V6 (0 = close, 1 = open)
6	State of valve V7 (0 = close, 1 = open)
7	State of valve V8 (0 = close, 1 = open)

Vorlage: Normal.dotm
Datei: DOC-000263_01_Protocol Description - Software Controller White Zelle.docx

₫ 5/5