

swtpcsim — examples

2026-09-27 · 0e4d89e

Machines that boot. Each directory here is self-contained: a `.toml` that describes the machine, the media it needs lying beside it, and a note saying what you will see. Copy any one of them anywhere and it still runs — a path inside a machine file resolves against **that file**, not against the directory you launched from.

Machines

```
swtpcsim examples/altair680/altair680-uio.toml      # Altair 680b + Universal I/O board
swtpcsim examples/altair680/altair680-kcacr.toml    # Altair 680b + KCACR audio-cassette interface
swtpcsim examples/flex/flex2-40.toml               # SWTPC 6800 + DC-4, boots FLEX 2.0 ($ D)
swtpcsim examples/cp68/cp68.toml                   # SWTPC 6800 + DC-4, boots CP/68 1.0 ($ D)
swtpcsim examples/debugger/debugger.toml           # a bare 6800 for learning the symbolic debugger
```

	What it is
<code>altair680/</code>	The built-in <code>altair680</code> machine — a Motorola 6800 with MON680 on its onboard 6850 console, to the <code>.</code> prompt — with a period expansion board added. <code>altair680-uio.toml</code> fits the Universal I/O board (<code>680uio</code>): a second 6850 serial port and a 6820 PIA. <code>altair680-kcacr.toml</code> fits the KCACR audio-cassette interface (<code>680kcacr</code>) and its loader PROM at <code>FD00</code> ; <code>.J FD00</code> reads an S-record cassette into memory. See the directory's own README.
<code>flex/</code>	The built-in <code>swtpc</code> machine — a Motorola 6800 with SWTBUG on its MP-S console and a DC-4 floppy (<code>dc4</code>) — with a FLEX boot disk mounted. Six machine files cover FLEX 2.0 and 3.0 in the DC-4's three geometries (35-track/40-track single-sided, 40-track double-sided); <code>\$ D</code> boots FLEX to its <code>+++</code> prompt. <code>FLEX2-40.DSK</code> ships; the rest are a download away. See the directory's own README.
<code>cp68/</code>	The same <code>swtpc</code> machine booting TSC's CP/68 1.0 (<code>cp68.toml</code>) from <code>CP68.DSK</code> . <code>\$ D</code> boots to the HEMENWAY ASSOCIATES CP/68-1.0 sign-on and its <code>.</code> prompt — a CP/M-style DOS on a single-density 128-byte-sector disk whose track 0 is numbered <code>0,1,2,4..18</code> .

Learning the tools

	What it is
<code>debugger/</code>	A bare 6800 — 32K of RAM and an MP-S console, no ROM and no disk — for learning the monitor's symbolic debugger. A 44-byte <code>HELLO</code> program (<code>HELLO.ASM</code> / <code>.LST</code> / <code>.S19</code>) you load, disassemble by name, single-step, and break on a label by hand. See the directory's own README.

For developers

	What it is
boards/lamp/	A minimal example board (<code>lamp.h</code>) — the worked source for docs/devguide/adding-a-board.md , which walks through writing a <code>Board</code> from scratch.