Azure IoT Hands-on workshop

Azure IoT

Agenda

- 09:30-10:00 Dev environment setup, Azure Resource creation (IoT Hub, DPS, Cosmos DB, ASA, Storage, etc)
- 10:00-10:30 Set-up Raspberry Pi
- 10:40-11:00 Run D2C message application on Pi
- 11:00-11:50 Provision a device using Azure IoT DPS (X.509 Individual Enrollment)
- 13:00-13:50 D2C message, Azure Stream Analytics, Data to Storage/DB
- 14:00-17:50 Custom Vision Edge module deployment

1. Create Azure resources

- Create an IoT Hub
- Create Azure Stream Analytics
- Create Blob Storage
- Create Cosmos DB

2. Set-up Raspberry Pi

Install the Raspbian operating system for Pi

- 1. Download Raspbian.
 - a. <u>Download Raspbian Stretch</u> (the .zip file).
 - b. Extract the Raspbian image to a folder on your computer.
- 2. Install Raspbian to the microSD card.
 - a. Download and install the Etcher SD card burner utility.
 - b. Run Etcher and select the Raspbian image that you extracted in step 1.
 - c. Select the microSD card drive. Etcher may have already selected the correct drive.
 - d. Click Flash to install Raspbian to the microSD card.
 - e. Remove the microSD card from your computer when installation is complete. It's safe to remove the microSD card directly because Etcher automatically ejects or unmounts the microSD card upon completion.
 - f. Insert the microSD card into Pi.


Enable SSH and I2C

1. Connect Pi to the monitor, keyboard, and mouse.


- 2. Start Pi and then sign into Raspbian by using pi as the user name and raspberry as the password.
- 3. Click the Raspberry icon > Preferences > Raspberry Pi Configuration.



4. On the **Interfaces** tab, set **I2C** and **SSH** to **Enable**, and then click **OK**. If you don't have physical sensors and want to use simulated sensor data, this step is optional.



Connect the sensor to Pi





(+) 방향: 3.3V PWR

중간 : GPIO 4

(-) 방향 : GND

Connect Pi to the network

Note IP address of your Pi.

3. Run D2C message application on Pi

Clone sample application and install the prerequisite packages

- 1. Connect to your Raspberry Pi with one of the following SSH clients from your host computer:
 - a. <u>Download and install PuTTY for Windows.</u>

- b. Copy the IP address of your Pi into the Host name (or IP address) section and select SSH as the connection type.
- 2. Install Node.js and NPM to your Pi.

Install the latest Node.js

```
curl -sL https://deb.nodesource.com/setup_4.x | sudo -E bash
sudo apt-get -y install nodejs
```

Clone the sample application

```
git clone https://github.com/Azure-Samples/iot-hub-node-raspberrypi-client-
app
```

Install all packages for the sample

```
cd iot-hub-node-raspberrypi-client-app sudo npm install
```

Configure the sample application

1. Open the config file by running the following commands:

```
nano config.json (or using vi)
```

2. Copy and paste below config

```
{
  "simulatedData": false,
  "interval": 2000,
  "deviceId": "raspberrypi",
  "LEDPin": 5,
  "messageMax": 256,
  "credentialPath": "~/.iot-hub",
  "temperatureAlert": 30,
  "i2cOption": {
    "pin": 2,
    "i2cBusNo": 1,
    "i2cAddress": 119
  }
}
```

- 3. Save and exit by typing Control-O > Enter > Control-X.
- 4. Create AM2302Sensor.js

```
/*
 * IoT Hub Raspberry Pi NodeJS - Microsoft Sample Code - Copyright (c) 2017
 - Licensed MIT
 */
 'use strict';
const rpiDhtSensor = require('rpi-dht-sensor');
```

```
function Sensor(/* options */) {
 this.rpidhtsensor = new rpiDhtSensor.DHT22(4);
 // nothing todo
}
Sensor.prototype.init = function (callback) {
 // nothing todo
 callback();
Sensor.prototype.read = function (callback) {
 callback(null, {
   temperature: this.rpidhtsensor.read().temperature,
   humidity: this.rpidhtsensor.read().humidity
 });
}
function random(min, max) {
 return Math.random() * (max - min) + min;
}
module.exports = Sensor;
```

5. Modify messageProcessor.js

```
* IoT Hub Raspberry Pi NodeJS - Microsoft Sample Code - Copyright (c) 2017
- Licensed MIT
'use strict';
const Bme280Sensor = require('./bme280Sensor.js');
const SimulatedSensor = require('./simulatedSensor.js');
const AM2302Sensor = require('./AM2302Sensor.js');
function MessageProcessor(option) {
 option = Object.assign({
   deviceId: '[Unknown device] node',
   temperatureAlert: 30
 }, option);
 //this.sensor = option.simulatedData ? new SimulatedSensor() : new
Bme280Sensor(option.i2cOption);
 this.sensor = new AM2302Sensor();
 this.deviceId = option.deviceId;
 this.temperatureAlert = option.temperatureAlert
 this.sensor.init(() => {
   this.inited = true;
 });
}
MessageProcessor.prototype.getMessage = function (messageId, cb) {
 if (!this.inited) { return; }
```

```
this.sensor.read((err, data) => {
   if (err) {
     console.log('[Sensor] Read data failed: ' + err.message);
     return;
   }
   cb(JSON.stringify({
     messageId: messageId,
     deviceId: this.deviceId,
     temperature: data.temperature,
     humidity: data.humidity
   }), data.temperature > this.temperatureAlert);
});
}
module.exports = MessageProcessor;
```


Run the sample application

sudo node index.js '<YOUR AZURE IOT HUB DEVICE CONNECTION STRING>'


4. Provision a device using Azure IoT DPS

Prepare the environment

1. Create Device Provisioning service



2. Link the IoT Hub and DPS



Create a self-signed X.509 device certificate and individual enrollment entry

1. Clone the GitHub repo for the code samples:

```
git clone https://github.com/Azure/azure-iot-sdk-node.git --recursive
```

2. Navigate to the certificate generator script and build the project

```
cd azure-iot-sdk-node/provisioning/tools
npm install
```

3. Create a leaf X.509 certificate by running the script using your own certificate-name. The leaf certificate's common name becomes the Registration ID so be sure to only use lower-case alphanumeric and hyphens.


```
node create_test_cert.js device raspberrypidps

-rw-r--r-- 1 pi pi 1678 May 12 13:09 raspberrypidps_key.pem

-rw-r--r-- 1 pi pi 1038 May 12 13:09 raspberrypidps_fullchain.pem

-rw-r--r-- 1 pi pi 1033 May 12 13:09 raspberrypidps_cert.pem
```

4. Add individual enrollment in the Azure Portal




5. Configure "Initial Device Twin State"

```
{
   "tags": {
     "location": "camera-group01"
   },
   "properties": {
     "desired": {
        "mode": "reconnect"
     }
   }
}
```

Run provisioning application on Pi

1. Copy Global device endpoint and ID Scope



2. Copy you certificate and key to the sample folder.

```
cp raspberrypidps_cert.pem ../device/samples/
cp raspberrypidps_key.pem ../device/samples/
```

3. Navigate to the device sample script and build the project

```
cp ../device/samples/
npm install
```

4. Edit the register_x509.js file

```
var provisioningHost = '[Global Device Endpoint]';
var idScope = '[Id Scope]';
var registrationId = '[registrationId]';
var deviceCert = {
  cert: fs.readFileSync('raspberrypidps_cert.pem').toString(),
  key: fs.readFileSync('raspberrypidps_key.pem').toString()
};
```


5. Execute the script and verify IoT Hub Device details. Check

```
node register_x509.js
```


5. Process message using Azure Stream Analytics

Create Steam Analytics


- 1. 브라우저에서 Azure 포털 (https://portal.azure.com)을 탐색합니다.
- 2. +새로 만들기, 분석(Analytics)을 선택한 다음 Stream Analytics Job 을 선택합니다.



- 3. 새 Stream Analytics 작업 블레이드에서 다음을 입력합니다.
 - a. 작업 이름: hot-stream 을 입력합니다.
 - b. 구독: 지금까지 사용해 온 동일한 구독을 선택합니다.
 - c. 리소스 그룹: iot-hol 리소스 그룹을 선택합니다.
 - d. 위치: 다른 리소스와 동일한 위치를 선택합니다.
 - e. 호스팅 환경: **클라우드**를 선택합니다.




- f. 새 Stream Analytics 작업을 프로비저닝하려면 생성을 선택합니다.
- 4. 프로비저닝이 완료되면 포털에서 새 Stream Analytics 작업을 탐색합니다.
- 5. 작업 토폴로지 아래의 왼쪽 메뉴에서 입력을 선택합니다.




6. 입력 블레이드에서 +스트림 입력 추가를 선택하여 IoT Hub 에 연결된 입력을 추가합니다.



- 7. 새 입력 블레이드에서 다음을 입력합니다.
 - a. 입력 별칭: 이 값을 sensorinput 로 설정합니다.
 - b. 원본 유형: **데이터 스트림**을 선택합니다.
 - c. 원본: **IoT Hub** 를 선택합니다.
 - d. 가져오기 옵션: **구독에서 IoT Hub 선택**을 선택합니다.
 - e. IoT Hub: 기존 IoT Hub 인 smartmeter-hub 를 선택합니다.
 - f. 끝점: **메시지**을 선택합니다.
 - g. 공유 액세스 정책 이름: **서비스**로 설정합니다.
 - h. 소비자 그룹: \$Default 로 남겨둡니다.
 - i. 이벤트 직렬화 형식: JSON 을 선택합니다.
 - i. 인코딩: UTF-8 을 선택합니다.
 - k. 이벤트 압축 유형: **없음**으로 설정을 둡니다.
 - I. 생성을 선택합니다.




8. 이제 작업 토폴로지 아래의 왼쪽 메뉴에서 출력을 선택합니다.




9. 출력 블레이드에서 +추가를 선택하여 쿼리에 대한 출력 대상을 Power BI로 추가합니다.

- 10. 새 출력 블레이드에서 다음을 입력합니다.
 - a. 출력 별칭: powerbioutput 으로 설정합니다
 - b. 데이터 집합 이름: telemetry 로 설정합니다.
 - c. 테이블 이름: telemetry 로 설정합니다.
 - d. Power BI 계정에 대한 연결에 권한을 부여하려면 **권한 부여**를 선택합니다. 팝업 창에 메시지가 표시되면 핸즈온 랩 실습 전, 작업 2 에서 Power BI 계정을 만드는 데 사용한 계정 자격 증명을 입력합니다.



- e. 저장을 클릭합니다.
- 11. 다음으로 작업 토폴로지 아래의 왼쪽 메뉴에서 쿼리를 선택합니다.



12. 쿼리 텍스트 상자에서 다음 쿼리를 붙여넣습니다.

```
--평균 온도, 습도 PowerBI Presentation

SELECT AVG(temperature) AS temp, AVG(humidity) AS humidity, deviceId,

EventEnqueuedUtcTime

INTO powerbioutput

FROM sensorinput

GROUP BY TumblingWindow(minute, 5), deviceId, EventEnqueuedUtcTime
```

```
--전체 데이터 CosmosDB 저장
SELECT *
INTO cosmosdboutput
FROM sensorinput
WHERE temperature > 25
```

13. 저장을 선택하고 확인 메시지가 표시되면 예를 선택합니다.




14. Stream Analytics 작업의 개요 블레이드로 돌아가서 시작을 선택합니다.



15. 작업 시작 블레이드에서 **지금**을 선택합니다(현재 시점부터 작업이 진행되면서 메시지 처리를 시작).




- 16. 시작을 선택합니다.
- 17. 몇 분 동안 Stream Analytics 작업을 시작합니다.
- 18. Stream Analytics 작업이 성공적으로 시작되면 개요 블레이드의 **모니터링** 차트에 **입력이벤트**가 하나라도 나타나는지 확인합니다. 라즈베리파이 시뮬레이터에서 이벤트를 확인하는 동안 잠시 "Run"을 눌러서 데이타가 시뮬레이션 되도록 해야 할 수도 있습니다.



Power BI 를 통한 핫 데이터 시각화

1. Power BI 구독(https://app.powerbi.com)에 로그인하여 데이터가 수집 중인지 확인합니다.

2. 왼쪽 메뉴에서 내 작업 영역을 선택한 다음, 데이터 집합 탭을 선택합니다.




3. 데이터 집합 목록에서 telemetry 데이터 집합을 선택합니다. 데이터 집합 목록에 너무 많은 항목들이 있는 경우에는 telemetry 데이터 집합을 검색합니다. 작업 열 아래의 보고서 생성




버튼을 선택합니다.


4. 차트 시각화를 위해서는 시각화 팔레트에서 꺽은선형차트를 선택합니다.




5. 필드 목록에서 eventenqueuedutctime 필드를 선택하고 이를 축 항목으로 끌어다 놓습니다. humidity 와 temperature 필드는 값 항목에 끌어 넣습니다.




6. 시각화 메뉴에서 **테이블**을 선택하고 humidity 와 temperature 필드를 값에 넣습니다.




7. 값의 옵션 중 평균을 선택합니다. 또한, 이름 바꾸기를 통하여 이름을 변경할 수 있습니다. 서식 메뉴를 통하여 제목의 폰트나 다른 서식 요소들을 변경할 수 있습니다.



8. 보고서를 저장합니다.



9. **읽기용 보기**로 전환합니다.



10. 보고서 내의 열 중 하나를 클릭하여 해당 장치에 대한 데이터를 확인합니다.