

**ROKENBOK®**  
TOY COMPANY


# MONORAIL METROPOLIS Start Set











**WARNING:**


CHOKING HAZARD.  
Toy contains small parts and small balls. Not for children under 3 years.












- Rokenbok recommends premium alkaline batteries for use in your Rokenbok products.
- Batteries are to be inserted with correct polarity as shown.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or nickel cadmium batteries.



- Pull green activator open.
- Open battery door.
- Insert 3x AA batteries.

Your Power ROK-Lift will only be operational once properly installed in the Monorail Metropolis build.



#### To engage:

- While driving forward or reverse with the compass wheel, press the X button located on the right side of the control pad.
- Release the X button and compass wheel at the same time. Your Monorail will travel in that same direction for approximately three minutes.

#### To disengage:

- Press any button on the Control Pad to stop the Monorail from moving, otherwise the Monorail will stop moving after three minutes.

