


04273

ROKENBOK®
TOY COMPANY


RC DOZER & RECYCLING CENTER







Color of building pieces may differ from those shown.


WARNING:
CHOKING HAZARD.
Toy contains small parts and small
balls. Not for children under 3 years.












- Rokkenbok recommends premium alkaline batteries for use in your RC vehicle.
- Batteries are to be inserted with correct polarity as shown.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or nickel cadmium batteries.


Rokkenbok Radio Control Center and Control Pad required, not included.



Three Control Pad ports for additional players.



Previous Vehicle Selection Push to Slow



A/B



Push A/B to Raise and Lower Dozer Blade

