

Input Screening - SOP

Titan Track and Trace

1. User Login

- 1 Open the application.
- 2 Sign in using your Microsoft Account (Microsoft SSO).
- 3 After successful authentication, the system redirects you to the Dashboard.

2. Open Input Screening

- 1 From the Dashboard, navigate to:
 - Production → Input Screening
- 2 Open the Input Screening Pick Table.
 - The newly received lots from Day Planning will be available.

For each new lot:

- **Lot Status:** Yet to Start
- **Current Stage:** Day Planning

This indicates that the lot has arrived from Day Planning and is waiting for Input Screening.

3. Verify Tray IDs

- 1 Click the View icon in the Action column.
- 2 The Tray Verification window opens.
 - All Tray IDs mapped during Day Planning are displayed.
- 3 Verify each Tray ID by:
 - Scanning using Barcode Scanner
 - Clicking an existing Tray ID
 - Manually entering the Tray ID
- 4 The system validates every scanned Tray ID.
 - Status is displayed as: **Verified** or **Not Verified**
- 5 After all Tray IDs are successfully verified:
 - The verification window closes automatically.
 - Accept and Reject actions become enabled.

4. Accept the Lot

- 1 Click **Accept**.
- 2 A confirmation dialog is displayed.
- 3 Click **Confirm**.
 - The system will complete Input Screening and move the accepted lot forward.

Input Screening Complete Table • Brass QC Pick Table

5. Reject the Lot

- Click **Reject** to open the rejection window.
- The system provides two rejection options.

Option 1 - Full Lot Rejection

- 1 Click **Lot Reject (Top-right corner)**.
- 2 Confirm the rejection.

The system will:

- Reject the complete lot.
- Move it to the Input Screening Reject Table.
- Stop further processing and traceability for this phase.

Option 2 - Reject with Reasons

- 1 Select the rejection reason(s).
- 2 Enter the rejected quantity against each reason.

The system automatically calculates and distributes, based on the entered rejection quantities:

Accepted Quantity

Rejected Quantity

Delink Quantity

6. Tray ID Scanning

Tray IDs can be scanned using any of the following methods:

- Barcode Scanner
- Click an existing Tray ID
- Manual Tray ID entry

7. Rejection Tray Handling

The system first requires users to complete the Rejected Tray scanning. Only after rejected trays are completed can users proceed with the Delink process.

8. Delink Process

If rejected material needs to be moved into another tray:

Scenario 1 - Empty Existing Tray Available

The system displays eligible empty trays. Users can:

- Select an existing empty tray
- Or scan a valid empty Tray ID

Scenario 2 - New Tray Required

If no eligible empty tray exists:

- Scan a new Tray ID.
- The system validates the new tray before assignment.

Invalid Tray Validation

If an invalid Tray ID is scanned, the cursor remains in the Tray ID field and the system displays an error message. Users must scan a valid Tray ID before continuing.

9. Remarks

The Remarks column allows users to enter additional comments.

Remarks entered during Input Screening are carried forward and can be viewed in:

Input Screening Complete Table

Input Screening Accepted Table

Input Screening Rejected Table

Brass QC Pick Table

Hover over the Remarks field to view the complete comment.

10. Save as Draft

At any stage during processing:

- Click **Draft**.
- The system saves all progress.
- Users can resume processing later without losing data.

11. Submit

After completing:

- Tray Verification
- Acceptance or Rejection
- Tray Scanning
- Delink (if applicable)
- Remarks

Click **Submit**. The lot is processed and moved to the next stage.

12.Sub Modules

Input Screening - Accepted

Displays only fully accepted lots. Information includes:

- Accepted Quantity
- Tray Information
- Remarks

Input Screening - Rejected

Displays rejected lots. Information includes:

- Rejected Quantity
- Rejection Reason
- Tray Details
- Remarks

Input Screening - Complete

Displays the complete processing summary. Includes:

- Original Lot Quantity
- Accepted Quantity
- Rejected Quantity
- Tray Information
- Remarks
- Processing Status

★Complete Workflow

- 1 Sign in using Microsoft SSO.
- 2 Navigate to Input Screening.
- 3 Open the Pick Table.
- 4 Verify all Tray IDs using the View option.
- 5 Scan Tray IDs using a scanner, by clicking an existing Tray ID, or by manual entry.
- 6 Ensure all Tray IDs are Verified.
- 7 Choose Accept or Reject.

- 8 For Accept, confirm the action to move the lot to the Complete Table and Brass QC Pick Table.**
- 9 For Reject, either:**
 - Perform a Full Lot Rejection, or
 - Reject specific quantities by entering rejection reasons and quantities.
- 10 Complete Rejected Tray scanning first.**
- 11 Perform the Delink process using eligible empty trays or a new valid tray if required.**
- 12 Enter Remarks if needed.**
- 13 Save the process as Draft at any time to resume later.**
- 14 Click Submit.**
- 15 Verify the processed lot in the appropriate sub-module (Accepted, Rejected, or Complete) and confirm that accepted lots are available in the Brass QC Pick Table.**