Dennis Chen PS08

a. Sketch $x_p(t)$
(sampled original signal)



b. Sketch $P(\omega)$



$$\sqrt{\frac{1}{LC} - \frac{1}{2}\frac{R^2}{L^2}}$$

c. Sketch $X_p(\omega)$



d. $\omega_m \leq \frac{\pi}{T_s}$ to keep all information.

e. To recover $x(t)$ from $x_p(t)$, bandpass $x_p(t)$ b/w $-\omega_m$ & ω_m, & then scale by $\frac{T_s}{2\pi}$ to get $x(t)$.

g. given $z(t)$, sketch $x_z(t) = x_p * z(t)$



holds last sampled value until the next one

h. Sketch $X_z(w)$

$z(t) = 1$ when $0 \le t \le T_s$
0 otherwise

$$Z(w) = \int_{-\infty}^{\infty} z(t) e^{-jwt}\, dt$$

$$= \int_0^{T_s} e^{-jwt}\, dt$$

$$= \left[\frac{e^{-jwt}}{-jw} \right]_0^{T_s} = \frac{e^{-jwT_s}}{-jw} - \frac{1}{-jw}$$

$$= \frac{1 - e^{-jwT_s}}{jw}$$

$1 - \cos(-wT_s) - j\sin(-wT$

$e^{j(-wT_s)} = \cos(-wT_s) + j\sin(-wT$

$e^{j\theta} = \cos\theta + j\sin\theta$



$x(t - t_0) \rightarrow e^{-jwt_0} X(w)$

$\sin = 0$ at $w =$ $x = 0$ or π

$$Z(w) = e^{-j\frac{wT_s}{2}} \cdot T_s \operatorname{sinc}\left(\frac{wT_s}{2\pi}\right)$$

→ this is of form $Ae^{j\theta}$ w/ amplitude & phase

$X_z(w) = X_p(w) Z(w)$



i. Sketch $\bar{X}(w) = X_\delta(w)H(w)$ & $\hat{X}(w) = X_p(w)H(w)$



j. How are $\bar{X}(w)$ & $\hat{X}(w)$ different?

$\bar{X}(w)$ & $\hat{X}(w)$ have different amplitudes, & $\bar{X}(w)$ was multiplied by a part of a sinc, so it is not a scaled version of the original, it's frequencies decrease more quickly when you go from 0 to W_M as compared to $\hat{X}(w)$. Another way of saying that is that it has a different envelope.

k. What is the ratio of $\bar{X}(W_M)$ to $\hat{X}(W_M)$ when $W_M = \frac{\pi}{T_s}$?

$$\left|Z\left(\frac{\pi}{T_s}\right)\right| = T_s \operatorname{sinc}\left(\frac{1}{2}\right) \rightarrow T_s \cdot \frac{\sin\left(\frac{\pi}{2}\right)}{\frac{\pi}{2}} = T_s \cdot \frac{2}{\pi} = \frac{2T_s}{\pi}$$

The ratio is $\frac{2T_s}{\pi}$, since you get $\bar{X}(w)$ effectively by multiplying $Z(w)$ by $X_p(w)$ & filtering b/w W_c & $-W_c$.

2a. $y(t) = x_1(t)\cos(\omega_1 t) + x_2(t)\cos(\omega_2 t)$, sketch $Y(\omega)$



b. sketch FFT of $y(t)\cos(\omega_1 t)$ & $y(t)\cos(\omega_2 t)$

$Y_1(\omega)$ $Y_2(\omega)$





c. To recover $x_1(t)$ from $y(t)$, multiply $y(t)$ by $\cos(\omega_1 t)$, lowpass filter w/ a cutoff at ω_M, & multiply the amplitude of the signal by 2. To recover $x_2(t)$, repeat the same process but multiply by $\cos(\omega_2 t)$ instead.

3.



$$i(t) = C\frac{d}{dt}V_{out}(t)$$

$$V_L(t) = L\frac{d}{dt}i(t) = CL\frac{d^2}{dt^2}V_{out}(t)$$

$$V_R(t) = R\,i(t) = RC\frac{d}{dt}V_{out}(t)$$

a. Write a diffeq relating Vout & Vin.

$$V_{in}(t) = V_R(t) + V_L(t) + V_{out}(t)$$

$$\boxed{V_{in}(t) = RC\frac{d}{dt}V_{out}(t) + LC\frac{d^2}{dt^2}V_{out}(t) + V_{out}(t)}$$

b. Find frequency response $H(\omega)$ of the system.

$$V_{in}(\omega) = j\omega RC\,V_{out}(\omega) + (j\omega)^2 LC\,V_{out}(\omega) + V_{out}(\omega)$$

$$V_{in}(\omega) = V_{out}(\omega)\left[j\omega RC + j^2\omega^2 LC + 1\right]$$

$$H(\omega) = \frac{V_{out}(\omega)}{V_{in}(\omega)} = \frac{1}{j\omega RC + j^2\omega^2 LC + 1} = \boxed{\frac{1}{j\omega RC - \omega^2 LC + 1}}\ \frac{(1-\omega^2 LC) - \omega RC\,j}{(1-\omega^2 LC)^2 + \omega^2 R^2 C^2}$$

c. Find $|H(\omega)|$

$$|H(\omega)| = \frac{1}{|j\omega RC + 1 - \omega^2 LC|} = \boxed{\frac{1}{\sqrt{\omega^2 (RC)^2 + (1-\omega^2 LC)^2}}}$$

$$(1-\omega^2 LC)^2 = 1 - 2\omega^2 LC + \omega^4 (LC)^2$$

d. Maximize $|H(\omega)|$

minimize $\omega^2 (RC)^2 + (1-\omega^2 LC)^2 \rightarrow \omega^2 (RC)^2 + 1 - 2\omega^2 LC + \omega^4 (LC)^2$

$$\omega^4 (LC)^2 - 2\omega^2 LC + \omega^2 (RC)^2 + 1$$

when is derivative zero?

$$4(LC)^2\omega^3 - 4LC\omega + 2(RC)^2\omega = 0$$

$$\omega\left[4(LC)^2\omega^2 - 4LC + 2(RC)^2\right] = 0$$

3d continued. $\omega\left[4L^2C^2\omega^2 - 4LC + 2(RC)^2\right] = 0$

$$\omega^2 = \frac{4LC - 2(RC)^2}{4(LC)^2} = \frac{4LC}{4(LC)^2} - \frac{2R^2C^2}{4L^2C^2}$$

$$\omega^2 = \frac{1}{LC} - \frac{R^2}{2L^2}$$

$$\boxed{\omega = \pm\sqrt{\frac{1}{LC} - \frac{R^2}{2L^2}} \quad \text{to maximize } |H(\omega)|}$$


R = 50 Ohms
Amplitude
Phase
Frequency (w)


R = 400 Ohms
Amplitude
Phase
Frequency (w)