



HOME SODA MACHINE

On tap.

Keep this guide
with your install kit.

No pour: check the water shutoff and the tee lever. **No power:** check the cord and outlet, then read any display message. **Warm pour:** allow about an hour for the first chill.

Sealed cooling circuit

R-600a (isobutane), flammable refrigerant.
Under 1.5 oz (40 g). Do not open, puncture or heat.

homesodamachine.com

Guides: homesodamachine.com/drawings



HOME SODA MACHINE

Install guide

From the box
to your first glass.

SEVEN STEPS. EVERY CONNECTION.

homesodamachine.com

BEFORE YOU START

Your route to soda

Use this booklet on its own, or beside the quick start. The same seven steps appear in both.

INSTALL

- 1

Mount the faucet

5-6
- 2

Add the cold-water tee

7-11
- 3

Match the rear connections

12-13

TURN IT ON

- 4

Prepare the cylinder

14-15
- 5

Water, then gas, then power

16-18

YOUR FIRST GLASS

- 6

Fill both flavors

19-20
- 7

Chill. Choose. Pour.

21

BEFORE THE FIRST CONNECTION

Check the kit and the space on pages 3-4. Keep the cylinder valve closed and the power cord unplugged while you install.

FIRST CHECKS

Check the leaking connection

Close the water shutoff and cylinder valve. Unplug the appliance. Leave pressurized connections assembled.

Water at a push fitting

Tee, filter or white TAP tube: run the tap or dispenser fed by that same cold-water line until flow stops. Keep the white tee's side lever open, if used.
Blue SODA tube: put a jug under the soda faucet and press its lever until water and hissing stop.

After pressure is released, hold the fitting's release ring in with the collet press and pull the tube out. Check for dirt or damage. Push an undamaged tube fully to the internal stop, then tug gently.

Gas at a connection

Growing bubbles in soapy water show the leaking joint. The cylinder nut seals on one flat nylon washer; the gray connector seals on rubber. A crooked washer needs reseating; replace a damaged seal. See page 14.

Keep gas fittings assembled until the regulator and red tether are depressurized. Do not loosen a fitting to let pressure out.

After repair: repeat the water and gas checks on pages 16-17. Connect power only when water joints stay dry and gas joints show no growing bubbles.