CHAPTER 2 CSL Memory Map

All rights reserved
Copyright ©2008 Fastpath Logic, Inc.
Copying in any form without the expressed written
permission of Fastpath Logic, Inc is prohibited

TABLE 2.1 Chapter Outline

- 2.1 CSL Memory Map Command Summary
- 2.2 CSL Memory Map Commands

2.1 CSL Memory Map Command Summary

2.1.1 Memory map rules

- 1. Every unit has its own local address map in the conceptual model.
- 2. An object from a unit can only be added to a memory map once.
- 3. Multiple instances of the same unit all have the same local address map
- 4. An unit can contains multiple instances of unit's mulitple instance.
- 5. The parent map is formed by the concatenation of the address maps of the child units
- 6. memory map ranges are declared as free or reserved.
- 7. The address ranges which an object is added to is no longer free.
- 8. It is illegal to add an object to an address range which is reserved.
- 9. It is illegal to add an object outside of a declared address range
- 10. It is illegal to add an object to a used/not free address range
- 11. It is illegal to have a memory map page which is not added to a memory map.
- 12. It is illegal to have a memory map with out memory map page instances.
- 13. It is illegal to have flat memory map with multiple page instances...
- 14. It is illegal for a flat memory map to have hierarchical memory pages.
- 15. It is illegal for a virtual memory map to have hierarchical memory pages.
- 16. It is legal to have Hierarchical memory pages for hierarchical memory map.
- 17. What can be added to a memory map page? Instances of an addressable object which include:

```
csl_memory
csl_register
csl_register_file
csl_fifo
```

18. Before adding an object of a memory map page the following are required: add all address ranges (legal, reserved)

14 6/12/08

- 19. After the memory map page is built it is then added to the memory map.
- 20. It is legal to add the memory map page to the memory map and then add objects to the memory page.
- 21. mandatory cmds for a memory map are set type
- 22. memory map must have memory map pages instantiated
- 23. mandatory cmds for a memory map page are add address range
- 24. a memory map page must have at least one addressable object added to it.

 A memory map page cannot be empty
- 25. The design address limits for the memory map is optional set_address_limits(lower, upper) -this is the valid address range for the chip set_address_width(numeric_expression)-this is the width of the address bus on the chip the limits and the width can be set. This is related to the address bus on the chip.
- 26. If the design address limits for the memory map is set then check all of the pages to see that the memory map page address range is with in the design address limits and that the width of the memory map page...
- 27. A memory map page has a set unit
- 28. A memory map page has to have a set_unit before adding addressable objects to the memory map page.
- 29. Every addressable object added to the memory map page has to be instantiated in the unit specified by set unit in the memory map page.
- 30. Only one set unit can be called per memory map page

```
csl_unit a {
  rf rf0;
  a() {}
};
csl_memory_map_page mpa {
  mpa() {
    set_unit(a);
    add(rf0);
  }
};
```

- 29. A unit can only be added to one memory map page
- 30. It is illegal to add a unit can only be added to more than one memory map page
- 31. The unit instances must have different base addresses
- 32. Multiple instances of the same page need to have different base addresses
- 33. If no base address is specified for a unit instance then the base address of the unit instance in the design memory map is calculted by the order of the instantiation of the pages in the memory map csl file(s).
- 34. The base address for the unit instances can be set using the following code example

```
csl unit a { a() {} };
csl unit b { a a0; a a1; b(){}};
csl_unit top { b b0; b b1; top(){} };
csl memory map page apage{
  apage(){
    set_unit(a);
    add address range(0,511);
    set address increment(2);
};
csl_memory_map mm{
 mm () {
    set_type(hier);
    top.b0.a0.set base address( 500);
    top.b0.a1.set base address( 1000);
    top.b1.a0.set_base_address( 1500);
    top.bl.al.set base address ( 2000);
};
```

- 35. Memory map pages are automatically added to the memory map.
- 36. Memory map pages will be automatically self registering with the design's single memory map class. The memory map page will NOT be instantiated in the memory map. This is consistent with testbench and vc's.

- 37. the add_reserved_address_range can NOT be called on a memory_map_page instance.
- 38. A range may only be set once in a memory page. Setting any part of the range again is illegal
- 39. Memory map page methods can only be called in memory map page constructors.

2.1.2 Usage tables

CSL Memory map page

can be defined and instantiated

- can be defined in

TABLE 2.2 CSL memory map page definition in other CSL classes

CSL class	Can be defined in
global scope	YES
CSL Unit	-
CSL Signal Group	-
CSL Interface	-
CSL Testbench	-
CSL Vector	-
CSL State Data	-
CSL Register	-
CSL Register File	-
CSL Fifo	-
CSL Memory Map	-
CSL Memory Map Page	-
CSL Isa Element	-
CSL Isa Field	-
CSL Field	-

- can be instantiated in

TABLE 2.3 CSL memory map page instantiation in other CSL classes

CSL class	Can be instantiated in
global scope	-
CSL Unit	-
CSL Signal Group	-
CSL Interface	-
CSL Testbench	-

TABLE 2.3 CSL memory map page instantiation in other CSL classes

CSL class	Can be instantiated in
CSL Vector	-
CSL State Data	-
CSL Register	-
CSL Register File	-
CSL Fifo	-
CSL Memory Map	YES
CSL Memory Map Page	YES
CSL Isa Element	-
CSL Isa Field	-
CSL Field	-

The manadatory commands for the memory map page are:

Memory map type Manadatory commands hierarchical set_unit_name(unit_name); virtual_with_base_address set_unit_name(unit_name); virtual_with_page_number_and_address set_unit_name(unit_name); f CSL Memory map can be defined and NOT instantiated

TABLE 2.4 CSL memory map definition in other CSL classes

CSL class	Can be defined in
global scope	YES
CSL Unit	-
CSL Signal Group	-
CSL Interface	-
CSL Testbench	-
CSL Vector	-
CSL State Data	-
CSL Register	-
CSL Register File	-

- can be defined in

18 6/12/08

TABLE 2.4 CSL memory map definition in other CSL classes

CSL class	Can be defined in
CSL Fifo	-
CSL Memory Map	-
CSL Memory Map Page	-
CSL Isa Element	-
CSL Isa Field	-
CSL Field	-

The manadatory commands for the memory map page are:

Manadatory commandas for memory map page

```
set unit name(unit name);
  memory map page name.add address range(lower bound,upper bound);
Memory Map methods to be called in units:
   set_address_range(num_expr,num_expr);
   set_access_rights( addressable_object | address_range, access_right);
   add(addressable object, start address [,access rights] [,symbol]);
   set address increment (numeric expression);
   [instance_name.]set_id(num_expr);
   //setting id for use w/ address bus
   auto mapper(off);
   //turning off automapper for the current unit so that the page would
   //span across multiple units until it's turned back on
Naming
   set symbol max length (numeric expression);
Word width
   set data word width(numeric expression);
              NOTE:to be explained
   set_access_rights_enum( enum ); //i need more details on this one
   set next address(numeric expression); //same as above
Alignment
   set alignment (numeric expression);
```

NOTE:propsed for removal

```
memory map page name.add reserved address range(lower bound, upper boun
   d); //use access rights on address range?
   addr obj.add to memory map(); //leave to automapper or manually add
   csl_memory_map_page_memory_map_page_name;
   memory_map_page_name.add(memory_map_page_object_name);
Memory map commands
  Manadatory commands for memory map
  set type(memory_map_type);
Memory Map: Declaration
   csl memory map memory map name;
Memory Map
   set base address(num expr);
   set top unit (unit object name);
   set_endianess(endianess_type);
Memory Map: Word width
   set_data_word_width(numeric_expression);
Memory Map: Prefix
   set_prefix(string);//needed now ?
Memory Map: Suffix
   set sufix(string);//needed now ?
              NOTE:proposed for removal
   auto gen memory map(); //default
   object name.add to memory map([address], [group, access right]);
TBD:
set addr abs(constant numeric); //new address
set addr rel(constant numeric); //new address = offset from current address
//add set max number of words command
```

2.2 CSL Memory Map Commands

[CSL Memory Map Command Summary]

```
set_unit_name(unit_name);
DESCRIPTION:
//

EXAMPLE:
//
CSL CODE
//
VERILOG CODE
//
```

```
csl_memory_map_page memory_map_page_name;
DESCRIPTION:
```


Creates a memory map page named <code>memory_map_page_name</code>. It is a scope delimited by curly braces. Each memory map page has an address range.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example we have one memory map *mmap* which contains a memory map page *mpage*.

FIGURE 2.1



CSL CODE

```
csl_memory_map_page mpage{
  mpage() {
  add_address_range(0,128);
  };
csl_memory_map mmap{
  mpage mpage;
  mmap() {
  set_data_word_width(32);
  set_type(hierarchical);
  }
};
```

6/12/08

VERILOG CODE

```
set_address_range(num_expr, num_expr);
DESCRIPTION:
```

This command adds an address range to a memory map page named memory_map_page_name The address range is set using lower bound and upper bound.

The add_reserved_address_range command shows that a part of the initial address range is marked as reserved(and that add_address_range has to be called before add reserved address range).


A flat memory map has one page .The address range for the one page is the address range for the entire memory map.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example it was created a memory map named *mmap* with a memory map page named *mpage_1*.

FIGURE 2.2



```
CSL CODE
```

```
csl_memory_map_page mpage_1{
  mpage_1() {
  add_address_range(128,511);
  add_reserved_address_range(128, 256);
  }
};
csl_memory_map mmap{
  mpage_1 mp1;
  mmap() {
  set_data_word_width(32);
  set_type(hierarchical);
  }
```

24 6/12/08

};

VERILOG CODE

```
set_address_increment(numeric_expression);
DESCRIPTION:
```


The address increment is the amount that the memory address increments from word to word for a memory map page named $memory_map_page_name$. The $numeric\ expression\ represent$ the increment of address.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example it is set the address increment for a memory map page named m_p1 from a memory map named map.

FIGURE 2.3



CSL CODE:

```
csl_memory_map_page memp1{
  memp1() {
    set_address_increment(4);
    add_address_range(128, 511);}
};
csl_memory_map mmap{
  memp1 m_p1;
  mmap() {
    set_data_word_width(32);
    set_type(hierarchical);
  }
};
```

VERILOG CODE:

```
set_next_address(numeric_expression);
DESCRIPTION:
```


Sets the next address for a memory map page named $memory_map_page_name$. The $numeric\ expression\ represents$ the next address.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example it is set the next address in a memory map page named *memp*.

FIGURE 2.4



CSL CODE

```
csl_memory_map_page mpage{
   mpage() {
    add_address_range(0, 1024);
    set_next_address(64);
   }
};
csl_memory_map mmap{
   mpage memp;
   mmap() {
    set_data_word_width(32);
    set_type(hierarchical);
}
};
```

6/12/08

VERILOG CODE

```
set_access_rights( addressable_object | address_range,
access_right);
```

DESCRIPTION:

With this command we can set the access rights for an addressable_object (eg. an instance of a register) or an address range address_range from a memory map page name. The access rights can be the following:

TABLE 2.5

group
sw
hw
test
driver
user

TABLE 2.6

acc_right	Description
access_none	without access rights
access_read	access rights only for read
access_write	access rights only for write
access_read_write	access rights for read-write

[CSL Memory Map Command Summary]

EXAMPLE:

Sets the access rights for the memory map page named mp.

CSL CODE

```
csl_memory_map_page mp{
   mp() {
    set_access_rights(200: 251, HWR, access_read_write);
   set_access_rights( 100, SWR, access_read);
   }
};
csl_memory_map mmap{
   mp mp;
   mmap() {
   set_data_word_width(32);
   set_type(hierarchical);
```

28 6/12/08

}
};
VERILOG COD

```
set_access_rights_enum( enum );
DESCRIPTION:
```

Sets the access rights for the enum named enum.

Can only be called in the mem_map scope. The category is an enum item from the enum set by set_access_rights_enum.If no enum has been set, the category can have one of the following default values: swr, hwr, driver, test, user.

[CSL Memory Map Command Summary]

```
EXAMPLE:
//
CSL CODE
   csl enum alu{
   ADD,
   SUB,
   MUL
       };
   csl_memory_map_page mpag{
     mpag(){
       set data word width (32);
       add address range (0,512);
   };
   csl memory map mmap{
     mpag mpag;
     mmap(){
     set_access_rights_enum(alu);
     set type(hierarchical);
   };
VERILOG CODE
   //
```

30

memory map page name.add reserved address range(lower bound, upper bound);

DESCRIPTION:

Adds a reserved address range in a memory map page memory map page name. The reserved address range is adds by lower bound and upper bound.


This command shows that a part of the initial address range is marked as reserved(and that add address range has to be called before add reserved address range).

[CSL Memory Map Command Summary]

EXAMPLE:

In a memory map page *mpage* is added a reserved address range.

FIGURE 2.5



```
CSL CODE
```

```
csl_memory_map_page mpage{
     mpage(){
      add_address_range(0,255);
      add reserved address range(0,127);
      set address increment(2);
   };
   csl memory map mmap{
     mpage mpage;
     mmap(){
     set data word width(32);
     set type(hierarchical);
   };
VERILOG CODE
```

add(addressable_object, start_address [,access_rights] [,symbol]);
DESCRIPTION:


Adds to a memory map page named <code>memory_map_page_name</code> an <code>addressable_object</code> which can be a fifo , register, register file, memory that are instantiate in a unit.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example it is added a register file named *rf* in a memory map page *mp*. The *symbol* for register file is "rf" and the *base_address* is 64.

FIGURE 2.6



```
CSL CODE
   csl_register_file rf{
   rf(){
      set width(32);
      set depth(128);
   };
   csl unit a {
      rf r1;
    };
   csl memory map page mpage {
   mpage(){
      add address range (0,511);
      set address increment(2);
      add(a.r1, "rf", 64);
        }
   };
   csl memory map mmap{
   mpage mpage1;
   mmap(){
    set type(hierarchical);}
   };
```

```
addr_obj.add_to_memory_map();
```

DESCRIPTION:


Adds to a memory map an addressable object $addr_obj$ which can be a fifo , register, register file, memory that are instantiate in a unit.

[CSL Memory Map Command Summary]

EXAMPLE:

We added in a memory map *mmap* a fifo named *f* which is instantiated in a unit *top*.

FIGURE 2.7



```
CSL CODE
   csl fifo f1{
     f1(){
     set width(8);
     set depth(8);
     add_to_memory_map();
   };
   csl unit top{
     f1 f;
     top(){}
   };
   csl memory map mmap{
     mmap(){
   set_type(hierarchical);
   };
VERILOG CODE
   `define DEFAULT GROUP hwr 2
   `define DEFAULT_GROUP_test 3
   `define DEFAULT GROUP driver 4
   module f1(push,
              pop,
              full,
              empty,
              data_out,
```

```
data in,
        reset ,
        clock,
        valid);
parameter ADDR_WIDTH = 3'd4;
parameter DATA_WIDTH = 4'd8;
input push;
input pop;
input [7:0] data_in;
input reset ;
input clock;
output reg full;
output reg empty;
output reg [7:0] data out;
output reg valid;
reg [ADDR WIDTH - 1:0] wr addr;
reg [ADDR_WIDTH - 1:0] rd_addr;
reg wr_en;
reg rd en;
assign full = wr_addr + 1 == rd_addr;
assign empty = wr_addr == rd_addr;
assign wr en = !full && push;
assign rd en = !empty && pop;
f1 fifo memory fifo memory instance(.clock(clock),
                                    .data in(data in),
                                     .data_out(data_out),
                                     .rd_addr(rd_addr),
                                     .rd en(rd en),
                                     .reset_(reset_),
                                    .valid(valid),
                                    .wr addr(wr addr),
                                     .wr en(wr en));
always @( posedge clock or negedge reset ) begin
  if ( ~reset_ ) begin
   rd_addr <= 1'd0;
  end
  else
             if (pop ) begin
     rd addr <= rd addr + 1'd1;
    end
```

34 6/12/08

end

```
always @( posedge clock or negedge reset ) begin
    if ( ~reset ) begin
      wr addr <= 1'd0;</pre>
    end
    else
               if (push ) begin
        wr addr <= wr addr + 1'd1;</pre>
      end
  end
endmodule
module f1 fifo memory(clock,
                       reset_,
                       data_in,
                       data out,
                       valid,
                       wr addr,
                       rd addr,
                       wr_en,
                       rd_en);
  parameter ADDR WIDTH = 3'd4;
  parameter DATA_WIDTH = 4'd8;
  parameter NUM WORDS = (1'd1 << DATA WIDTH);</pre>
  input clock;
  input reset ;
  input [DATA_WIDTH - 1:0] data_in;
  input [ADDR WIDTH - 1:0] wr addr;
  input [ADDR_WIDTH - 1:0] rd_addr;
  input wr_en;
  input rd en;
  output reg [DATA_WIDTH - 1:0] data_out;
  output reg valid;
  reg [DATA_WIDTH - 1:0] internal_memory[1'd0:NUM WORDS - 1'd1] ;
  always @( posedge clock or negedge reset_ ) begin
    if ( ~reset ) begin
      valid <= 1'd1;</pre>
    end
    else begin
```

```
valid <= rd_en;
  data_out <= internal_memory[rd_addr];
  if ( wr_en ) begin
    internal_memory[wr_addr] <= data_in;
  end
  end
  end
end
endmodule

module top();
  f1 f();
endmodule</pre>
```

memory map page name.add(memory map page object name);

DESCRIPTION:


This command adds a memory map page object named memory_map_page_object_name to a memory map page memory_map_page_name.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example two memory map pages mpage1 and mpage2 are added.

FIGURE 2.8



CSL CODE

```
csl memory map page mpage1{
     mpage1(){
     add_address_range(512,1023);
     add (mpage1);
   };
   csl memory map page mpage2{
     mpage2(){
     add_address_range(0,511);
     add (mpage2);
   };
   csl memory map mmap{
     mpage1 mpage1;
     mpage2 mpage2;
     mmap(){
     set data word width(32);
     set type(hierarchical);
VERILOG CODE
   //
```

```
set_data_word_width(numeric_expression);
DESCRIPTION:
```

Sets the width of the words in the memory map page. If the memory map page width is specified, it is not necessary to declare the width of each individual word. The elements that will be added to the memory map page must have the width less or equal with the word with of memory map page.

[CSL Memory Map Command Summary]

EXAMPLE:

Create a memory map page named mpage with the word width 32.

FIGURE 2.9 A memory map page with word width 32

```
word width
lo addr
          mpage
hi addr
CSL CODE
   csl memory map page mpage {
     mpage(){
     set data word width (32);
   };
   csl memory map mmap{
     mpage mpage;
     mmap(){
      set data word width (32);
      set type(hierarchical);
VERILOG CODE
C++ CODE
   const int WORD WIDTH = 16;
```

set_alignment(numeric_expression); DESCRIPTION:

Address alignment - addresses are byte, half-word (16-bit), word (32-bit), double-word (64-bit), quad-word (128-bit) aligned. The width of the memory elements in a particular memory element range.

TABLE 2.7 Byte aligned

Type	Dimension
byte	8
half word	16
word	32
double word	64
long word	128
quad word	256

[CSL Memory Map Command Summary]

EXAMPLE:

Create two memory map pages named mpage_0 and mpage_1 set alignment as byte.

FIGURE 2.10 A memory map with byte alignment

CSL CODE

6/12/08

```
csl_memory_map_page mpage_0{
   mpage_0() {
   add_address_range(0,63);
   set_address_increment(2);
   set_alignment(16);
   }
};
csl_memory_map mmap{
   mpage_0 mpage_0;
   mmap() {
   set_data_word_width(16);
   set_type(hierarchical);
}
};
```

39

VERILOG CODE

'define <MMN>_ALIGN 16

```
set_endianess(endianess_type);
```

DESCRIPTION:

The endianess of the memory map can be specified with the **endianess** keword. The *endianess_type* can be either little endian or big endian respectively.

TABLE 2.8 Endianess Type


Endianess	Mnemonic
Little Endian	little_endian
Big Endian	big_endian

[CSL Memory Map Command Summary]

EXAMPLE:


Create a memory map page named *mpage0* and set endianess to big endian.

FIGURE 2.11 Little Endian



memory map

FIGURE 2.12 Big Endian



memory_map

CSL CODE

```
csl_memory_map_page mpage0{
  mpage0() {
  add_address_range(0,128);
  set_endianess(big_endian);
  }
};
csl_memory_map mmap{
  mpage0 mpage0;
  mmap() {
  set_data_word_width(32);
```

Fastpath Logic Inc.

```
set_type(hierarchical);
});
```

43

```
set_symbol_max_length(numeric_expression);
DESCRIPTION:
```

Sets the maximum number of characters for each word (name) in the memory map name. The number of characters for each word can be less or equal with the maximum length.

[CSL Memory Map Command Summary]

EXAMPLE:

Create a memory map page with the name *mpage_0* and set the maximum number of characters for the name of elements to 10.

CSL CODE

```
csl_memory_map_page mpage_0 {
    mpage_0() {
    add_address_range(0, 63);
    set_symbol_max_length(10);
    }
};
csl_memory_map mmap{
    mpage_0 mpage_0;
    mmap() {
    set_type(hierarchical);
    }
};
VERILOG CODE
    'define MEM_MAP_MAX_LENGTH 10;
```

```
csl memory map memory map name;
This command declares an object of type memory map, named memory map name.
                                           [ CSL Memory Map Command Summary ]
EXAMPLE:
Create a memory_map named mmap.
FIGURE 2.13 A memory map named mmap
  mmap
CSL CODE
   //AV
   //creates a memory map with the name mmap;
   csl memory map mmap{
      mmap(){
       set_type(hierarchical);
   };
VERILOG CODE
   //AV
```

auto_gen_memory_map();

DESCRIPTION:

This command is used to generate automatic the memory map for the all memory elements and unit instances

[CSL Memory Map Command Summary]

EXAMPLE:

Generates automatic a memory map for a memory map page named pg1.

FIGURE 2.14



CSL CODE

VERILOG CODE

```
csl_memory_map_page pg1{
   pg1() {
   add_address_range(0, 511);
   }
};
csl_memory_map mmap{
   pg1 pg1;
   mmap() {
   auto_gen_memory_map();
   set_type(hierarchical);
   }
};
```

```
set_top_unit(unit_object_name);
DESCRIPTION:
```


This command is used to set the top unit that has instances of other units.

[CSL Memory Map Command Summary]

EXAMPLE:

In this example we have three units named top1, top2 and top. The unit top has instances of the top1 and top2 units named t1 and t2. In a memory map named mmap is set the top unit using set_top_unit method.

FIGURE 2.15



```
CSL CODE
   csl_unit top1{
     top1(){}
   };
   csl_unit top2{
     top2(){}
   };
   csl_unit top{
     top1 t1;
     top2 t2;
     top(){}
   };
   csl memory map mmap{
     mmap(){
     set_top_unit(top);
     set type(hierarchical);
   };
```

VERILOG CODE

```
object_name.add_to_memory_map([address],[group,access_right]);
```

DESCRIPTION:

This method will add one object called *object_name* to the memory map. Optionaly can be set the address in the memory map where the object will be mapped and the access righit for this object. At least one parameter should exist.

TABLE 2.9 Acces Rights

ACCES RIGHTS	Description
access_none	None
access_read	Read
access_write	Write
access_read_write	Read/Write

[CSL Memory Map Command Summary]

EXAMPLE:

Adds a *fifo* named *f1* to a memory map named *mmap*. Fifo will be added to the address 32 and with access write.

```
CSL CODE
   csl fifo f1{
     f1(){
     set width(32);
     set depth(128);
     add to memory map(32, SWR, access write);
   };
   csl memory map mmap{
     mmap(){
    set type(hierarchical); }
   };
VERILOG CODE
   `define DEFAULT GROUP user 0
   `define DEFAULT GROUP swr 1
   `define DEFAULT GROUP hwr 2
   `define DEFAULT GROUP test 3
   `define DEFAULT GROUP driver 4
   module f1(push,
              pop,
              full,
              empty,
              data out,
              data_in,
```

```
reset ,
         clock,
        valid);
parameter ADDR WIDTH = 4'd8;
parameter DATA WIDTH = 6'd32;
input push;
input pop;
input [31:0] data in;
input reset_;
input clock;
output reg full;
output reg empty;
output reg [31:0] data out;
output reg valid;
reg [ADDR_WIDTH - 1:0] wr_addr;
reg [ADDR WIDTH - 1:0] rd addr;
reg wr_en;
reg rd en;
assign full = wr addr + 1 == rd addr;
assign empty = wr addr == rd addr;
assign wr_en = !full && push;
assign rd en = !empty && pop;
f1_fifo_memory fifo_memory_instance(.clock(clock),
                                     .data in(data in),
                                     .data out(data out),
                                     .rd_addr(rd_addr),
                                     .rd en(rd en),
                                     .reset (reset ),
                                     .valid(valid),
                                     .wr addr(wr addr),
                                     .wr en(wr en));
always @( posedge clock or negedge reset ) begin
  if ( ~reset_ ) begin
    rd addr <= 1'd0;
  end
  else
             if (pop ) begin
      rd addr <= rd addr + 1'd1;
    end
end
always @( posedge clock or negedge reset ) begin
```

48 6/12/08

```
if ( ~reset ) begin
      wr addr <= 1'd0;</pre>
    end
    else
               if (push ) begin
        wr addr <= wr addr + 1'd1;</pre>
      end
  end
endmodule
module f1_fifo_memory(clock,
                       reset ,
                       data_in,
                       data out,
                       valid,
                       wr addr,
                       rd addr,
                       wr en,
                       rd_en);
  parameter ADDR WIDTH = 4'd8;
  parameter DATA WIDTH = 6'd32;
  parameter NUM WORDS = (1'd1 << DATA WIDTH);</pre>
  input clock;
  input reset ;
  input [DATA_WIDTH - 1:0] data_in;
  input [ADDR_WIDTH - 1:0] wr_addr;
  input [ADDR WIDTH - 1:0] rd addr;
  input wr_en;
  input rd en;
  output reg [DATA_WIDTH - 1:0] data_out;
  output reg valid;
  reg [DATA WIDTH - 1:0] internal memory[1'd0:NUM WORDS - 1'd1] ;
always @( posedge clock or negedge reset ) begin
    if ( ~reset ) begin
      valid <= 1'd1;</pre>
    end
    else begin
      valid <= rd_en;</pre>
      data out <= internal memory[rd addr];</pre>
      if (wr en ) begin
        internal memory[wr addr] <= data in;</pre>
      end
```

6/12/08 49

Confidential Copyright © 2008 Fastpath Logic, Inc. Copying in any form without the expressed written permission of Fastpath Logic, Inc. is prohibited

end end **endmodule**

```
set_type(memory_map_type);
DESCRIPTION:
```

Sets the type for a memory map. The memory map type can be one of the following:

TABLE 2.10

Memory map type
hierarchical
virtual_with_page_number_and_address
virtual_with_base_address

[CSL Memory Map Command Summary]

EXAMPLE:

In this example is set the type of a memory map *named* mmap wihch contains the instances of two memory map pages named *map0* and *map1*.

CSL CODE

```
csl_memory_map_page mpage_0{
     mpage 0(){
     add_address_range(64,511);
     set address increment(2);
     }
   };
   csl_memory_map_page mpage_1{
     mpage 1(){
     add_address_range(0,63);
     set_address_increment(1);
     }
   };
   csl_memory_map mmap{
     mpage 0 map0;
     mpage_1 map1;
     mmap()
     set data word width(32);
     set_type(hierarchical);
     }
   };
VERILOG CODE
```

6/12/08 51

```
set_prefix(string);
DESCRIPTION:
```

Applies *string* as a prefix to all names in the memory map. Acts as a global prefix to the current scope.

[CSL Memory Map Command Summary]

EXAMPLE:

In a memory map *mmap* which contains a memory map page *mpage* is set the prefix "*mem*". CSL CODE

```
csl_memory_map_page mpage {
    mpage() {
    add_address_range(0,1023);
    set_address_increment(1);
    }
};
csl_memory_map mmap {
    mpage mpage0;
    mmap() {
    set_data_word_width(32);
    set_prefix("mem");
    set_type(hierarchical);
    }
};
VERILOG CODE
    'define <MMN>_PREFIX name;
```

```
set_sufix(string);
```

DESCRIPTION:

Applies *string* as a sufix to all names in the memory map. Acts as a global sufix to the current scope. [CSL Memory Map Command Summary]

EXAMPLE:

In a memory map *mmap* which contains a memory map page *mpage* is set the sufix "mem".

CSL CODE

```
csl_memory_map_page mpage{
    mpage() {
    add_address_range(0,1023);
    set_address_increment(1);
    }
};
csl_memory_map mmap{
    mpage mpage0;
    mmap() {
    set_data_word_width(32);
    set_sufix("mem");
    set_type(hierarchical);
    }
};
VERILOG CODE
    'define <MMN>_SUFIX name;
```

2.2.1 Generated Code

2.2.1.1 Generated C++ Code !!turn this to H2

```
#ifndef __csl_I_<NAME>_VH_
#define csl I <NAME> VH
//
// DO NOT EDIT - automatically generated by <toolname>!
// -----
//
// Copyright (c) <year>, <company name>
// All Rights Reserved.
//
// This is UNPUBLISHED PROPRIETARY SOURCE CODE of <company name>;
// the contents of this file may not be disclosed to third parties,
copied or
// duplicated in any form, in whole or in part, without the prior writ-
// permission of <company name>.
//
// RESTRICTED RIGHTS LEGEND:
// Use, duplication or disclosure by the Government is subject to
restrictions
// as set forth in subdivision (c)(1)(ii) of the Rights in Technical
// and Computer Software clause at DFARS 252.227-7013, and/or in simi-
lar or
// successor clauses in the FAR, DOD or NASA FAR Supplement. Unpub-
// rights reserved under the Copyright Laws of the United States.
//
// generated C++ section
// generated from toolname : <toolname>
// path to tool:
                        : <path>
// tool version:
                        : <version>
// time stamp for tool: : <tool time stamp>
```

```
// generated from filename : <filename>
// source filename:
                     : <filename>
// source file timestamp: : <source file time stamp>
// generated file timestamp: <current file time stamp>
// Register register name
#define register name REGISTER ADDRESS 0x<address>
// value to reset the entire register to
// the following two fields can be defined using the field reset and
set values.
#define register_name_REGISTER_RESET_VAL 0x<reset_value>
#define register_name_REGISTER_SET_VAL
                                             0x<set_value>
// the shift value is equal to the LSB bit position of the field
#define register_name_field_name_SHIFT_AMOUNT <shift_value>
#define register name field name MASK
                                               <mask>
// use the following define to set the value of the field
#define register name field name SET SHIFT AND MASK <mask> << <shift>
// use the following define to get the value of the field
#define register name field name GET SHIFT AND MASK <mask> >> <shift>
#define register name field name BITRANGE
<msb bit position>:<lsb bit position>
#define register name field name INIT_VAL 0x<field init_value>
#define register name field name SET VAL 0x<field set value>
#define memory map name END ADDRESS
                                           <address>
```

2.2.1.2 Generated Verilog Code

```
#ifndef __csl_I_<NAME>_VH_
#define __csl_I_<NAME>_VH_

//
// Generated by <toolname>
// DO NOT MODIFY
```

6/12/08

```
// -----
//
// Copyright (c) <year>, <company name>
// All Rights Reserved.
//
// This is UNPUBLISHED PROPRIETARY SOURCE CODE of <company name>;
// the contents of this file may not be disclosed to third parties,
// duplicated in any form, in whole or in part, without the prior writ-
ten
// permission of <company name>.
// RESTRICTED RIGHTS LEGEND:
// Use, duplication or disclosure by the Government is subject to
restrictions
// as set forth in subdivision (c)(1)(ii) of the Rights in Technical
Data
// and Computer Software clause at DFARS 252.227-7013, and/or in simi-
// successor clauses in the FAR, DOD or NASA FAR Supplement. Unpub-
lished -
// rights reserved under the Copyright Laws of the United States.
// Generated verilog section
// generated from toolname : <toolname>
// path to tool:
                         <path>
// tool version:
                         <version>
// generated from filename: <filename>
// source filename:
                          <filename>
// source file timestamp: <source file time stamp>
// generated file timestamp: <current file time stamp>
#define <name> WIDTH16
#define <name> RANGE15:0
#define <name> ADDR0
// Register < reg name >
```

57

```
#define <reg name> WIDTH8
#define <reg name> RANGE7:0
#define <reg name> 32'h0
#define <reg name> RESET NUM8'bxxxxxxxx
#define <reg name> INIT NUM8'h0
//fields belonging to the above register
// there are n fields which in total width can equal but not exceed the
width of the above //register definition
#define <reg_name>_field_name_WIDTH<field_width>
#define <reg name> field name RANGE<field range>
#define <reg name> field name RW<r=2, rw=3> // 10 and 11
#define <reg_name>_field_name_NUM <field_width>'h<value> // devulat
//<value> is 0
Example:
// Register register name
#define register name ADDRESS 32'h<address>
#define register name RESET VALUE 2'b<value>
#define register name SET VALUE 3'h<value>
#define register name BITRANGE [<msb bit position>:<lsb bit position>]
#define register name REGISTER WIDTH <width>
#define register name field name BITRANGE
#define register name field name field WIDTH 1
#define register name field name ATTR
#define register_name_field_name_DEFAULT 1'h0
#define BASE ADDRESS <module name>
                                               <address>
class register name : public register {
  register name ADDRESS 32'h<address>
  register name RESET VALUE 2'b<value>
  register name SET VALUE 3'h<value>
  register_name_BITRANGE [<msb_bit_position>:<lsb_bit_position>]
 field name register name REGISTER WIDTH <width>
  register name field name BITRANGE
  register name field name field WIDTH 1
  register_name_field_name_ATTR
```

6/12/08

```
register_name_field_name_DEFAULT 1'h0
BASE_ADDRESS_<module_name> <address>
}
#endif __csl_I_<NAME>_VH_
```

2.2.2 Generated code

2.2.2.1 Generated C++ Code

```
#ifndef csl 1 <NAME> VH
#define csl 1 <NAME> VH
// DO NOT EDIT =automatically generated by <toolname>!
//
// -----
//
//Copyright (c) <year><company name>
// All Rights Reserved
//This is UNPUBLISHED PROPRIETARY SOURCE CODE of <company name>;
//the contents of this file may not be disclosed to third parties, cop-
ied or duplicated in any form, in whole or in part, without the prior
written permission of <company name>
//
//RESTRICTED RIGHTS LEGEND:
// Use, dulpication or disclosure by the Government is subject to
restrictions as se
//forth in subdivision (c)(1)(ii) of the Rights in Technical Data and
Computer Soft
//ware clause at DFARS 252.227-7013, and/or in similar or succesor
clauses in the
//FAR, DOD or NASA FAR Supplement. Unpublished rights reserved under
//Copyright Laws of the United States
//
#Generated C++ section
#toolname: <toolname>
#path to tool: <path>
```

```
#tool version: <version>
#time stamp for tool: <tool time stamp>
#generated from filename: <filename>
##file timestamp <source file timestamp>
#generated timestamp <current file time stamp>
//Register STATUS 0
#define STATUS 0
#define STATUS 0 RESET NUM 0x0
#define STATUS 0 BSY SHIFT 7
#define STATUS 0 BSY FIELD (0x1<<STATUS 0 BSY SHIFT)
#define STATUS 0 BSY RANGE 7:7
#define STATUS 0 BSY DEFAULT 0x0
#define STATUS 0 DRDY SHIFT 6
#define STATUS 0 DRDY FIELD (0x1<<STATUS 0 DRDY SHIFT)
#define STATUS 0 DRDY RANGE 6:6
#define STATUS 0 DRDY DEFAULT 0x0
#define STATUS_0_DRQ_SHIFT 3
#define STATUS 0 DRQ FIELD (0x1<<STATUS 0 DRQ SHIFT)
#define STATUS 0 DRQ RANGE 3:3
#define STATUS 0 DRQ DEFAULT 0x0
#define STATUS_0_ERR_SHIFT 0
#define STATUS 0 ERR FIELD (0x1<<STATUS 0 ERR SHIFT)
#define STATUS 0 ERR RANGE 0:0
#define STATUS 0 ERR DEFAULT 0x0
#define CEATAO LAST REG STATUS 0//0x000d
```

2.2.2.2 Generated Verilog Code


6/12/08

```
//RESTRICTED RIGHTS LEGEND:
   // Use, dulpication or disclosure by the Government is subject to
   restrictions as se
   //forth in subdivision (c)(1)(ii) of the Rights in Technical Data and
   Computer Soft
   //ware clause at DFARS 252.227-7013, and/or in similar or succesor
   clauses in the
   //FAR, DOD or NASA FAR Supplement. Unpublished rights reserved under
   //Copyright Laws of the United States
   #Generated verilog section
   #toolname : <toolname>
   #path to tool <path>
   #tool version : <version>
   #time stamp for tool: <tool time stamp>
   #generated from filename : <filename>
   #file timestamp <source file time stamp>
   #generated timestamp <current file time stamp>
   #define <name> WIDTH16
   #define <name> RANGE 15:0
   #define <name> ADDR0
   //register <reg name> 0
   #define <reg name> 0 WIDTH8
   #define <reg_name>_0_RANGE 7:0
   #define <reg name> 0 32'h0
   #define <reg name> 0 RESET NUM8'bxxxxxxxx
   #define <reg name> 0 INIT NUM8'h0
   //fields belonging to the above register
   //there are n fields which in total can equal ubt not exceeded the
   width of the above register definition
   #define <reg name> 0 field name WIDTH<field width>
   #define <reg name> 0 field name RANGE<field range>
   #define <reg name> 0 field name RW<r=2,rw=3>//10 and 11
   #define <reg name> 0 field name NUM <field width>'h<value>//devulat
   for <value>
Example:
   //register register name 0
   #define register name 032'h5
   #define register name 0 RESET NUM2'bxx
   #define register name 0 INIT NUM3'h0
```

```
#define register_name_0_RANGE2:1
#define register_name_0_WIDTH2
#define register_name_0_field_name_RANGE2
#define register_name_0_field_name_WIDTH1
#define register_name_0_field_name_RW3
#define register_name_0_field_name_DEFAULT'h0
#define register_name_0_field_name_RANGE1
#define register_name_0_field_name_WIDTH1
#define register_name_0_field_name_RW3
#define register_name_0_field_name_DEFAULT1'h0
#define BASE_ADDRESS_MODULE32'h00000000
#endif csl I <NAME> VH
```


NOTE:<Move this to commands examples>


FIGURE 2.16



```
csl_memory_map mmn;
csl_unit p[0-7];
p[0-7].set_range(mmn, 0, 29);
set_address(mmn, \1.getadde_size()*\2);
• \1=p[0-7]
• \2=[0-7]
default address= lastobject.baseaddress()+lastobject.addr_size()+mmn.inc_amounts
p[0-7].add_to_memory_map(mmn);
user next address which is equal to mmn.inc_amounts
```

FIGURE 2.17 Individual processors memory spaces and the combined memory map shrink figure





each processor address space starts at an offset

</Move this to commands examples>

<ADD>

move this ADD to sw components

Consumer Electronic Chips

FIGURE 2.18





FIGURE 2.19



</ADD>

<ADD>

Code generation - move to code gen doc lalso move the generated code abvoe

<memory_map_class_name>::enum<register_name>_<field_name_in_register>_<enum
_name_in_field>

All letters are capitilized except the enum.

Register output abreviations

mme = memory map element

```
fld = field in a register
enum = enumerated type value for a given field
```

```
C/C++ classes will be generated with a prefix letter "C". 
 C/C++ enumerated types will be generated with a prefix letter "c" 
 (i.e. enum cenum<enumerated_type_name> \{...\}).
```

Verilog code will be generated with a prefix letter "v"

Verilog defines which are equivalent to the C/C++ enumerated will be generated with a prefix letter "cv" (i.e. `define venum<enumerated type name> <value>).

enumerated types should have an illegal field which can be returned from C/C++ switch default cass and from Verilog cas statement default cases. The illegal field can be "caught" by the "downstream" logic and can flag problems with switch and case statement selector inputs. </ADD>

Virtual Memory

SW address map is global. HW address map is local. Upper bits are the page ID. Upper bits map to a unit ID.

TABLE 2.11 Virtual memory table

upper bits	global	local
0	m	0
0	n	(n-m)
1	p	0
1	q	(q-p)
2	b	0
2	c	(c-b)
3	d	0
3	e	e-d

FIGURE 2.20




TABLE 2.12

	global	local
flat	x,y	x, y
	psa+m, psa+n address	m, n
hier	x, y	x, y
v m	sa=(pno< <amount) ea=(pno<<amount)< td=""><td>1.x 1.y x,y</td></amount)<></amount) 	1.x 1.y x,y

VM base	VMPN in Addr	
000000	0000000 = (0<<20) 0	
100000	0100000 = (1<<20) 0000	
200000	0200000 = (2<<20) 0000	
20 bits global	28 bit global	

<ADDED_2007.05.12>

Different methods used for programming chip registers

Chips contain registers which need to be configured with values

6/12/08

65

The register values also need to be read out to a different unit ont he chip or outside of the chip.

CSL provides a way to write a set of registers on a chip using one or 4 different

physical bus/network topologies. The

All buses contain essentially the same set of commands.

addr (address)

data

v (valid)

cmd (command)

All buses/networks are connected to the controller and all leaf level units.

In the caes of the tree network there may be intermediate nodes which are used to

gather information from a cluster of units and for timing reasons.

- 1. In band SOC bus
- 2a. Out of band network tree
- 2b. Out of band network Ring
- 3. In band pipeline

1. In band SOC bus

Each bus master waits for a slot on the bus and then sends a bus command to

another unit on the bus. All units "listen" to the bus for bus commands addressed to the unit.

2a. Out of band network tree

The Out of band network tree has both a send and a receive network The send network contains the following of signals:

addr - data

data - address

v - valid

cmd - command

The send network is used to send data and commands to the leaf level units.

```
The leaf level units execute the commands and if requested send a reply
reply tree to the controller.
The controller broadcasts messages to all units which match the uid in
the message and then
execute the command.
2b. Out of band network Ring
The Out of band network ring connects all units in a ring topology.
The ring contains the following of signals:
addr - data
data - address
v - valid
cmd - command
3. In band pipeline
Each pipestage can contain one or more registers which can be read/
written via packets sent down the
command pipeline. The command pipelne packets contain the following
signals.
addr - data
data - address
v - valid
cmd - command
When the address in the pipestage address signal matches an address in
the pipestage and the valid is
'1' then the command is exectued and a register is either read or writ-
ten.
______
========
// note that in the memory map b elow we do not set the data word width
or the address word
width. The clsc will determine the address word width based on the
address range (start and end
addresses) for the memory map.
```

6/12/08

csl_memory_map mem_map {

 $mem_map()$

csl memory map page unit a;

```
set type(VM WITH ADDRESS);
   unit_a.set_range(0, 65767);
}
csl_enum bus_cmd {
  BUS CMD RD,
 BUS_CMD_WR,
  BUS_CMD_PING,
 BUS CMD NOP
};
// create a bus with signal names that match the pin names on the reg-
isters that the bus
// is logically connected to. There are intermediate units whiuch the
bus is connected to
// for timing and distribution reasons. The units that the bus is con-
nected to have a bus
// interface unit (BIU) that the bus is connected to. The BIU detects
commands that are
// intended for the unit and converts the commands into local control,
address, and data
//
//
//
//
csl_interface reply_bus {
  csl port data(input, 32),
           addr(input, mem map.get address word width()), // 9 bits
since log2(512) = 9
             (input );
};
csl interface cmd bus : reply bus {
  csl port cmd(input,2);
  ifc(){
    cmd.add enum(bus cmd);
};
```

```
csl unit controller {
  cmd_bus bus_out;
  reply bus bus in;
  controller(){
   bus out.reverse();
};
csl register group unit a rg {
  csl register r[[0-31]](32); // create 32 32-bit registers
 unit a rg() {
  }
};
csl_unit a{
  cmd bus bus in;
  reply bus bus out;
 unit_a_rg unit_a_rg0;
  int unit a mem map base addr;
  a() {
    unit a mem map base addr = 2048;
   bus out.reverse();
   mem_map.unit_a.add(unit_a_rg0, "unit_regs",
unit_a_mem_map_base_addr);
    unit_a_rg0.use_biu_to_write();
// unit a rg0 has the same interface as bus in so they can be connected
// each register has a set of pins that match the signal names and
directions
// in the bus.
// however the bus in and the bus out are not directly connected to the
registers
// instead intermediate logic is created to write the registers.
// The cslc detects that each register in the register group unit a rg0
are in the memory
```

6/12/08

```
// map. Since all registers in the memmory map they need to be con-
   nected to the the unit a
   // BIU (bus interface unit ) which listens to the bus as described
   above and generates the
   // write enable (wr en) signals for each individual register.
   // The interface bus out is no directly connected to the register out-
   puts. Instead the register
   // outputs are connected to a mux and the bus_in_addr selects the reg-
   ister to send back to the
   // controller which sent the read command to unit_a.
   //
   // If not all registers are in the memory map generate a compiler
   error.
       unit_a_rg0.connect(bus_in);
       bus in.connect(unit a rg0);
       csl signal a en =
       reg 0.d = data;
       mem_map.set_unit_address_signal(a,addr);
   };
   csl unit top{
     a a0;
     controller cntl0;
     top(){
       a0.set instance id(3);
     }
   };
OLD CSL CODE
   csl_memory_map mem_map;
   csl enum bus cmd {
     BUS_CMD_RD,
     BUS CMD WR,
```

71


```
BUS CMD PING,
 BUS_CMD_NOP
};
csl interface reply bus {
 csl_port data(input,32),
           addr(input,5),
           v(input) ;
};
csl_interface cmd_bus : reply_bus {
 csl port cmd(input,2);
 ifc(){
    cmd.add_enum(bus_cmd);
 }
};
csl_unit controller {
 cmd bus bus out;
 reply bus bus in;
 controller(){
   bus out.reverse();
 }
};
csl_unit a{
 cmd_bus bus_in;
 reply bus bus out;
  csl_register reg_0(32);
  a(){
  bus out.reverse();
  reg 0.
  csl_signal a_en =
  reg 0.d = data;
  }
};
mem_map.add_logic(object_wr_en, address)
mem_map.add_object(a.reg_0)
mem_map.set_unit_address_signal(a,addr);
```

```
csl unit top{
     a a0;
     top(){
       a0.set instance id();
   };
VERILOG CODE
   `define BUS_CMD_RD
   `define BUS CMD WR
   `define BUS_CMD_PING
   `define BUS CMD NOP 3
   `define UID 3 //unit id
   `define REG_0_ADDR 128 //reg_0 address
   module a(bus in data,
           bus_in_addr,
           bus_in_cmd ,
            clk,
           bus_out_data,
           bus_out_v
            );
    input [31:0] bus_in_data;
    input [9:0] bus in addr;
    input [1:0] bus_in_cmd;
    input clk;
    output bus_out_v;
    reg bus_out_v;
    output [31:0] bus out data;
    reg [31:0] bus_out_data;
    //local signals
    reg [31:0] reg_0;
    wire bus cmd rd = (`BUS CMD RD == bus in cmd) ;
    wire bus_cmd_wr = (`BUS_CMD_WR == bus_in_cmd) ;
    wire bus_cmd_ping = (`BUS_CMD_PING == bus_in_cmd);
    wire bus cmd nop = (`BUS CMD NOP == bus in cmd);
```

```
wire unit_a_en = bus_in_addr[9:8] == `UID;
 wire unit a wr en = unit a en && bus cmd wr;
 wire unit a rd en = unit a en && bus cmd rd;
 wire unit a ping en= unit a en && bus cmd ping;
 wire req 0 addr en = bus in addr[7:0] == `REG 0 ADDR;
wire reg 0 wr en = unit a wr en && reg 0 addr en;
 always @(posedge clk) begin
  if(reg 0 wr en) begin
    reg 0 <= bus in data;
  end
 end
always @(posedge clk) begin
   bus_out_v <= unit_a_rd_en & unit_a_ping_en;</pre>
end
always @(posedge clk) begin
    if(unit a rd en) begin
  case (bus in addr)
  `REG 0 ADDR: bus out data <= reg 0;
  endcase
  end
  else if(unit_a_ping_en) begin
     bus out data = `UID;
  end
end
endmodule
```

6/12/08 73

FIGURE 2.21 Bus Interface Unit Command Decoder



6/12/08

</ADDED_2007.05.12>

<ADDED ON 2007.05.16>

NOTE: UPDATE COMMAND SUMMARY ACCORDING TO THIS

Note: There should be 8 examples from :

TABLE 2.13

Type	User defined mem map	automatic mem map
hierarchical	X	X
virtual with page number and address	X	X
virtual with base address	x	X

User defined example:


```
csl unit processor {
};
csl_unit cluster {
 processor p[[0-7]];
};
csl_unit chip {
 cluster c[[0-7]];
};
csl memory map page mproc {
 mproc() {
    set unit(processor);
};
csl memory map page mcluster {
  mproc mp[[0-7]](p[[0-7]]); //user specified
 mcluster() {
    set unit(cluster);
};
csl_memory_map_page mchip {
 mcluster mc[0-7]](c[[0-7]]); //user specified
 mchip(){
    set_unit(chip);
};
csl_memory_map mmap {
 mchip mchip;
 mmap(){
  set_type(hierarchical);
```


Automatic example:

```
csl unit processor {
};
csl_unit cluster {
 processor p[[0-7]];
};
csl_unit chip {
 cluster c[[0-7]];
};
csl_memory_map_page mproc {
 mproc(){
   set unit(processor);
 }
};
csl_memory_map mmap {
  mmap(){
 set top unit(chip);
 set type(hierarchical);
 use_instance_decl_order();
//This generates the same code as the user defined version above
```

EXAMPLE:

P₁M





```
csl_register sr;
csl_register ir;

csl_memory im(16,128);
csl_memory dm(16,256);

csl_unit p{
  im im();
  dm dm();

  sr sr();
  ir ir();
  p(){
    sr.add_to_mem_map(5);
    ir.add_to_mem_map(5);
    dm.add_to_mem_map(128);
    // insert at address 5
```

80

6/12/08

```
im.add to mem map(512);  // insert at address 512
     }
   csl memory page mp{
     mp(){
       set_unit(p);
   csl_memory_map mm{
     mp mp;
     mm () {
       set_top_unit(chip);
       set_type(hierarchical);
       autogen_mem_map;
   }
   csl_unit cl{
     p p[[0-7]];
   csl_unit chip{
     cl cl[[0-7]];
     chip(){
Generated header file:
   #define sr
                            0x000
   #define ir
                            0 \times 0.05
   #define mp start addr 0x000
   #define mp_end_addr
                            0x3FF
   #define dm_start_addr
                            0x080
   #define dm end addr
                            0x0FF
   #define im_start_addr
                            0x200
   #define im_end_addr
                            0x2FF
```

When generating the memory map acces rights and visibility will be specified as parameters to generate only those defines that correspond to that specific options.

The adaptor needs to know how to connect the pins objects in the memory map to the network which will read/write the objects in the memory map.

Flat memory will need - data, address, command (W/R) and valid.

All units will listen to the address bus and they will need an address range checker (optional).

For hierarchical memory maps there will be a tree of enable signals to select the unit . ex: chip enable + cluster enable + processor enable

Virtual with unit ID and address

The upper bits of the address bus will be used to identify the unit (unit ID), the lower bits will be used to address local memory in the selected unit.

Virtual memory with base address?

0

1

2