# **DJBB Midi Loopster**





The DJBB Midi Loopster is a simple MIDI controller with a very simple looper feature. It does not care about tempo, can't save loops, and isn't precise - but all of this makes it quick and fun to use and experiment with.

The hardware and software are open source, but I also sell kits and full units @ djbajablast.com

More on the design / build / background process here

### **General Interface**

To move between setting pages, click the encoder. The icon on the bottom of the screen indicates that turning the encoder switches menus.



Function button held and notification icons.

# **Screens / Settings**

Make sure you are not in screen navigation mode, otherwise, encoder function will be overridden by screen navigation function.


## **Play Screen**



Play screen

#### Standard Mode

- To Play Notes, press the 16 pad buttons.
- · To Change Banks, Turn the encoder.
- · To Set pad velocity, hold pad(s) and turn the encoder.
- To enter Single Note Mode, hold [fn] and click a pad.
  - The pad's note will be mapped to all 16 pads with a gradient of velocities from 1-127.
  - To exit this mode, hold [fn] and click any pad.



Single note mode notification

#### **Encoder Play Mode**

All functions from standard mode still apply, except for the velocity set function.

- To Switch Between Standard and Encoder Play Modes, double click [fn].
- In **Encoder Play Mode**, you can still play the pads as usual, but now if you hold a pad and turn the encoder, it sends a note for each "click".
- Note that an off note will only be sent if you release the pad, or if you turn the encoder backwards, which immediately sends off notes for all pads.

#### Scale Screen

Turn the encoder to change between scales. In future versions of the software I want to flesh this out more. I hope to add a chord mode.

#### **Looper Screen**



Looper mode main screen

- To Begin Recording or Stop Recording, click [fn]
- To Start or Stop loop, double click [fn]
- To **Overdub** add more notes to the current loop click **[fn]** while the loop is playing. Click it again to disarm recording.
  - · Only 50 notes can be recorded at a time
- To **Delete The Loop**, hold **[fn]**.



Loop cleared notification after holding [fn]

# Contact / Links / Etc.

Getting started with the Pico:

https://learn.adafruit.com/getting-started-with-raspberry-pi-pico-circuitpython/overview

Github Repo for this project:

https://github.com/derrickthomin/DJBB-Midi-Loopster

### Support, questions, ideas?

Email me <u>djbb@djbajablast.com</u>

Instagram @dj\_baja\_blast Site <u>djbajablast.com</u>