```
PSECT code
movlw 0x3C; Load 15536 to the timer
movwf TMR0H
movlw 0xB0
movwf TMR0L
bcf INTCON, INTCON_TMR0IF_POSITION
movlw 0x83
movwf T0CON
movlw 0x00
                                ; PortD pin 0 is output
movwf TRISD
                               ; Send a digital 1
movlw 0x01
movwf PORTD
wait:
     btfss INTCON, INTCON_TMR0IF_POSITION
     bra wait
bcf INTCON, INTCON_TMR0IF_POSITION
xorwf PORTD
                                ; The last bit will change state
bra wait
END
```

#include <xc.inc> ; This will select the correct header automatically