
# Interfacing LCD16x2 with AVR ATmega16/ATmega32 in 4-bit mode

## Overview of LCD16x2



LCDs (Liquid Crystal Displays) are used for displaying status or parameters in embedded systems.

LCD 16x2 is a 16 pin device which has 8 data pins (D0-D7) and 3 control pins (RS, RW, EN). The remaining 5 pins are for supply and backlight for the LCD.

The control pins help us configure the LCD in command mode or data mode. They also help configure read mode or write mode and also when to read or write.


LCD 16x2 can be used in 4-bit mode or 8-bit mode depending on the requirement of the application. In order to use it, we need to send certain commands to the LCD in command mode and once the LCD is configured according to our need, we can send the required data in data mode.

For more information about LCD 16x2 and how to use it, refer to the topic LCD 16x2 display module (http://electronicwings.com/sensors-modules/lcd-16x2-display-module) in the sensors and modules section.

## LCD16x2 Pinout

**Platforms** 

(/explore)




LCD 16x2 Pin Diagram

## LCD16x2 4-bit Mode

- In 4-bit mode, data/command is sent in a 4-bit (nibble) format.
- To do this 1st send a Higher 4-bit and then send a lower 4-bit of data/command.
- Only 4 data (D4 D7) pins of 16x2 of LCD are connected to the microcontroller and other control pins RS (Register select), RW (Read/write), E (Enable) is connected to other GPIO Pins of the controller.

Therefore, due to such connections, we can save four GPIO pins which can be used for another application.

## Connection Diagram of LCD16x2 with ATmega16/32



Interfacing LCD 16x2 With AVR ATmega16/ATmega32

ElectronicWings.com

## Programming LCD16x2 4-bit mode with AVR ATmega16/Atmega32

#### Initialization

- 1. Wait for 15ms, Power-on initialization time for LCD16x2.
- 2. Send 0x02 command which initializes LCD 16x2 in 4-bit mode.
- 3. Send 0x28 command which configures LCD in 2-line, 4-bit mode, and 5x8 dots.
- 4. Send any Display ON command (0x0E, 0x0C)
- 5. Send 0x06 command (increment cursor)

```
void LCD_Init (void) /* LCD Initialize function */
         LCD_Dir = 0xFF;
                                    /* Make LCD port direction as o/p */
         _delay_ms(20);
                                    /* LCD Power ON delay always >15ms */
         LCD_Command(0x33);
         LCD_Command(0x32);
                                    /* Send for 4 bit initialization of LCD */
         LCD_Command(0x28);
                                    /* 2 line, 5*7 matrix in 4-bit mode */
         LCD_Command(0x0c);
                                    /* Display on cursor off */
         LCD_Command(0x06);
                                     /* Increment cursor (shift cursor to right) */
                                    /* Clear display screen */
         LCD_Command(0x01);
}
```

Now we successfully initialized LCD & it is ready to accept data in 4-bit mode to display.





To send command/data to 16x2 LCD we have to send higher nibble followed by lower EW Electronic Wings (As 16x2 LCD's D4 - D7 pins are connected as data pins, we have to shift the



**Platforms** (/explore)

Pro lever nibble to the right by 4 before transmitting.

(/projects) (/contests)

#### Command write function

- 1. First, send a Higher nibble of command.
- 2. Make RS pin low, RS=0 (command reg.)
- 3. Make RW pin low, RW=0 (write operation) or connect it to ground.
- 4. Give High to Low pulse at Enable (E).
- 5. Send lower nibble of command.
- 6. Give High to Low pulse at Enable (E).

```
void LCD_Command( unsigned char cmnd )
         LCD_Port = (LCD_Port & 0x0F) | (cmnd & 0xF0);/* Sending upper nil
                                           /* RS=0, command reg. */
         LCD_Port \&= \sim (1 << RS);
         LCD_Port |= (1<<EN);</pre>
                                            /* Enable pulse */
         _delay_us(1);
         LCD_Port \&= \sim (1 << EN);
         delay us(200);
         LCD_Port = (LCD_Port & 0x0F) | (cmnd << 4);/* Sending lower nibbl
         LCD Port |= (1<<EN);
         _delay_us(1);
         LCD_Port &= \sim (1<<EN);
         _delay_ms(2);
}
```

#### **Data write function**

- 1. First, send a Higher nibble of data.
- 2. Make RS pin high, RS=1 (data reg.)
- 3. Make RW pin low, RW=0 (write operation) or connect it to ground.
- 4. Give High to Low pulse at Enable (E).
- 5. Send lower nibble of data.
- 6. Give High to Low pulse at Enable (E).

```
void LCD_Char( unsigned char data )
{
        LCD Port = (LCD Port & 0x0F) | (data & 0xF0);/* Sending upper nil
        LCD_Port |= (1<<RS); /* RS=1, data reg. */
        LCD Port|= (1<<EN);</pre>
         _delay_us(1);
        LCD_Port \&= \sim (1 << EN);
         _delay_us(200);
        LCD_Port = (LCD_Port & 0x0F) | (data << 4); /* Sending lower nik</pre>
        LCD_Port |= (1<<EN);
        _delay_us(1);
        LCD_Port \&= \sim (1 << EN);
        _delay_ms(2);
}
```



Q

+ Project (/publish/project)





## ProjeCD16x2 4 doiteMode Code for ATmega16/32

```
(/contests)
(/projects)
      /*
        LCD16x2 4 bit ATmega16 interface
        http://www.electronicwings.com
      */
      #define F_CPU 800000UL
                                              /* Define CPU Frequency e.g. here 8MH
      #include <avr/io.h>
                                     /* Include AVR std. library file */
                                          /* Include Delay header file */
      #include <util/delay.h>
      #define LCD_Dir DDRB
                                          /* Define LCD data port direction */
      #define LCD_Port PORTB
                                          /* Define LCD data port */
      #define RS PB0
                                     /* Define Register Select pin */
      #define EN PB1
                                     /* Define Enable signal pin */
      void LCD_Command( unsigned char cmnd )
               LCD_Port = (LCD_Port & 0x0F) | (cmnd & 0xF0); /* sending uppe
               LCD_Port \&= \sim (1 << RS);
                                                    /* RS=0, command reg. */
               LCD_Port |= (1<<EN);</pre>
                                                    /* Enable pulse */
                _delay_us(1);
               LCD_Port \&= \sim (1 << EN);
```

#### MOUSER ELECTRONICS (https://www.

ntent=0x0)

mouser.in?
utm\_source=el
ectronicswing
Powered By s&utm\_mediu
m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co

## **Components Used**

LCD16x2 Display X 1

(https://www.mouser.c om/ProductDetail/Ada fruit/1447? qs=XAKIUOoRPe6ACI msjw7y7g%3D%3D&ut m\_source=electronics wings&utm\_medium=d isplay&utm\_campaign =mousercomponentslisting&ut m\_content=0x0)

LCD16x2 Display







(https://www.

mouser.in?



Platforms (/explore)

Projects (/projects)

Contests (/contests)

## **Components Used**

utm\_source=el
ectronicswing
Powered By s&utm\_mediu
m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co
ntent=0x0)

(https://www.mouser.i

ATmega 16 ATmega 16 n/ProductDetail/Micro chip-Technology-Atmel/ATMEGA16L-8PU? qs=%2Fha2pyFaduiGC JtTvs2wv8fVZbVAalLu 7lq%2FglTS0tALAx6f MenLvg%3D%3D&utm\_ source=electronicswin gs&utm\_medium=displ ay&utm\_campaign=m ousercomponentslisting&ut m\_content=0x0)

Datasheet (/componen ts/atmega-16/1/datash eet)

Atmega32 Atmega32

X 1

X 1

■ Datasheet (/componen ts/atmega3 2/1/datashe et)



+ Project (/publish/project)





**Projects** Contests Dow (/api/download/platf (/projects) ATmega16 LCD 16x2 4bit Mode project file nloa orm-attachment/63) Dow (/api/download/platf ATmega16 LCD 16x2 4bit Proteus Simulation nloa orm-attachment/64) d

## Comments



#### Comment



sridhar

:

(/users/sridhar/profile) 2018-10-07 08:24:55

hi...I hooked up a 16x2 LCD with Atmega16 (16MHZ) and made sure all the connections were according to the program . My contrast is adjusted perfectly but the problem is that there are black boxes on the top line while the lower one is empty.

can you help me. what could be a problem....?

Reply Like

lokeshc

:

:

:

(/users/lokeshc/profile) 2018-10-08 02:32:17

which means lcd not initialized properly. In the above program, you are using 16 mhz so there may be a chance that your delay will not be accurate. Reply Like

sridhar

:

(/users/sridhar/profile) 2018-10-07 08:50:02

if i have increased delay in LCD initialise step, it will work .....?

Reply Like

lokeshc

(/users/lokeshc/profile) 2018-10-08 02:32:51

yes. it will. Reply Like

sridhar

(/users/sridhar/profile) 2018-10-08 22:18:21

i didn't made any changes, the same code is working in Atmega16 (16MHZ)

board.

Reply Like

KavanDave :

(/users/KavanDave/profile) 2022-02-08 10:28:21



Can you tell me the solution? I am facing the same issue. lower one is empty and + Project (/publish/project) upper one is getting black boxes

**Platforms** (/explore)

**Projects** 

Reply Like Contests

(/projects)davidwongcy(/contests) (/users/davidwongcy/profile) 2022-05-08 09:17:06 :

It's most probably due to your Vcc not meeting the LCD controller's requirement. It must reach 4.5v in 10ms for 5v operation, or 2.7v in 10ms for 3v operation (see Hitachi HD44780U datasheet page 59). If this condition is not met, the internal reset circuit will not work, and you'll need to perform a manual init by sending 4 init nibbles at specific intervals (datasheet page 46): Power on -> wait at least 15ms -> send 0x3 -> wait at least 4.1ms -> send 0x3 -> wait at least 100us -> send 0x3 -> send 0x2 -> follow by the rest of the

```
initialization.
             Since Vcc rise time varies across hardware and is hard to guarantee, it is best to
             perform the manual init anyway.
             Reply Like
      davidwongcy
                                                                                             :
      (/users/davidwongcy/profile)
       2022-05-08 09:19:41
             The modified code is as follow:
             void LCD_nibble_cmd(unsigned char nibble)
             LCD_Port = (LCD_Port & 0x0F) | (nibble << 4); /* send nibble */
             LCD_Port &= \sim (1<<RS); /* RS=0, command reg. */
             LCD_Port|= (1<<EN);
             _delay_us(1);
             LCD_Port &= ~ (1<<EN);
             void LCD_Init (void) /* LCD Initialize function */
             LCD_Dir = 0xFF; /* Make LCD port direction as o/p */
             _delay_ms(20); /* LCD Power ON delay min 15ms */
             LCD_nibble_cmd(3); /* manual 4 bit initialization of LCD */
             _delay_ms(5); /* min 4.1ms */
             LCD_nibble_cmd(3);
             _delay_ms(1); /* min 100us */
             LCD_nibble_cmd(3);
             LCD_nibble_cmd(2);
             /* this is no longer needed
             LCD_Command(0x02); /* send for 4 bit initialization of LCD */
             LCD_Command(0x28); /* 2 line, 5*7 matrix in 4-bit mode */
             LCD_Command(0x0c); /* Display on cursor off*/
             LCD Command(0x06); /* Increment cursor (shift cursor to right)*/
             LCD_Command(0x01); /* Clear display screen*/
             _delay_ms(2);
             Reply Like
(/users/enthusiasticgeek/profile) 2019-05-06 07:15:11 • Edited
```


enthusiasticgeek

:

Hi

What is the license of your source code?

I have modified your source code to work on ATMEGA2560.





Platforms (/explore) Projects I have given you credit to your URL but I couldn't find license. All my source code is (/projects)eleased under Onterestable on this repo.

https://github.com/enthusiasticgeek/Elegoo\_Mega\_2560/blob/master/LCD16x2\_4bit. If you have license I will gladly add it. Thanks. Reply Like lokeshc : (/users/lokeshc/profile) 2019-05-06 13:47:20 it seems open source. So no need to add any license or you can add open source license to it. Reply Like enthusiasticgeek : (/users/enthusiasticgeek/profile) 2019-05-07 00:33:24 ok. Thanks. Reply Like alekseybazilevich : (/users/alekseybazilevich/profile) Hi. I connected 20x4 LCD instead of 16x4. And apply the source code from this article, but I can't figure out how to connect the third and fourth lines. What part I need to change or maybe add some where in this code to make it possible to work with the third and fourth line? Reply Like lokeshc : (/users/lokeshc/profile) 2019-09-25 12:30:26 It is simple refer below link which has 20x4 LCD library https://www.electronicwings.com/avr-atmega/gps-module-interfacing-withatmega1632 It will help you to clear your doubts Reply Like mostafamehdipour : (/users/mostafamehdipour/profile) 2022-09-22 18:20:07 how define D4 to D7 PIN from PORTB? Reply Like otgxotg : (/users/otgxotg/profile) This code is not working properly on my device LCD showing only 1 box dot. Please suggest me something Reply Like : otgxotg (/users/otgxotg/profile) I have taken RS as PB3 and EN PB2 And data pins from PC4 to PC7 and all the necessary changes have been done

still not getting correct output on LCD



Platforms (/explore) Projects (/projects)

Q About Us (/about)
Business Offering (/business-Contests services)
Host Platform (/launch-platform)
Contact Us (/contactus)

Connect On: + Project (/publish/project)

Facebook(https://www.facebook.com/electronicwings)

LinkedIn(https://www.linkedin.com/company/electronicwin

Youtube(https://www.youtube.com/channel/UCNdqkukBtk4

(https://www.instagram.com/electronicwings\_collnstagram

igshid=1cip10jijttko)

Terms of Service (/terms-ofservice)

Cookies Policy (/cookie-policy)

Privacy Policy (/privacy-policy)

ElectronicWings © 2023