

# MPU6050 (Gyroscope + Accelerometer + Temperature) interface with AVR ATmega16.

#### **Overview of Gyroscope**



MPU6050 Module

The MPU6050 sensor module is an integrated 6-axis Motion tracking device.

- It has a 3-axis Gyroscope, 3-axis Accelerometer, Digital Motion Processor, and a Temperature sensor, all in a single IC.
- It can accept inputs from other sensors like a 3-axis magnetometer, and pressure sensor using its Auxiliary I2C bus.
- If an external 3-axis magnetometer is connected, it can provide complete 9-axis Motion Fusion output.
- A microcontroller can communicate with this module using the I2C communication protocol.
- Gyroscope and accelerometer reading along X, Y, and Z axes are available in 2's complement form. The temperature reading is available in a signed integer form.
- Gyroscope readings are in degrees per second (DPS) unit; Accelerometer readings are in g unit, and Temperature reading is in degrees Celsius.


For more information about the MPU6050 Sensor Module and how to use it, refer to the topic MPU6050 Sensor Module (http://electronicwings.com/sensors-modules/mpu6050-gyroscope-accelerometer-temperature-sensor-module) in the sensors and modules section.

# Connection Diagram of MPU6050 with ATmega16/32

The interfacing of the MPU-6050 module with ATmega16 is shown in the below figure.

**Platforms** 

(/explore)



#### MPU6050 Example Using ATmega16/32

Let's program MPU6050 (Gyro meter + Accelerometer + Temperature) sensor module with AVR-based ATmega16 to read all sensor values and send all values on computer terminals over USART.

- MPU-6050 has an I2C communication interface to connect it with the I2C of ATmega16 (https://www.electronicwings.com/avr-atmega/atmega1632-i2c).
- The module requires a +5V DC power supply, so connect it to the VCC pin of the
- Connect the ground to the GND pin of the module.
- Here we have used FTDI serial to USB converter to send values serially to a computer terminal.

#### MPU6050 Gyroscope Code for ATmega16/32



+ Project (/publish/project)



```
Platforms
(/explore)
```

```
Projects Contests http://www.electronicwings.com
(/projects)
                      (/contests)
       */
       #define F_CPU 8000000UL
                                           /* Define CPU clock Frequency 8MHz */
       #include <avr/io.h>
                                      /* Include AVR std. library file */
       #include <util/delay.h>
                                      /* Include delay header file */
       #include <inttypes.h>
                                  /* Include integer type header file */
       #include <stdlib.h>
                                      /* Include standard library file */
       #include <stdio.h>
                                      /* Include standard I/O library file */
       #include "MPU6050_res_define.h" /* Include MPU6050 register define file */
       #include "I2C_Master_H_file.h" /* Include I2C Master header file */
       #include "USART_RS232_H_file.h" /* Include USART header file */
      float Acc_x,Acc_y,Acc_z,Temperature,Gyro_x,Gyro_y,Gyro_z;
                                 /* Gyro initialization function */
      void Gyro_Init()
       {
                                                      /* Power up time >100ms */
                 delav ms/1501.
```

#### MPU6050 Output Window of Terminal

The output window will show all values mentioned below

Ax = Accelerometer x-axis data in g unit

Ay = Accelerometer y-axis data in g unit


Az = Accelerometer z-axis data in g unit

T = temperature in degree/Celcius

Gx = Gyro x axis data in degree/seconds unit

Gy = Gyro y axis data in degree/seconds unit

Gz = Gyro z axis data in degree/seconds unit





(https://www.mouser.in?
utm\_source=el
ectronicswing
s&utm\_mediu
m=display&ut
m\_campaign=
mouser-

#### **Components Used**

m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co
ntent=0x0)

(https://www.mouser.i

ATmega 16 ATmega 16

X 1

m/ProductDetail/Micro chip-Technology-Atmel/ATMEGA16L-8PU? qs=%2Fha2pyFaduiGC JtTvs2wv8fVZbVAalLu 7lq%2FglTS0tALAx6f MenLvg%3D%3D&utm\_source=electronicswin gs&utm\_medium=displ ay&utm\_campaign=m ouser-componentslisting&ut m\_content=0x0)

■ Datasheet (/componen ts/atmega-16/1/datash eet)







mouser.in?

ntent=0x0)

(https://www.



Platforms (/explore)

Projects (/projects)

Contests (/contests)

## **Components Used**

utm\_source=el
ectronicswing
S&utm\_mediu
m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co

Atmega32 Atmega32

X 1

■ Datasheet (/componen ts/atmega3 2/1/datashe et)

#### MPU6050 Gyroscope and Accelerometer

MPU6050 (Gyroscope + Accelerometer + Temperatur... X 1

Datasheet (/componen ts/mpu6050 -gyroscope-and-acceleromet er/1/datash eet)

X 1







(https://www.

mouser.in?



Platforms (/explore) Projects (/projects)

Contests (/contests)

## **Components Used**

utm\_source=el
ectronicswing
s&utm\_mediu
m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co
ntent=0x0)

CP2103 USB TO UART BRIDGE

CP2103 is single chip USB to UART Bridge. It su...

(https://www.mouser.c om/ProductDetail/Silic on-Labs/CP2103-GMR? qs=Zq62GxwlckYrXEg TuxpNRg%3D%3D&ut m\_source=electronics wings&utm\_medium=d isplay&utm\_campaign =mousercomponentslisting&ut m\_content=0x0)

Datasheet (/componen ts/cp2103-usb-to-uart-bridge/1/dat asheet)

#### **Downloads**

MPU-6050_DataSheet.pdf	Dow (/api/download/platf nloa orm-attachment/189) d
RM-MPU-60xxA.pdf	Dow (/api/download/platf nloa orm-attachment/190) d
ATmega MPU6050 Interface	Dow (/api/download/platf nloa orm-attachment/355) d

#### **Comments**



Q

+ Project (/publish/project)



**Platforms** (/explore)

**Projects** (/projects)

Contests (/contests)

Comment



Rascal

(/users/Rascal/profile) 2017-12-29 12:45:34

Hi and thanks for you code. I ran it on an atmega 16 but found that now and again the i2c bus hangs the code when reading the raw values. My xtal is 11059200 and I changed the F\_cpu valu accordingly. Any suggestions? Thanks Reply Like

Rascal

:

:

(/users/Rascal/profile) 2017-12-29 12:45:36

Hi and thanks for you code. I ran it on an atmega 16 but found that now and again the i2c bus hangs the code when reading the raw values. My xtal is 11059200 and I changed the F\_cpu valu accordingly. Any suggestions? Thanks

Reply Like

lokeshc

:

(/users/lokeshc/profile) 2017-12-30 00:51:00

@Rascal: Hello friend,

make sure that your MPU6050 is connected to atmega16 properly. since the i2c functions used in above example using while(1) methods for sending and receiving the data. so the situation may come while your connection gets loose and i2c functions will get stuck to while(1) behaviour due to no response from slave device(MPU6050 here).

Also you need to change the f\_cpu in every library used for above example i.e. you need to change the f\_cpu in i2c library and uart library as well.

you are using external crystal so i hope you already sets controller to use external crystal.

try above things and let me know if still it getting stucks Reply Like

Rascal

:

(/users/Rascal/profile) 2017-12-30 01:42:07

@lokeshc: thanks I believe that part was all done ok. It works perfectly for a couple of minutes at times and prints fine but then hangs. I did use a sparkfun level converter but will try without that when I am back and will let you know. Russell

Reply Like

Rascal

:

(/users/Rascal/profile) 2018-01-01 17:21:36

@Rascal: Hi. Ok I removed the level converter and just did a direct connection. Now it seems fine and runs reliably. Thanks for the great site and info. Regards and best for the new year. Russell

Reply Like

mina

:

(/users/mina/profile) 2018-03-03 21:26:58

+ Project (/publish/project)

:

:



**Platforms** (/explore)

Projects lokesho Contests

(/projects)/users/lokesh/propflests)

Yes sure. Just you have to change the selected microcontroller in the project from ATmega16 to ATmega32

Reply Like

raosige

(/users/raosige/profile) 2018-10-25 04:16:45

Hi,

Thank you very much for your source code and hardware information.

It is really great work.

i have connected mpu6050 to ATMEGA32A micorcontroller and i succeeded to get raw data from 3 axis accelerometer/Gyroscopes from MPU6050.

i want to find ROII, Pitch and YAW angles. how can i find or calculate from these raw data from mpu6050?

any help will be appreciated

Reply Like

: anjanaouseph

(/users/anjanaouseph/profile) 2019-03-09 18:58:04

why do we need to use USART communication in this?whats buffer here?

Reply Like

lokeshc :

(/users/lokeshc/profile) 2019-03-11 12:00:00

to see the output of MPU6050

Reply Like

anjanaouseph :

(/users/anjanaouseph/profile) 2019-03-11 12:12:19

How do you set up tera term?

Reply Like

lokeshc :

(/users/lokeshc/profile) 2019-03-12 18:45:03

Just start with new connection and set used baud rate.

anjanaouseph :

(/users/anjanaouseph/profile) 2019-03-16 09:01:04

When i opened a new connection iam not able to select the serial communication radio button, its greyed out! Do you know what to do here?

Reply Like

lokeshc :

(/users/lokeshc/profile) 2019-03-16 10:13:08

Have you installed driver for serial to USB module? It should be installed then it will show serial port in serial communication radio button.

Aslo closed all previous connections in tera term.

Reply Like

anjanaouseph :

(/users/anjanaouseph/profile) 2019-03-16 10:36:41



Tera term works fine now, i selected atmega328p as the board in the

project, now its showing errors such as UCSRB undeclared and Stoins Way his h/project)



:

**Platforms** (/explore)

to be done? Reply Contests **Projects** (/contests) (/projects)

dannyfabricio3006

(/users/dannyfabricio3006/profile) 2019-04-29 09:46:47

Hello, I have problems with the code you have provided, I am using an Atmega32A and change the frequencies in all the libraries, but

in TeraTerm it gives me negative zeros in the 6 axes, also in the Proteus simulator.

Excuse my English grief, greetings from Ecuador.

Reply Like

**JohnSanchez** :

(/users/JohnSanchez/profile) 2020-09-06 02:21:10 • Edited

Hello, thanks for the code so much . I just want to ask how can I get the data for my PC exactly as a HID gyroscope, not as a console text?

Reply Like

Pacimani :

(/users/Pacimani/profile) 2020-09-10 20:37:43

Does anyone know where I can find the licence for the codes so that I can them for my school project? My school requires me to provide a licence before I include the device's code into my project.

Reply Like

zeverist0101 :

(/users/zeverist0101/profile) 2021-06-04 12:48:58

How would you do if you want to use this code with atmega328p chip instead?

Reply Like

NoorAmalinaOthmanA18MB0090 :

(/users/NoorAmalinaOthmanA18MB0090/profile)

Hi sir. May i know how i can change the coding for Atmega328 because i faced error with the MPU6050 res.h and recipe for target main.o failed when i try to copy the coding to another file

Reply Like

MohammadBidokh :

(/users/MohammadBidokh/profile) 2022-05-04 15:20:43

Hi how can i use this code in codevision?

please guide me

Reply Like

TalalAedo :

(/users/TalalAedo/profile) 2022-12-25 03:38:02

Hello, I need the mikroc code to run the mpu5060

Reply Like 116

About Us (/about) Connect On:

**Business Offering (/business-**Facebook(https://www.facebook.com/electronicwings)

services)

LinkedIn(https://www.linkedin.com/company/electronicwin Host Platform (/launch-

platform)

Contact Us (/contactus) Youtube(https://www.youtube.com/channel/UCNdqkukBtk4



Platforms (/explore) Projects (/projects)

Instagram(https://www.instagram.com/electronicwings\_com? igshid=1cip10jijttko) + Project (/publish/project)

Terms GPBাকেরিভ (/terms-of-(/constensits)

Cookies Policy (/cookie-policy) Privacy Policy (/privacy-policy) ElectronicWings © 2023

