# **Analog DECT Phone** AGR-8206-SMK



# Quick Installation Guide V 1.01

## 1 Over View

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

## **Package Contents**

When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

- 1. Base Unit
- 2. Cordless Handset
- 3. Stand
- 4. Battery
- 5. AC Adaptor
- 6. 10-feet, 4 wire Line Cord (with RJ-11 connector)
- 7. Quick Installation Guide (This document)

# 2 Product Description

The following contains important information to help you familiarize with the functions of the phone.

#### **Front View**



## 1. Handset keys


Name	Description
Message waiting indicator	A red light indicator means that you have an incoming call or message.
Display screen	To display calls and status information.
Speed dial keys	Press any of the keys to speed dial the preset contact number.

Name	Description
LINE 1 / LINE 2	There are two LINEs bottom in this handset.
End key	Press to end a phone call
Alphanumerical keys	Press these keys to enter phone numbers or texts.
Function keys	
Hold	Press to put an active call on hold.
Speaker	Press to activate the speakerphone for hands free conversations.
Volume	Press to increase or decrease the volume of the ringer tone, handset, or the volume of the current call using the speakerphone.

## 2 Base unit keys

Name	Description
Message waiting indicator	A red light indicator means that you have an incoming call or message.
Speed dial keys	Press any of the keys to speed dial the preset contact number.
LINE 1 / LINE 2	To indicate a line been used as the following status: - Idle: No LED indication In call: Red LED In on-hold call: Blinking red LED.
End key	Press to end a phone call
Alphanumerical keys	Press these keys to enter phone numbers or texts.
Function keys	
Hold	Press to put an active call on hold.
Speaker	Press to activate the speakerphone for hands free conversations.
Volume	Press to increase or decrease the volume of the ringer tone, handset, or the volume of the current call using the speakerphone.


## **Back View**




Name	Description
PSTN line port	Connects to PSTN line.
DC 6V Power jack	Connects to AC power adapter.


## **Connecting the Phone**

The following illustration shows how to connect the power and PSTN ports of DECT phone.




The following illustration shows how to install the phone and stand.





The following illustration shows how to install the handset and battery.



# 3 Operations

## **Answering a Call**

An incoming call is indicated by a ringing tone and a flashing indicator at the top of both handset and base units. You can answer the call by doing one of the followings:

- Pick up the **handset** to answer the call.
- Press the Line (Line1/Line2)/Speaker key on the base or handset to answer the call.

## Making a Call

#### Dialing with the Keypad

• Enter the telephone number with the alphanumerical keypad and the call will start automatically.

### Using the Speed dial keys

You can use the 6 pre-assigned speed dial hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using speed dialing, follow the steps below:

• Press the speed dial hotkey that has been pre-assigned to the phone number and the call will start automatically.

## **Call Options**

While a call is in progress, a number of additional options are available.

### Using the Speaker Phone

For hands free operation, you can use the built-in speaker to talk on the phone. To use the speakerphone, follow the steps below:

- While talking on the phone, press the **Speaker** key on the phone to enable the Speakerphone function.
- Press Speaker key again to terminate the call.

## Putting a Call on Hold

You may want to put a call on hold temporarily while doing some work or attending to a second incoming or outgoing call. To put a call on hold, do one of the following:

- Press the **Hold** key on the phone to put the call on hold.
- When you receive a second call, press the next available LINE key to attend to the new call, and the first call will be put on hold automatically.

#### **Checking Voice Messages**

If the **message waiting indicator** at top of handset or base unit lights up in red, it indicates that there are one or more new messages in voicemail box.

• Press the VOICE MAIL key on the phone to retrieve voice messages.

(An external ITSP or PBX must support voice message feature. And you need to set a voice message code before using the voice mail feature.)

#### Pairing handset and base unit

If you want to get the complete phone function, please be pairing handset and base before using.

- Put handset on the base, the base will start pairing automatically.
- After finished pairing, the base will play the beeps tone.

### **Charging the Handset Battery**

You would need to charge the handset battery before using the handset.

- Install the battery into the handset.
- Place the handset onto the base unit and base unit will start to charge the handset automatically.
- The charging indicator lights up in red during charging progress. The LED goes off after the handset battery is fully charged.