

Honda Civic 2023 - Owner & Service Manual Excerpt

1. Vehicle Identification

Brand: Honda

Model: Civic

Year: 2023

Engine: 2.0L i-VTEC 4-Cylinder / 1.5L VTEC Turbo (available)

Transmission: CVT

2. Honda Sensing - Collision Mitigation Braking System (CMBS)

When does CMBS activate?

CMBS uses a front camera and radar to monitor traffic ahead and will:

- Display a visual warning and sound an audible alert when a frontal collision risk is detected.
- Apply light automatic braking if the driver does not respond, followed by strong braking if a collision becomes unavoidable.

CMBS may be temporarily unavailable if the camera near the rearview mirror or the front radar emblem is obstructed by mud, ice, or stickers.

3. Anti-Theft System and Alarm Triggers

The Civic's anti-theft alarm is triggered when:

- A door, hood, or trunk is opened without first unlocking the vehicle with the remote transmitter or key.
- An attempt is made to start the engine without a recognized immobilizer-coded key.
- The battery is disconnected and reconnected while the system is armed (may require re-arming after unlock).

To silence the alarm, press the unlock button on the remote or insert and turn a valid key in the driver's door cylinder.

4. Climate Control - Automatic Recirculation Behavior

Air recirculation is automatically turned off in the following situations:

- When MAX defrost mode is selected to clear windshield fog or ice.
- When outside temperature is very low and the system prioritizes fresh air to reduce fogging.
- When switched to Fresh mode manually by the driver via the recirculation button.

5. Engine Oil and Maintenance Minder

When the Maintenance Minder indicates an oil change is due:

1. Use only oil meeting Honda's specification (typically 0W-20 full synthetic) as listed on the oil fill cap.
2. Check the oil level with the engine off and the vehicle on level ground, waiting a few minutes after shutdown.
3. Reset the Maintenance Minder system only after the service has actually been performed.
4. Persistent illumination of the oil pressure warning light (distinct from Maintenance Minder) means stop driving immediately.

6. Seat Heater Safety Precautions

Seat heaters should not be switched on when:

- The seat surface is wet, damp, or recently cleaned with liquid upholstery cleaner.
- A child safety seat, cushion, or blanket covers the heated area, which can trap excess heat.
- The occupant has diabetes, poor circulation, or reduced skin sensitivity, without first consulting a physician.