Hari Om TubeOS: all common questions and answers (collected from every chapter)

Accurate as of 31 October 2026.

From chapter 00: Welcome to Hari Om TubeOS: the big picture

Q: Why does my sidebar look different from my colleague's? A: Each role sees only its pages. See the role table in Getting started.

Q: The plan says "not planned yet" but the operator already logged a run. Is that wrong? A: No. Planning never blocks. The run is kept and flagged as before planning.

Q: A reading was outside the band at Oven. Is the card stopped? A: No. In-process readings are flagged, not held. The card carries on; managers see the flag.

Q: A reel failed incoming QC. Can the store issue it? A: No. A held lot cannot be issued until QC re-checks it or the plant head concedes it.

Q: Why is a GRN in January called P/26/...? A: GRN numbers follow the financial year (April to March). January to March 2027 belongs to 2026-27.

Q: Where do I see everything waiting for me? A: The **Inbox** (sidebar Overview) and the bell in the header.

From chapter 01: Getting started

Q: I cannot find a page my colleague uses. A: It belongs to a role your login does not have. Ask the Owner or Admin to add the role in System › Users.

Q: The plant switcher is missing. A: Only the Owner and Admin can switch plants. Your plant comes from your login.

Q: The page says "pick one plant" but I only have one plant. A: You are probably in **All Visible Plants** (Owner/Admin). Choose Plant A or Plant B in the switcher.

Q: Text looks wrong in dark mode. A: Click the sun/moon button to go back to light, or set Appearance › **Light**. Tell the Admin which page looked wrong.

Q: My phone keeps signing me out. A: That is the 15-minute safety rule. Signing in again returns you to the same page.

Q: What does the amber "Close Sep" chip mean? A: September has ended but has not been closed. The Owner closes it in Month-end close after the count is approved.

Q: I switched role but the sidebar did not change. A: The sidebar always shows the pages of all your roles. The role switcher changes your start page and work queues.

From chapter 02: Dashboard and inbox

Q: A tile says "Not reported". Is the figure zero? A: No. That source did not answer. Press refresh in a minute; the list page shows live status meanwhile.

Q: Why do I not see Company KPIs? A: Only the Owner has the KPI and Action center tabs. Other roles see figures for their own work.

Q: Why does clicking Dashboard take me to the QC desk? A: The Quality Control role's dashboard is the QC desk.

Q: I marked a notification read by mistake. A: Click its read/unread button to **Mark as unread**.

Q: The Inbox says 2,000 unread. Do I have to open each? A: No. Work the **Needs action** view, then press **Mark all read**.

Q: A notification has no button. A: It is for information, or your role cannot do that action. Open it to read.

Q: Purchase lanes say "Select a plant to see this queue". A: You are in All Visible Plants. Choose Plant A or Plant B in the header.

From chapter 03: Using TubeOS on a phone

Q: The Camera app shows the QR but nothing opens. A: Tap the link banner that appears. If there is no link, it is an old label: type its number on the Scan page or ask the store to reprint it.

Q: "We could not read this label". A: The number is not in your plant or the connection dropped. Check the network and scan again, or type the number.

Q: Log output is grey. A: Read the small text under the button: the stage or card is closed, or your role cannot log runs.

Q: My phone signed me out in the middle of a run. A: Sign in again; the card reopens and your typed draft is offered back.

Q: I scanned a reel and got a lot card, not the issue page. A: Either your role does not issue stock, or the reel is not cleared (the card says "Waiting for incoming QC" or "Failed incoming QC").

Q: Do I need to choose a shift when issuing? A: No. Shift and date come from the clock when you press Issue.

Q: Can I use a handheld scanner? A: Yes. In-app scan boxes read new links and older labels alike.

From chapter 04: Sales orders

Q: Why can't I approve my own order? A: Maker-checker. Press **Send for approval**; another user approves. Only the Owner and Admin may approve their own.

Q: Release lines is grey. A: Hover over it: "Approve the order first", "Lift the customer hold to release", "The order is closed" or "All lines are already released to job cards".

Q: The release dialog says "Pick the parchment colour..." on a plain line. A: Every job card needs a colour to wind; pick one now.

Q: I want to cancel but only Short close is offered. A: Something is already released or dispatched. Short close drops the rest; released cards finish.

Q: The reason I need is not in the list. A: Ask the Owner or Admin to add it in **Order close reasons**.

Q: Where did the Order tracker, Pending orders and Order audit pages go? A: They are the Orders list (tiles and tabs) and the Order page's History tab. Old links still work.

Q: The order shows "No date". Is that a problem? A: No. Delivery date is optional; add it on the Deliveries tab when the customer confirms.

Q: I entered the wrong PO number after release. A: Use **Change PO (once)**. After that it is locked; ask the Owner for a decision.

From chapter 05: Specifications

Q: My spec does not appear on the sales order. A: It is not approved yet, or it is obsolete. Approve it; drafts are listed under "Not approved yet — approve in Specifications first".

Q: Approve & Go Live is grey. A: Hover over it for the reason: not Owner/Admin, no plant selected, not submitted, or blockers left.

Q: The list shows "Needs attention" for Monsoon. A: Open **Readiness** to see what is missing (for example the Monsoon recipe is not confirmed).

Q: If I change the recipe, do running job cards change? A: No. Each card keeps the recipe and tolerances it was released with.

Q: Why does release say the spec is not ready? A: The active season's recipe or QC setup has blockers. Fix them on the spec, or ask the Owner about the season.

Q: Can Planners or Sales edit a spec? A: No. Only the Owner and Admin. Others use approved specs.

Q: What is the 12.5%? A: The plant default allowance for adhesive and parchment together on top of the paper; parchment takes 1.5% and adhesive the rest. Change it with **Edit defaults** (plant level) or

on the spec.

From chapter 06: A day in the life

Q: I am new. Which page do I open first? A: Your start page (it opens after sign-in), then the Inbox.

Q: Two people do my job. Do we share work? A: Yes. Queues and lists are per plant and role, not per person.

Q: I cover two roles. A: Ask the Admin to add both roles to your login and use the role switcher.

Q: Who do I ask when a button is grey? A: Read its reason first. If it is a role or plant reason, ask the Owner or Admin.

Q: Can I fix a mistake myself? A: Usually yes, with a reason: edit the run, change the colour on the order, raise a stock correction. Approved and closed records need the Owner.

From chapter 10: Job cards

Q: Why is Log output greyed out? A: Hover over it. Common reasons: "Card is closed", "Old entry form — use the Old form tab", "No open stage takes runs", or "Your role cannot log runs".

Q: The card is not planned. Can the operator still log a run? A: Yes. The run saves and is flagged "run before planning". Planning is only the plan; the job card log is the truth.

Q: What does "Flagged · 3 runs" mean in the QC column? A: Three runs have at least one reading outside its band. They were accepted and not held. Click the flag to open the card's QC tab.

Q: What is the difference between a flag and a hold? A: A flag is information; nothing stops. A hold is raised by QC on the Quality pages; it stops the next stage and dispatch until the plant head, Owner or Admin releases it.

Q: Why can't I close the stage? A: The close dialog says why. Usually QC readings are short ("I.D. 1/2") or runs are still with the supervisor. Only Plant Manager, Owner or Admin can confirm a close.

Q: What does "Missed slot ×2" mean? A: The card was planned twice and nothing was logged within 36 hours after each shift, so it went back to the planner queue. Plan it again, or log the run if it did happen.

Q: What is a "count gap"? A: On Process, the pieces counted (made + cutting loss + held) do not match bamboo × pcs per bamboo. The run is saved and flagged for the owner; nothing has to be written for it.

Q: How do I split, edit or cancel a card? A: Click **Manage card**. That opens the Job card manager (see the next chapter).

Q: Where are the old "Supervisor entry" and "EOD entry" pages? A: They now open Log output. See "Log output and QC entry".

From chapter 11: Job card manager

Q: Why is Edit greyed out? A: The card is already on the board or running. Take it back to the queue on the planner, or split the unstarted part into a new card.

Q: When do I use Split into a new card and when Split plan? A: Split into a new card when part of the order needs its own card (own print, QC, dispatch). Split plan when the same card should run over more shifts, days or machines.

Q: Force close is locked on my card. Why? A: It is a batch-entry card with runs logged. Open the card page and use **Close stage**; a short close needs a reason and sends the balance back to the order.

Q: Can I undo a cancel? A: No. Release the quantity again from the sales order to make a new card.

Q: Who gets told about an emergency insert? A: Everyone affected is notified, and each card that had to move gets the move in its history.

Q: Does closing a stage still need a supervisor's name? A: No. Plant Manager, Owner or Admin closes it, and that login is recorded.

Q: The new split card is not on the board. Is that normal? A: Yes. A split card starts in the planner queue, unplaced. Use **Place it on the planner board**.

From chapter 12: Planner

Q: Why can't I drag this card onto the Oven board? A: Its Winding has no slot yet. Plan Winding first; the card shows in **Waiting for the previous plan** with a lock.

Q: The floor logged a run but the card was not planned. Is that wrong? A: No. It is allowed and flagged "Run before planning". The overview shows the slot as **Logged before planning**.

Q: What does "Missed slot ×2" mean? A: The card was planned twice and nothing was logged within 36 hours after each shift ended. Re-plan it, or have the floor log the run if it happened.

Q: What is the difference between Split plan and Split into a new card? A: Split plan keeps one card and cuts its plan into two time slots. Split into a new card (Job card manager) creates a separate card with its own number.

Q: The capacity bar says 120%. Will it stop me? A: No. You are asked first; **Schedule and split** keeps what fits and moves the rest to the next shift.

Q: Why do the queue panel bars not match machine use? A: They compare queued load only, including missed slots. They do not measure machine utilization.

Q: Where did the Order tracker go? A: Old /planning/tracker links open the Orders list with the matching filter. Missed slots are on the Planning overview.

From chapter 13: Log output and QC entry

Q: The scan opened "That QR is on a material or tool label". What now? A: You scanned a reel, lot or tool label. Scan the QR on the printed job card.

Q: It is 2 a.m. Why does the form say yesterday's date? A: The run belongs to Shift B, which started yesterday at 20:00. That is correct.

Q: Do I have to fill start and end time? A: No. They are optional and never stop a save.

Q: My reading is outside the band. Will the card stop? A: No. It is saved and flagged. Only a hold raised by QC on the Quality pages stops a card.

Q: Why can't the next stage take my batch? A: Its QC is not done yet. Add at least 2 readings for every required check on that run, or ask the supervisor to override with a reason.

Q: I saved a run but it does not count. A: It is with the supervisor. A plant manager, Owner or Admin must submit it.

Q: I typed the wrong quantity on a submitted run. A: Ask the supervisor to void it with a reason, then log it again. If the next stage already used that output, it cannot be voided.

Q: Where is the old Supervisor entry page? A: It now opens Floor entry. Use Log output.

From chapter 14: Quality

Q: Why can't Store issue this reel? A: Its lot is held: a reading was out of band. QC must re-check, the plant head concede, or Store return it.

Q: A floor reading is out of band. Must I hold the card? A: No. It is flagged, not held. Raise a hold only if you decide the material must stop.

Q: Who can release a job-card hold? A: Only the plant head (Plant Manager), Owner or Admin.

Q: Where do I change the GSM band for one paper? A: In Masters (the band button on the paper row, or Masters › Inward QC tolerances). QC only lists the checks.

Q: I edited a stage rule. Why do old cards still use the old band? A: Cards freeze their rules at release. Only cards released after your save use the new version.

Q: What does "Recorded only — no limit" mean? A: The reading is kept but never judged in or out of band.

Q: A complaint's dispatch number is not found. A: The complaint is still logged, marked unverified. Check the DC number with Dispatch.

Q: Where are quality trends? A: **Analytics** (Reports › Quality analytics): pass rates by stage and material, flagged readings, holds and complaints.

From chapter 15: Month-end close

Q: Why does every item show "Waiting for count"? A: The month-end count is not approved yet. Used per count is known only after the Owner approves the count.

Q: The close button is grey. Why? A: Hover over it: a checklist step is open, or you are not the Owner. The first open step is marked.

Q: The operator cannot save a run for last month. A: That month is closed. Ask the Owner to re-open it, enter the run, then close it again.

Q: Why is spec 0 for an item we used? A: Spec is posted when Process closes on a card. If no card using it closed Process in the month, spec is 0. Also check "Spec items not linked to a stock item".

Q: Are usage limits the same as QC tolerances? A: No. Usage limits are for month-end only. QC bands are in Quality and Masters.

Q: I changed a limit. Did August change? A: Only if August is still open. Closed months keep their own limits.

Q: What does "Legacy" mean in time reconciliation? A: The stage record has no card-time source of its own. It is information only.

From chapter 16: Dispatch

Q: Why is there no Make challan button on my card? A: Read the state: "Waiting for Process to close", "Waiting for the stock posting" or "On QC hold". The button appears only when pieces can ship and your role can prepare challans.

Q: The seal says the plant GSTIN is missing. A: Ask an Owner or Admin to fill it in **Plants** (System). Then press **Reload** on the challan.

Q: Can Sales seal a challan? A: No. Sales can view and print sealed challans. Dispatch, Owner or Admin seal.

Q: The card has QC flags. Can I still ship? A: Yes. Flags do not block. Only an active QC hold blocks sealing.

Q: I sealed the wrong quantity. A: A sealed challan cannot be changed. Speak to the Owner or Admin about a correction; do not make a second challan for the same pieces.

Q: Why can only 893 ship when the order released 900? A: Only accepted finished goods can ship. Process made 893 good pieces, so 893 is the most that can ship.

Q: The net weight is empty. A: The spec has no tube weight. Type the net weight in kg.

From chapter 20: Purchase orders, PO approvals and requisitions

Q: Why can't I see the New purchase order button? A: Only Store, Plant Manager, Owner and Admin make POs. A Planner proposes arrivals on the RM inward calendar; when the Owner approves them, the draft PO is made automatically.

Q: Where do I type the PO number? A: You don't. The system gives the next RP-PM or OT number when you save the draft, and it never changes, even after revisions.

Q: Where is the "Incoming QC required" tick? A: It was removed. Every PO line now needs incoming QC, and QC checks each delivery against the material standard.

Q: A scheduled draft says "Rate needed". What do I do? A: Click **Fill the rate**, enter the vendor's rate and save. If the Owner did not make this change himself, the PO then goes to him for approval before it can be sent.

Q: The Owner rejected my PO. Can I fix it? A: Yes. Open it from **Sent back by Owner**, read the reason in the history, click **Edit / vendor change**, fix it and submit again. Or cancel it.

Q: Can an Admin approve a PO they made? A: Yes. The Owner and an Admin may approve their own PO; the history records "approved by the same person". RM arrivals and requisitions are approved by the Owner only.

Q: Can I receive goods on a PO that is still waiting approval? A: No. Goods inward lists only approved POs with an open balance. Ask the Owner or an Admin to approve it.

Q: The vendor will not send the last 120 kg. How do I close the PO? A: The Plant Manager or Owner types a close reason and clicks **Short-close remaining quantities**.

Q: I changed a sent PO. Does the vendor get it automatically? A: No. The PO shows "Revision 2 approved; send it again". Use **Send again**.

From chapter 21: RM inward calendar and expected arrivals

Q: I proposed 500 kg but the balance did not change. Why? A: A proposal is not counted until the Owner approves it. Look at **If proposals approved** in the material sheet to see the effect.

Q: Reels are in the store but the calendar still says short. Why? A: Reels waiting for incoming QC count from tomorrow, not today. If QC rejects them they never count. Ask QC to inspect them.

Q: Why can't I approve arrivals? A: Only the Owner approves arrivals. Admin and the desk can pick a vendor for an arrival so it is ready for him.

Q: The Owner approved arrivals but nothing came to the vendor. A: Approval makes a draft PO. The desk must still open **Scheduled drafts to send** and click **Check & send**.

Q: What does "Need is not fully known" mean? A: Some order lines could not be turned into material need, or a material has no stock item linked. Click **Details**; link missing materials in Inventory › Items.

Q: An arrival shows "Overdue". Is it still counted? A: Yes, an overdue arrival that is not received is counted on today. Chase the vendor and use **Change date**, or make the GRN if the goods came.

Q: A row in Expected arrivals shows "Add date" instead of "Confirm". A: That PO line has no dated delivery row yet. **Add date** creates one with the date the vendor gives.

Q: Why is my approved PO not in Expected arrivals? A: Only approved and partly received POs with an open quantity are listed. A draft or a PO waiting approval is not expected yet.

From chapter 22: Invoice differences, debit notes and purchase reports

Q: The vendor's rate is ₹0.10 higher. Do I really need a case? A: Yes. Any rate difference opens a case. Accept it with a reason if the extra is agreed.

Q: Why is the Claim box greyed out on my row? A: Only positive **Rate** or **Quality** rows that are still open and have the invoice attached can be claimed. Rows with "Invoice pending" become claimable after the invoice is attached in the GRN register.

Q: Can the reels be used while the rate case is open? A: Yes, once incoming QC passes them. Invoice and rate questions never hold paper back.

Q: I made the GRN. Why can't I accept its difference? A: The person who made the receipt cannot decide its own exception. Ask the plant head or Accounts.

Q: Does accepting a difference change the PO rate for next time? A: No. The PO stays as approved. Only the stock cost of that receipt line follows the invoice rate.

Q: Does issuing a debit note mean the money is recovered? A: No. Issued means the claim was sent. Record each payment or credit with **Record settlement**; the note is **Settled** only when nothing is open.

Q: Which register do I give the auditor for purchases? A: The **GRN receipt register** (one row per received line) and the **Inward and lot register** (one row per reel or coil), as Full Excel.

From chapter 23: Goods inward, GRN register and labels

Q: The vendor sent only the challan. Can I still receive? A: Yes. Tick **Challan received · invoice pending**, type the challan rate if you have it, and attach the invoice later in the GRN register. The reels are not held for the invoice.

Q: Why doesn't my PO appear in Approved purchase order? A: Only approved POs of that vendor with an open quantity are listed. It may still be waiting approval, fully received or closed.

Q: Do I enter gross weight and tare? A: No. Enter only the net kg of each reel or coil (paper alone).

Q: I typed the wrong weight and already posted. How do I fix it? A: A posted GRN cannot be edited. Raise a stock correction with the reason "Wrong GRN weight"; the Owner approves it (see the stock counts chapter).

Q: Why does the inward number start with IN and not P? A: P is used only when every line is paper, A only when every line is adhesive. Anything else, or a mix, uses IN.

Q: It is January 2027. Why is the number still P/26/...? A: The number follows the financial year, April to March. 26 means 2026-27; it changes to P/27/001 on 1 April 2027.

Q: The label got wet. How do I print a new one? A: Open the receipt in the GRN register, type a **Reprint reason** and click **Prepare 1 label**.

Q: Can the reels go to the floor before QC? A: No. They show **Waiting for QC** until incoming QC passes them. Rate and invoice questions never hold them, but QC does.

From chapter 24: Issue to the floor: reels, coils and materials

Q: Why isn't there a shift or date box? A: The shift and date come from the clock when you press Issue. An issue at 01:30 on 7 Nov is Shift B of 6 Nov.

Q: A reel is in the store but not in Ready for the floor. Why? A: It has not passed incoming QC. It is under **Not cleared yet** with the reason. Ask QC to inspect it, or use **Inspect now** if you have QC access.

Q: Can I issue half a reel? A: No. A reel or coil goes to the floor whole. Material issue (adhesive, packing, parchment) is by quantity.

Q: The floor did not use all the adhesive. Can I take it back into stock? A: No. Nothing comes back from the floor; the stock count settles what was really used.

Q: I issued the wrong reel. How do I undo it? A: You cannot undo an issue. Issue the right reel. If the wrong one is still in the store, the next stock count shows it as "Issued, but found in store", and the Owner decides whether to add it back on QC hold.

Q: I scanned a parchment coil on the reel desk and got a message. A: Parchment is issued by colour and kg on the material desk. Click **Open material issue** in the message.

Q: What does the RMIssue role allow? A: Raw material issue only: issue reels, coils and materials to the floor, write slitting cards, read issue history and genealogy, and take part in stock counts. Its home page is Reel & coil issue.

Q: What are "Older open issues"? A: Reels issued to a machine before floor issue started. Close each once with **Used kg**, or **Back to stock, then issue to floor** to return it unchanged and issue it again. New issues never appear here.

Q: Why does the desk say "Stock is still loading"? A: You scanned before the stock list finished loading. The label is checked as soon as it is ready; you do not need to scan again.

From chapter 25: Stock counts, stock book, locations and opening stock

Q: I counted a rack correctly, so why does it show lots "not found"? A: Rack done marks every lot the book expects on that rack and nobody scanned as not found. Use **Look again** before confirming. If the lot is on another rack, scan it there; it will show as **In the wrong place** and move on approval, not be written off.

Q: A reel was issued to the floor but it is still lying in the store. Can I return it? A: No. Nothing comes back from the floor. Scan it in a count; it shows as **Issued, but found in store**, and the Owner either leaves it as used or adds it as new stock on QC hold with a new label.

Q: Why can't I start the month-end count? A: Read the note on the card. The running month opens only in its last 3 days. A closed month, or a month before a closed month, cannot be counted. A spot count can run any time.

Q: What is the difference between a whole-store spot count and the month-end count? A: Both change stock when approved, but only the month-end count becomes the month's stock certificate, which Month-end close uses.

Q: The Owner approved a count with a mistake. How do we undo it? A: Approval cannot be undone. Fix it with a new spot count of that rack, or a correction for that lot.

Q: Why did my correction post a different quantity from what I raised? A: At approval the system re-bases it on the stock at that moment. If a count or another correction already changed that lot, only the remaining difference is posted, and the note on the line says so.

Q: Why does the stock book say "Opens from the book on the 1st" and not from last month's close? A: The previous month is not closed yet. After it is closed, the chip says "Opens from last month's close".

Q: Why is the Value on a count shown in amber, with "with no rate"? A: Some lines have no rate yet, usually because the GRN invoice is pending. Those lines are left out of the ₹ total, but their stock change still posts in full.

Q: We forgot one rack at go-live. Can we still add it? A: Yes, as a new batch on the same go-live date, until the go-live month is closed. After that, add the stock through a stock count.

Q: Where does goods inward put stock if I do not choose a rack? A: In the location marked **RM store · goods inward lands here**. The Owner or Admin can make another active store rack the RM store from its **More actions** menu.

From chapter 26: Inventory, material items, manual FG, stock alerts and RM costing

Q: Why does Stock on hand not include our cartons and cores? A: That tile and the material chart add up only materials counted in kg. Pieces are shown separately, because kg and pcs are never added together.

Q: I saved a stock alert policy but no alerts appear. A: A draft does nothing. A different person must click **Activate as checker**, and then someone must click **Evaluate active policies now**.

Q: I am the Plant Manager and drafted the policy myself. Why can't I activate it? A: Policies use maker-checker. Ask another Plant Manager, the Owner or the Admin to activate it.

Q: Stock went up but the alert is still open. A: It recovers only above reorder + recovery margin, and only when Evaluate runs again. Held lots do not count as free stock until QC clears them.

Q: A customer sent back 500 tubes. Do I enter them in Manual FG? A: No. The system refuses customer returns here. Record them in Quality > Customer complaints, so they are held for QC and linked to the customer and dispatch.

Q: I posted manual FG twice by mistake. A: If you gave the same Reference both times, the second post was ignored. If not, ask the Plant Manager to correct the extra stock; the post cannot be undone from this page.

Q: Why can't I delete an old paper item? A: It still has stock. Issue, count or correct the balance to zero first. Deleting only switches the item off; its history stays.

Q: Does activating a new RM cost change what we paid on old POs? A: No. It is a planning cost only. PO rates, invoice rates and the cost of lots already received are never changed.

Q: Where does a new paper master show up as a stock item? A: Automatically, with the same code, when the master is saved. You then set its reorder, safety and lead days under **Material items**.

From chapter 27: Reports

Q: Why does a tile say "Not reported"? A: Either your role cannot read that source (pack figures need Owner, Admin, Planner or Plant Manager), or the source did not answer. Refresh after a minute; it never shows a false zero.

Q: Why is machine utilization above 100%? A: The load assigned to the machines is larger than the capacity set for them, often because capacity is entered in a different or smaller unit. Check the machine's capacity in System > Machines.

Q: OTIF shows 0% but we delivered on time. A: OTIF counts only closed (fully dispatched) orders with a due date. Few closed orders, or orders without a due date, give 0%.

Q: Why are so many runs "Run before planning"? A: The floor logged the run before the planner gave the stage a slot. The floor is never blocked by this; it only shows the planner where the plan lagged.

Q: Why is every customer "at risk" in Customer 360? A: A customer with no closed order in the window has OTIF 0, which is below 90%, so it shows as Watch until orders close on time.

Q: The slitting wastage % looks low compared with the paper issued. A: The % uses only reels whose slitting card is written. Write the pending cards to complete it.

Q: Can I change the window on Operations command or Sales pulse? A: No. Operations command is always the last 7 days and Sales pulse and Customer 360 the last 30 days. Use Throughput or Planning performance for other periods.

Q: Can I get the owner pack by email? A: The system can send the owner pack every day (06:30 by default) through Background jobs. Ask the Admin whether it is switched on for your plant.

From chapter 28: Masters

Q: I deleted a customer by mistake. Is it gone? A: No. Delete only deactivates it. Set Status to Inactive, find it and click **Activate**.

Q: Why can't I change an order close reason's code? A: Closed orders keep that code. Rename it instead, or deactivate it and add a new one.

Q: I changed a paper's GSM. Why does an old spec still show the old value? A: Saved recipe versions keep the values they were saved with. Save a new recipe version to use the new value.

Q: The customer row says "No dispatch address". Does it matter? A: Yes for dispatch. The challan prints the ship-to address from here. Edit the customer and fill it, or tick **Same as the billing address**.

Q: I typed a GSTIN and the PAN changed by itself. A: A GSTIN contains the PAN (characters 3 to 12) and the state code (first 2 digits), so the system fills them to match.

Q: A new paper does not appear in Material items. A: It is created automatically when the master is saved. Refresh Material items. If its code is already used by another type of material, the system reports a conflict instead; use a different code.

Q: Where do I change who can log in? A: Not here. Employees are shop-floor people for reports. Logins are under System > Users.

Q: Why can't the Plant Manager edit papers? A: Masters are Owner and Admin only, except Reason codes, which the Plant Manager may also change.

From chapter 29: System, audit, production season and the guide

Q: I changed a person's role but they still see the old screens. A: Saving signs them out. Ask them to sign in again.

Q: Can a user have two roles? A: Yes. Tick both. Access adds up, and they can switch role from the top bar.

Q: Why can't I tick "Allow all plants" for a Plant Manager? A: All-plant access is only for Owner and Admin. Tick each plant they need under **Allowed plants** instead.

Q: A person left the company. Do I delete them? A: Untick **Account active**. They cannot sign in, and their history stays in the audit trail.

Q: Why does the Users list show fewer people than I expect? A: It shows users of the plant chosen in the top plant switcher. Switch to all plants to see everyone.

Q: Why did the season switch refuse with "Season preview changed"? A: Someone changed a spec or QC rule after you opened the preview. Click the season again to get a fresh preview.

Q: Does switching the season change job cards already on the floor? A: No. Released job cards keep the season and tolerances they were released with. Only new releases use the new season.

Q: The daily summary did not arrive. A: Check **Background jobs**. If it says "Run by the server's timer", the server sends it at 6:30 am. If an error shows under **What went wrong**, tell the Admin.

Q: Where is the latest guide? A: The Guide page in the app (Full handbook tab) and the same handbook on the sign-in screen link. The book icon on any page opens the guide for that page.