

Dropdown List User Guide

Add, rename, discontinue, and restore tool attributes without technical support.

LIVE SYSTEM	WHO CAN EDIT
35-154-224-14.sslip.io/masters/tools	Admin, Owner, Plant Manager

Before You Start

- 1

Sign in with an **Admin, Owner, or Plant Manager** account.
- 2

Select a **specific plant** in the top bar. Do not use All plants while editing masters.
- 3

Open **Masters > Tools**, then choose Add Tool or Edit.

Five fixed categories

Notch Blade Holder V + Flat Punch

Categories are fixed. Users can add any number of tool definitions and physical assets under them.

Edit a List Inside the Tool Form

Status

Active

Display Name

Auto from tool points

NOTCH POINTS
These fields create the spec-sheet dropdown value.

Type Manage list Thickness

Select type 6 mm

Design Manage list

Select design

Degree Manage list

Select degree

Add degree value + Add

50 Discontinue

55 Discontinue

60 Discontinue

Cancel Save

- 1 Choose the required tool category.
- 2 Find Type, Design, Degree, Blade Type, or Punch and select **Manage list**.
- 3 Enter a new value and select **Add**. The new value is selected automatically.
- 4 Use the pencil icon to rename an existing value.
- 5 Select **Discontinue** to hide a value from new selections while preserving history.
- 6 Open the same list and select **Reactivate** when the value is needed again.

Example: Add Degree 65

Add or edit a Notch tool, open Manage list beside Degree, enter **65**, and select Add. Complete the tool details and Save.

Direction, Distance, and Depth

FIELD	HOW IT IS MAINTAINED
Notch Direction	Editable Dropdown Registry: Category Notch, field notch_direction.
Notch Distance	Direct numeric input in the specification sheet.
Notch Depth	Direct numeric input in the specification sheet.

Why Discontinue Instead of Delete?

Discontinue removes the value from future selections but keeps old specifications, production records, and traceability intact. Reactivate restores it for future use.

Troubleshooting

- 1 If Manage list is missing or disabled, select a specific plant and verify the user role.
- 2 If a duplicate warning appears, use or rename the existing value.
- 3 If a discontinued value is missing, reactivate it from Manage list or the registry.
- 4 If a change is not visible, close and reopen the form and confirm the selected plant.

PRODUCTION CHECK

AWS production accepted an Owner-role dropdown update. List changes are plant-scoped and feed the corresponding tool and specification-sheet dropdowns.