

USB-C J1 is the only power/data input (standalone or from battery board J7). Battery X arrives as 100 Hz open-drain PWM on J2 (Dupont, 1=GND 2=BAT_PWM). Buttons: LEFT GPIO8, OK GPIO9 (BOOT), RIGHT GPIO2. J8 (DNP) = external 5 V via D2. TFT top contact confirmed by user. J6 (DNP) = external e-paper adapter, DESPI-C02 pin order: fit one display. One PM module.

