SmartPrint ATM Kiosk • Hardware Calibration Sheet

Rajalakshmi Institute of Technology • MH-ET LIVE Scanner v3.0 Setup

STEP 1: Unlock Setting Mode

[illegible] (1 Beep)

STEP 2: Auto-Sensing / Induction

[illegible]

STEP 3: Turn OFF White LED

[illegible] LED-[illegible]

STEP 4: Save to Memory

[illegible]

STEP 5: Lock & Exit Config

[illegible]

STEP 6: LIVE ORDER TEST PASS (PIN: 9287)

[illegible] Kiosk [illegible]!