

CONTRACTOR SAFETY MANUAL - SECTION 1 - INTRODUCTION

This manual applies to every contractor working on company sites.

It is issued by the Site Safety Office and reviewed every two years.

Contractors must read it before their first day on site.

CONTRACTOR SAFETY MANUAL - SECTION 2 - SITE INDUCTION

Every contractor completes a site induction before starting work.

The induction takes 90 minutes and is valid for twelve months.

Induction cards must be carried at all times on site.

CONTRACTOR SAFETY MANUAL - SECTION 3 - PERSONAL PROTECTIVE EQUIPMENT

Steel capped boots, a hard hat and safety glasses are required in all work zones.

Hearing protection is required where noise exceeds 85 decibels.

Contractors supply their own protective equipment unless the work order says otherwise.

CONTRACTOR SAFETY MANUAL - SECTION 4 - SUPERVISION

Each contractor crew nominates a leading hand before work starts.

The leading hand is the contact point for the site supervisor.

CONTRACTOR SAFETY MANUAL - SECTION 5 - HOT WORK PERMITS

Welding, grinding and cutting require a hot work permit.

A hot work permit is valid for one shift of up to 8 hours.

Hot work permits are signed off by the duty engineer.

A fire watch stays for 60 minutes after hot work ends.

CONTRACTOR SAFETY MANUAL - SECTION 6 - CONFINED SPACES

Entry to a tank, pit or vault requires a confined space permit.

The atmosphere is tested for oxygen and gas before every entry.

Confined space permits are signed off by the entry supervisor.

A confined space permit is valid for 4 hours.

CONTRACTOR SAFETY MANUAL - SECTION 7 - WORKING AT HEIGHTS

A harness is required for any work above 2 metres without edge protection.

Harnesses are inspected every six months and tagged.

Working at heights permits are signed off by the rigging coordinator.

CONTRACTOR SAFETY MANUAL - SECTION 8 - SCAFFOLDING

Only licensed scaffolders may erect or alter scaffolding.

Scaffolds are inspected every 30 days and after storms.

A green scaffold tag means the scaffold is safe to use.

CONTRACTOR SAFETY MANUAL - SECTION 9 - ELECTRICAL ISOLATION

Equipment is isolated and locked out before maintenance.

Each worker applies a personal danger lock and tag.

Only the person who applied a lock may remove it.

CONTRACTOR SAFETY MANUAL - SECTION 10 - PORTABLE ELECTRICAL EQUIPMENT

Portable tools and leads are tested and tagged every three months.

Untagged equipment is removed from site.

CONTRACTOR SAFETY MANUAL - SECTION 11 - HAZARDOUS CHEMICALS

A safety data sheet must be on site for every chemical brought in.

Chemicals are stored in the bunded store behind Building C.

CONTRACTOR SAFETY MANUAL - SECTION 12 - ASBESTOS

The asbestos register is held by the Site Safety Office.

Check the register before drilling or cutting any wall or ceiling.

Suspected asbestos stops work immediately.

CONTRACTOR SAFETY MANUAL - SECTION 13 - EXCAVATION

Any dig deeper than 300 millimetres needs a buried services search first.

Excavation permits are signed off by the civil engineer.

Trenches deeper than 1.5 metres must be shored or battered.

CONTRACTOR SAFETY MANUAL - SECTION 14 - CRANE LIFTS

Every crane lift needs a lift plan approved the day before.

Lifts stop when wind gusts exceed 40 kilometres per hour.

CONTRACTOR SAFETY MANUAL - SECTION 15 - MOBILE PLANT

Forklifts and elevated work platforms are operated only by licence holders.

Plant is pre-start checked at the beginning of each shift.

The site speed limit for plant is 10 kilometres per hour.

CONTRACTOR SAFETY MANUAL - SECTION 16 - TRAFFIC MANAGEMENT

Pedestrian walkways are marked in yellow and must be kept clear.

Reversing plant requires a spotter.

CONTRACTOR SAFETY MANUAL - SECTION 17 - NOISE AND VIBRATION

Noisy work is limited to 7am to 5pm on weekdays.

Jackhammer use is rotated between workers every 30 minutes.

CONTRACTOR SAFETY MANUAL - SECTION 18 - DUST AND SILICA

Cutting concrete or stone requires water suppression or on-tool extraction.

P2 respirators are required during dry cutting.

CONTRACTOR SAFETY MANUAL - SECTION 19 - MANUAL HANDLING

Loads over 20 kilograms require a two person lift or a mechanical aid.

CONTRACTOR SAFETY MANUAL - SECTION 20 - HOUSEKEEPING

Work areas are cleaned at the end of every shift.

Waste is separated into general, metal and timber skips.

CONTRACTOR SAFETY MANUAL - SECTION 21 - FIRST AID

Each crew of five or more carries a first aid kit.

The site first aid room is next to the gatehouse.

CONTRACTOR SAFETY MANUAL - SECTION 22 - HEAT STRESS

When the temperature exceeds 35 degrees, crews take a 10 minute break every hour.
Cool drinking water is provided at the gatehouse.

CONTRACTOR SAFETY MANUAL - SECTION 23 - TEMPORARY LIGHTING

Temporary lighting must provide at least 160 lux in work areas.

Lighting leads are run overhead, never across walkways.

CONTRACTOR SAFETY MANUAL - SECTION 24 - ENVIRONMENTAL CONTROLS

Spill kits are kept at every chemical store and refuelling point.

Stormwater drains are covered during concrete washout.

CONTRACTOR SAFETY MANUAL - SECTION 25 - SUBCONTRACTORS

A contractor may engage a subcontractor only with written approval from the site supervisor.
Subcontractors complete the same site induction.

CONTRACTOR SAFETY MANUAL - SECTION 26 - INSURANCE

Contractors hold public liability cover of at least 20 million dollars.

Certificates of currency are provided before the first day on site.

CONTRACTOR SAFETY MANUAL - SECTION 27 - AUDITS

The Site Safety Office audits each contractor at least once a quarter.

Audit findings rated high must be closed within 7 days.

CONTRACTOR SAFETY MANUAL - SECTION 28 - NON-COMPLIANCE

A first breach of this manual results in a written warning.

A second breach within twelve months removes the contractor from site for 14 days.

A serious breach ends the contract.

CONTRACTOR SAFETY MANUAL - SECTION 29 - CLOSING OUT WORK

When work is finished, permits are returned and signed closed.

The leading hand walks the area with the site supervisor before handover.

CONTRACTOR SAFETY MANUAL - SECTION 30 - REVIEW OF THIS MANUAL

This manual was last revised in March 2026.

Feedback on the manual goes to the Site Safety Office.