DinoGuard Application Procedures

1. Prepare the Area & Equipment

Dinoflex recommends using a thin napped paint roller or t-bar lamb's wool applicator to apply DinoGuard. It is also recommended to line a paint tray with a garbage bag, this will keep the DinoGuard from entering the tray and eliminate the possibility of a foreign substance or unwanted chemical from getting into the coating or on the floor. It will also eliminate another clean up step once you've finished applying the DinoGuard to the floor. Set up all necessary caution/wet floor/room closed floor signs. Isolate or close off any area that will have DinoGuard applied to it. You cannot have any traffic through this area until all coats are completely dried. Ensure the rubber flooring is completely dried (including the pores) before applying the initial coat of DinoGuard. If the floor is not 100% dry, DinoGuard will not set or cure properly.

2. Applying 1st Coat


Calculate the amount of square footage that needs to be coated. Always ensure to have more DinoGuard on hand than is necessary. You do not want to run out before the job is finished. DinoGuard will cover approximately 1,000 square feet per container (2.64 US Gallons) depending on porosity of the surface.

- Step 1. Slowly mix the container by gently agitating it to ensure a consistent emulsion mixture. Do not shake as this will create bubbles in the mixture and potentially cause foaming that will not level out
- Step 2. Open the container and slowly pour into a clean lined tray.
- Step 3. The coating is now ready to use. Roll the paint roller or lamb's wool applicator into the coating to get it fully saturated. Apply an even coat of DinoGuard to the floor and work in small areas (6'w x 4'd) making sure to overlap similar to painting a wall. After each small area has been coated go over the area again to remove excess coating and roller lines. Repeat until the area is completely coated working your way toward an exit point (See next page for diagram). This not only provides complete coverage, but it is the most efficient way to apply coating in a room without ever doubling up and walking over an area you've already completed.
- Step 4. If any coating is splashed onto the baseboards or surrounding objects, it should be removed immediately as removal later can be a lengthy and tedious process.

3. Applying 2nd Coat (if desired)

The 1st coat must be allowed to completely dry before applying any subsequent coats. Allow a minimum of 1-hour dry time if you are planning on applying a 2nd coat of DinoGuard. Dry time will vary with humidity, temperature and ventilation. Adjust accordingly. A single coat of DinoGuard is typically adequate to blend in shade variation or the natural tendency of framing, however a 2nd coat may be desired to enhance cleaning & maintenance efforts.

Updated: May 10, 2018



3. Clean Up

If there are several areas that need coating over the next few days, you will need to thoroughly clean your applicator tool and allow it to fully dry prior to starting the application process again. It is recommended to have extra paint rollers or lamb's wool applicators on hand. If you are finished applying DinoGuard the materials can be discarded or cleaned for future use. Wash out and thoroughly clean all other objects and equipment that may have come in contact with the coating to ensure it is ready for use at the next opportunity. Never pour unused DinoGuard back into the primary container as you risk contamination and failure in future applications.

If DinoGuard comes into contact with skin wash off immediately.

Refer to the SDS supplied with the product for proper disposal methods and First Aid information.

Dinoflex Group LP 5590 46 Ave SE Salmon Arm, BC Canada 1-877-713-1899