



Ultibo provides bare metal programming for the Rpi-Zero, RP2B, and RPi3B Compiling Ultibo Edition for Raspberry Pi (Rpi) 01/08/17


Based on infromation found at https://ultibo.org/wiki/Building_for_Raspbian

The scripts and config files are found at https://github.com/develone/jpeg-2000-test/tree/master/bare-metal/build_ultibo_RPi







C




D





E






G





Ι





When the first shell, in the upper left hand corner, returns to the prompt the sources of fpc 3.0 and Lazarus have been downloaded an compiled. The 3.0 version of fpc will be used to compile the Ultibo Edition which be 3.1.1. This version is located at Development/FreePascal/fpc freepascal.desktop lazarus lazarus.desktop.

pi@raspberrypi2-142:~/Development/FreePascal/lazarus \$./startlazarus





This is Lazarus with the first example opened.





K







M In the upper right hand window many applications are being compiled for fpc 3.1.1.

```
ls lib/fpc/3.1.1/units/arm-linux/
         fcl-registry hermes
a52
                                            rtl-extra
                                  ncurses
         fcl-res
                    httpd22
aspell
                                          rtl-objpas
                                newt
bfd
         fcl-sdo
                    httpd24
                                numlib
                                           rtl-unicode
bzip2
          fcl-sound
                      ibase
                                 odbc
                                           sdl
cairo
         fcl-stl
                   iconvenc
                                oggvorbis sqlite
cdrom
          fcl-web
                      imagemagick openal
                                                svgalib
chm
          fcl-xml
                     imlib
                                opengl
                                           symbolic
dblib
         fftw
                   jni
                             opengles
                                         syslog
dbus
                    ldap
                               openssl
         fpgtk
                                          tcl
        fpindexer
dts
                     libcurl
                                oracle
                                          unzip
          fpmkunit
fastcgi
                      libenet
                                  pasjpeg
                                             users
fcl-async fppkg
                      libgd
                                            utils-lexyacc
                                 paszlib
                   libmicrohttpd pcap
fcl-base
          fv
                                            utmp
fcl-db
         gdbint
                     libpng
                                postgres
                                           uuid
                      libsee
                                 proj4
fcl-extra gdbm
                                           x11
fcl-fpcunit ggi
                     libtar
                               ptc
                                        xforms
fcl-image gmp
                      libvlc
                                            zlib
                                 pthreads
fcl-js
         gnome1
                     libxml2
                                  pxlib
                                            zorba
fcl-json
          googleapi
                      lua
                                 regexpr
fcl-net
         gtk1
                    mad
                               rsvg
fcl-passrc gtk2
                     modplug
                                   rtl
                                  rtl-console
fcl-process hash
                      mysql
```


Ultibo for the ARMv7 is compiled in the lower left hand window. ARMv7 is the processor for the RPi2B & RPi3B.



Ultibo for the ARMv6 is compiled in the lower right hand window. ARMv6 is the processor of the RPiA/B/A+/B+ and Zero use the ARMv6.



ARM6v



Now the configurations files need to added to the /home/pi/ultibo/fpc/bin/ foldered.

pi@raspberrypi2-169:~ \$ cp jpeg-2000-test/bare-metal/build_ultibo_RPi/rpi*.cfg ultibo/core/fpc/bin

mkdir test ultibo

cd test_ultibo

git clone https://github.com/ultibohub/Demo.git

cd Demo

export PATH=/home/pi/ultibo/core/fpc/bin:\$PATH

fpc -B -Tultibo -Parm -CpARMV6 -WpRPIB @/home/pi/ultibo/core/fpc/bin/rpi.cfg -O2 UltiboDemoRPi.lpr

Free Pascal Compiler version 3.1.1 [2017/01/08] for arm

Copyright (c) 1993-2015 by Florian Klaempfl and others

Target OS: Ultibo

Compiling UltiboDemoRPi.lpr

Compiling DemoMain.pas

Assembling demomain

Assembling ultibodemorpi

Linking UltiboDemoRPi

1765 lines compiled, 4.0 sec, 2598596 bytes code, 81824 bytes data

fpc -B -Tultibo -Parm -CpARMV7A -WpRPI2B @/home/pi/ultibo/core/fpc/bin/rpi2.cfg
-02 UltiboDemoRPi2.lpr
Free Pascal Compiler version 3.1.1 [2017/01/08] for arm

Copyright (c) 1993-2015 by Florian Klaempfl and others

Toward 00: 1114/b.

Target OS: Ultibo

Compiling UltiboDemoRPi2.lpr
Compiling DemoMain.pas
Assembling demomain
Assembling ultibodemorpi2
Linking UltiboDemoRPi2
1765 lines compiled, 4.8 sec, 2612452 bytes code, 84472 bytes data

fpc -B -Tultibo -Parm -CpARMV7A -WpRPI3B @/home/pi/ultibo/core/fpc/bin/rpi3.cfg -O2 UltiboDemoRPi3.lpr
Free Pascal Compiler version 3.1.1 [2017/01/08] for arm
Copyright (c) 1993-2015 by Florian Klaempfl and others
Target OS: Ultibo
Compiling UltiboDemoRPi3.lpr
Compiling DemoMain.pas
Assembling demomain
Assembling ultibodemorpi3
Linking UltiboDemoRPi3

1766 lines compiled, 4.9 sec, 2609932 bytes code, 84440 bytes data