
************** Pico Lifting Step Data Serial Transfers

"sudo minicon -s"

```
File Edit Tabs Help

+----[configuration]-----+
| Filenames and paths
| File transfer protocols
| Serial port setup
| Modem and dialing
| Screen and keyboard
| Save setup as dfl
| Save setup as dfl
| Exit
| Exit from Minicom
```

Scroll down to "Serial port setup"



Depress Enter

Configure ttyUSB0

Depress Enter

Scroll down to "Exit"

Depress Enter

```
File Edit Tabs Help


Welcome to minicom 2.7.1

OPTIONS: I18n
Compiled on Aug 13 2017, 15:25:34.
Port /dev/ttyUSB0, 06:41:25

Press CTRL-A Z for help on special keys
```

The file "r.bin" will be sent. The file needs to be in /root folder.

Depress "ctrl A S"



Scroll down to ascii.

Depress Enter

```
File Edit Tabs Help
                   -----[Select a file for upload]-----
  |Directory: /root
OP| [..]
Co| [.cache]
Po| [.config]
  [.local]
   [.ssh]
   [.vnc]
   .bash_history
   .bash_history-01185.tmp
   .bashrc
   .lesshst
   .profile
   dead.letter
   minicom.log
   myfilt.bin
   mysig.bin
                 ( Escape to exit, Space to tag )
                 [Goto] [Prev] [Show] [Tag] [Untag] [Okay]
CTRL-A Z for help | 1000000 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | yUSB0
```

scroll down to "r.bin"

```
File Edit Tabs Help
                   -----[Select a file for upload]-----
  |Directory: /root
OP| [.ssh]
Co| [.vnc]
Po| .bash_history
   .bash_history-01185.tmp
   .bashrc
   .lesshst
   .profile
   dead.letter
   minicom.log
   myfilt.bin
   mysig.bin
   r.bin
   raster-b.img
   _raster-b.img.gz
   ultibo.img
                 ( Escape to exit, Space to tag )
                 [Goto] [Prev] [Show]
                                         [Tag] [Untag] [Okay]
CTRL-A Z for help | 1000000 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | yUSB0
```

Depress Enter. The transfer will begin.

When the file is sent.