
Rayleigh Flow

> perivations

-> Plots



Keith & John

Ramjet Combistor

$$\frac{T_0}{T_1} = \left(7 + \frac{r}{z} M_1^2\right) \rightarrow T_0$$

