
Physical Layer: Components

Kameswari Chebrolu

All the figures used as part of the slides are either self created or from the public domain with either 'creative commons' or 'public domain dedication' licensing. The public sites from which some of the figures have been picked include: http://commons.wikimedia.org (Wikipedia, Wikimedia and workbooks); http://www.sxc.hu and http://www.pixabay.com

Physical Layer

Bit-by-bit delivery




Nodes: Hosts, Routers or Switches Hosts: General Purpose computers

Routers/Switches: Specialized hardware (for performance reasons)

Components: Outline

- Host Internals
- Link Characteristics
- Types of Links


Inside Computer




Expansion Slots (network adaptor, graphics card etc)

Network Code Organization

- Most applications implemented as user space processes.
- Protocols are implemented in the system kernel.
 - Socket Layer
 - Protocol Layer
 - Interface Layer



Architecture



Data Transfer

- Digital Data (bits: 1's and 0's)
- Direct Memory Access (DMA)
 - Adaptor directly reads/writes host memory
- Programmed I/O (PIO)
 - CPU responsible for moving data between adaptor and memory

Links

- Examples: Twisted Pair, Co-axial cable, Wireless
- Physical medium that propagates signals (electromagnetic waves)
- Wave: speed, frequency, wavelength

$$c = f * \lambda$$

(c is speed of light in the medium, ranges from 2*10⁸ to 3*10⁸ m/s)

Imperfect Physical Media

- Signal often made up of multiple frequency components
- Attenuation: Loss of energy over distance (expressed in dB/km)
 - Different frequencies experience different amount of loss
 - Often some frequencies are fully cutoff leading to link bandwidth
- Delay Distortion: Different frequencies propagate at different speeds
- Noise: Unwanted energy from other sources
 - Thermal Noise due to random motion of electrons
 - Crosstalk: Interference from adjacent transmissions
 End Result: Received Signal is distorted

Decibels

- Ratio between two power quantities expressed in logarithmic scale
 - $-10\log_{10}(P1/P2)$
- Example: 3dB/100m attenuation means P2 = P1/2 i.e. power reduced by half after 100m