B74FLR
PREPARATION FOR INSTALLATION INSTRUCTIONS

REAR WALL PREPARATION:

1. Uppermost 1/4”-20 x 1” UPPER MOUNTING STUDS remain in place (as shipped).
2. Lowermost 1/4“-20 x 1” BOTTOM MOUNTING STUDS remain in place as well (as shipped).
3. BOX will allow a 74“ interior to mount as shipped, using the UPPER and BOTTOM MOUNTING STUDS. Make sure to secure with wing nuts (provided with the interior).
4. To mount any other size interiors, BOTTOM MOUNTING BOLTS are provided in the BAG TAPED TO BOX. (Two pairs of bolts are in the bag. The shorter pair are for RP1 interiors, the longer pair are for P2 interiors.) When mounting the interior, hang it off of the UPPER MOUNTING STUDS and secure with the wing nuts (provided with the interior). Then screw the two BOTTOM MOUNTING BOLTS through the lower interior mounting holes and into the appropriate INTERIOR MOUNTING HOLES, **X** number of inches above the BOTTOM MOUNTING BOLTS per this schedule:
    a. 6” higher = 68” interior
    b. 12” higher = 62” interior
    c. 18” higher = 56” interior
    d. 24” higher = 50” interior
    e. 30” higher = 44” interior
    f. 36” higher = 38” interior
    g. 42” higher = 32” interior
    h. 48” higher = 26” interior

FLOOR PREPARATION:

1. Remove OPEN ENDWALL (if not required).
2. If OPEN ENDWALL is required, remove the BOTTOM BLANK ENDWALL and move OPEN ENDWALL to the lowest position. Then secure with (8) SCREWS from the original BOTTOM BLANK ENDWALL mounting.

