

#### **School Of Information Technology and Engineering**

October, 2015

#### EMBEDDED SYSTEMS LAB RECORD

(ITE 306)

of

**B.TECH** 

in

**Information Technology** 

by

<ANAND UJWAL>-(13BIT0088)

1)Write an ALP & Embedded C program to transmit a letter "M" continuously at a baud rate of 9600,8 bit data and 1 bit stop and start bit, using Timer 1 in mode 2.

#### **ALP**

mov scon, #050h

mov tmod, #020h

mov th1, #0feh

setb tr1

again:

mov sbuf, #'m'

loop: jnb ti, loop

clr ti

sjmp again

end

### C program

```
#include<stdio.h>
#include<regx51.h>
int main()
{
SCON=0x050;
TMOD=0x020;
TH1=0x0fe;
TR1=1;
while(1)
SBUF='m';
while(TI==0);
TI=0;
```

}

2)Write an ALP & Embedded C program to transmit a word "MESSAGE" continuously at a baud rate of 4800, with an oscillator frequency of 11.0592 Mhz,8 bit data and 1 bit stop and start bit, using Timer 1 in mode 1

#### **ALP**

```
mov scon, #050h
mov tmod, #020h
mov th1, #0feh
setb tr1
again:
mov sbuf, #'M'
acall loop
mov sbuf, #'E'
acall loop
mov sbuf, #'S'
```

acall loop mov sbuf, #'S' acall loop mov sbuf, #'A' acall loop mov sbuf, #'G' acall loop mov sbuf, #'E' acall loop sjmp again loop: jnb ti, loop clr ti ret end

### C program

#include<stdio.h>

```
#include<regx51.h>
void fun(unsigned char x)
{SBUF=x;
while(TI==0);
TI=0;
}
int main()
{
SCON=0x050;
TMOD=0x020;
TH1=0x0fe;
TR1=1;
while(1)
fun('M');
fun('E');
fun('S');
fun('S');
fun('A');
```

```
fun('G');
fun('E');
}
```

3)Write an ALP & Embedded C program to receive a letter at a baud rate 2400, with an oscillator frequency of 12 MHz, 8 bit data and 1 bit stop and start bit mode, using Timer 1 in mode 0.Simultaneously send the received byte to port3.

#### **ALP**

```
mov scon, #050h
mov tmod, #020h
mov th1, #0feh
setb tr1
again:
mov a,sbuf
mov p3,a
mov sbuf, a
loop: jnb ri, loop
```

```
clr ri
sjmp again
end
                        C program
#include<stdio.h>
#include<regx51.h>
int main()
{unsigned char x;
SCON=0x050;
TMOD=0x020;
TH1=0x0fe;
TR1=1;
while(1)
{
x=SBUF;
P3=x;
```

```
SBUF=x;
while(RI==0);
RI=0;
}
```

## 3)C program to AND 8b data of port 0 and port 1 and to send result to port 2

```
#include<stdio.h>
#include<regx51.h>

int main()
{
  P0=0x01;
  P1=0x03;
  P3=P0 & P1;
}
```

#### 4)C Program to AND P0.0 and P1.3 send result to P2.0

```
#include<stdio.h>
#include<regx51.h>
int main()
{
P0=0x01;
```

```
P1=0x03;
P2_0=P0_0 & P1_3;
5)C Program to read p1 and send data to p2 and p3
based on condition
#include<stdio.h>
#include<regx51.h>
int main()
unsigned int x;
P1=0x01;
x=P1;
if(x\%2==0)
P2=x;
else
P3=x;
}
6)C Program to left shift data at port 1 repetitively
```

#include<stdio.h>

#include<regx51.h>

{ unsigned int i,j;

void delay(unsigned int x)

```
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
}
int main()
{
  unsigned int x;
P1=0x06;
x=P1;
  while(1)
{
  P1=P1<<1;
  delay(1000);
}
}</pre>
```

#### 7)C program to send 0-9 to port 2

```
#include<stdio.h>
#include<regx51.h>
void delay(unsigned int x)
{    unsigned int i,j;
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
int main()
{
    unsigned int x;
for(x=0;x<=9;x++)
{P2=x;
delay(1000);</pre>
```

```
}
}
```

#### 8)C Program to send hex data to port 0

```
#include<stdio.h>
#include<regx51.h>

int main()
{
    P0=0x01;
    P1=0x03;
    P2_0=P0_0 & P1_3;
}
```

#### 9)C Program to send ASCII value of the characters

```
#include<stdio.h>
#include<regx51.h>
void delay(unsigned int x)
{    unsigned int i,j;
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
int main()
{
    unsigned char x='a';</pre>
```

```
\{P2=x;
}
10)C Program to toggle LEd's at port 1
#include<stdio.h>
#include<regx51.h>
void delay(const unsigned int x)
    unsigned int i,j;
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
int main()
while(1)
P0=0x01;
delay(20000);
P0=0x03; }
11)C program to toggle to alternate bits of port 1
#include<stdio.h>
#include<regx51.h>
void delay(const unsigned int x)
    unsigned int i,j;
for(i=0;i<x;i++)
```

```
for(j=0;j<1275;j++)
{}
}
int main()
{
    while(1)
{
    P0=0xaa;
    delay(600);
    P0=0x55;
}

12)C Program to toggle LSB bit of Port 1</pre>
```

# #include<stdio.h> #include<regx51.h> void delay(const unsigned int x)

```
void delay(const unsigned int x)
{    unsigned int i,j;
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
int main()
{
P1=0x00;
while(1)
{
P1_0=1;
delay(20000);</pre>
```

P1=0x00; }

### 13)C program to toggle MSB bit of port 1

```
#include<regx51.h>
#include<regx51.h>
void delay(const unsigned int x)
{    unsigned int i,j;
for(i=0;i<x;i++)
for(j=0;j<120;j++)
{}
}
int main()
{
P1=0x00;
while(1)
{
P1_7=1;
delay(20000);
P1=0x00; }
}</pre>
```

#### 14)C program to implement Traffic Control Signal.

```
#include<regx51.h>
void delay()
unsigned int i,j;
for(i=0;i<1000;i++)
for(j=0;j<10000;j++)
void red()
{
P0_0=1;
P0_4=0;
P0 7=0;
delay();
void yellow()
P0_0=0;
P0_4=1;
P0_7=0;
delay();
void green()
{
PO 0=0;
P0_4=0;
P0_7=1;
delay();
```

```
int main()
{
     P0=0x00;
while(1)
{
    red();
yellow();
green();
yellow();
}
}
```


#### 15)C program to implement WaterLevel Detector.

```
#include<regx51.h>
#include<Math.h>
void delay()
{
  unsigned int i,j;
  for(i=0;i<1000;i++)
  for(j=0;j<10000;j++)
{
  }
}
int main()
{
  unsigned int i;
  P1=0x00;
  P2=0x00;
  for(i=0;i<9;i++)
{</pre>
```

```
P1=pow(2,i)-1;
delay();
}
if(P1_7==1)
{
P2_0=1;
while(1);
}
```

### (Cycle Sheet 1)

### Write an ALP to perform 16 bit BCD addition



# Write an ALP to perform BUBBLE SORT (ASCENDING ORDER)

MOV DPTR,#1000H
MOV R6,#04H
OUTER:
MOV DPL,#00H
MOV R7,#04H
INNER:
MOV R0,DPL
MOVX A,@DPTR
MOV B,A
INC DPTR
MOV R1,DPL
MOVX A,@DPTR
CJNE A,B,LB
LB:
JNC LABEL
MOV DPL,R0
MOVX @DPTR A

MOV DPL,R1

MOV A,B

MOVX @DPTR,A

**LABEL:DJNZ R7,INNER** 

DJNZ R6,OUTER END

# Write an ALP to perform complement of a number

MOV A,#08H

CPL A

**INC A** 

## Write an ALP to perform GCD operation by EULERS Algorithm

MOV A,#18H
MOV B,#10H
LABEL:
MOV R0,B
MOV R7,A
DIV AB
MOV A,B
CJNE A,#00H,LOOP
MOV A,R0
JMP EN
LOOP:
MOV A,R0
JMP LABEL
EN:
END

#### Write an ALP to find factorial of a number

**MOV R0,#07H** 

**MOV A,#01H** 

**AGAIN:** 

MOV B,R0

**MUL AB** 

**DJNZ R0,AGAIN** 

### Write an ALP to find FIBONACCI SEQUENCE

MOV DPTR,	<sup>‡</sup> 1000H		
MOV R0,#0A	Н		
MOV A,#00H			
MOV R1,A			
MOVX @DP	ΓR,A		
INC DPTR			
MOV A,#01H	, ,		
MOVX @DP	ΓR,A		
INC DPTR			
LOOP:			
MOV R2,A			
ADDC A,R1			
MOVX @DP	ΓR,A		
INC DPTR			
MOV B,R2			
MOV R1,B			
DJNZ R0,LO	OP		
END			

# Write an ALP to perform INSERTION SORT for 10 numbers in ascending order

MOV DPTR,#1000H **MOV R5,#01H** MOV R6,#09H **OUTER:** MOV DPL,R5 **MOVX A,@DPTR MOV B,A** MOV A,R5 MOV R7,A **INNER:** DEC R7 **MOV DPL,R7 MOVX A,@DPTR CJNE A,B,LB** LB: **JC LBA** INC R7 **MOV DPL,R7** 

**MOVX @DPTR,A** 

MOV A,B

DEC R7

MOV DPL,R7

MOVX @DPTR,A

INC R7

**DJNZ R7,INNER** 

LBA:

INC R5

**DJNZ R6,OUTER** 

#### Write an ALP to find max of 10 nos

MOV DPTR,#1000H
MOV R0,#0AH
MOV B,#00H
LOOP:
MOVX A,@DPTR
CJNE A,B,LB
LB:
JC LBA
MOV B,A
LBA:
INC DPTR
DJNZ R0,LOOP

### Write an ALP to find MINIMUM OF 10 NOS

MOV DPTR,#1000H
MOV R0,#0AH
MOV B,#9FH
LOOP:
MOVX A,@DPTR
CJNE A,B,LB
LB:
JNC LBA
MOV B,A
LBA:
INC DPTR

DJNZ R0,LOOP

# Write an ALP to move a data block from one memory to another

MOV DPTR,#2000H

MOV R0,#40H

MOV B,#0AH

**AGAIN:** 

MOV A,@R0

**MOVX @DPTR,A** 

INC DPTR

INC R0

**DJNZ B,AGAIN** 

# Write an ALP to perform selection sort for 10 values

MOV DPTR,#1000H
MOV R5,#00H
MOV R6,#09H
OUTER:
MOV DPL,R5
MOV A,R6
MOV R7,A
MOVX A,@DPTR
MOV B,A
MOV R3,DPL
INNER:
INC DPTR
MOVX A,@DPTR
CJNE A,B,LB
LB:
JNC LBA
MOV R3,DPL
MOV B,A
LBA:
DJNZ R7,INNER

**MOV DPL,R5** 

**MOVX A,@DPTR** 

MOV R0,A

MOV A,B

MOVX @DPTR,A

MOV DPL,R3

MOV A,R0

MOVX @DPTR,A

INC R5

**DJNZ R6,OUTER** 

# Write an ALP to perform sum of first 15 natural nos

MOV R0,#0fH

MOV A,R0

INC R0

MOV B,R0

**MUL AB** 

**MOV B,#02H** 

**DIV AB**