About Privacy Policy Write For Us | Earn Money Search ... Search



Home Buy Project Kits

Store Ad

Advertise With Us

Write For Us

(i) Ads by Google

Circuit Diagram

Project Circuit

Circuit Design

Block Diagram

Home / Microcontrollers / 8051 Microcontroller

8051 Microcontroller

Last Updated on December 11, 2014 by jojo in Microcontrollers with 47 Comments



A micro controller is an integrated circuit or a chip with a processor and other support devices like program memory, data memory, I/O ports, serial communication interface etc integrated together. Unlike a microprocessor (ex: Intel 8085), a microcontroller does not require any external interfacing of support devices. Intel 8051 is the most popular microcontroller ever produced in the world market. Now lets talk about 8051 microcontroller in detail.

Before going further, it will be interesting for you to understand the *difference between a Microprocessor and Microcontroller*. We have a detailed article which describes the basic difference between both.

Microprocessor vs Microcontroller

Here is a Quick Access to various sections of this article:-

Pin Diagram :- Internal Architecture :- Program Memory Organization :- Data Memory Organization :-8051 System Clock :- 8051 Reset Circuit

Introduction

Intel first produced a microcontroller in 1976 under the name MCS-48, which was an 8 bit microcontroller. Later in 1980 they released a further improved version (which is also 8 bit), under the name MCS-51. The most popular microcontroller 8051 belongs to the MCS-51 family of microcontrollers by Intel. Following the success of 8051, many other semiconductor manufacturers released microcontrollers under their own brand name but using the MCS-51 core. Global companies and giants in semiconductor industry like Microchip, Zilog, Atmel, Philips, Siemens released products under their brand name. The specialty was that all these devices could be programmed using the same MCS-51 instruction sets. They basically differed in support device configurations like improved memory, presence of an ADC or DAC etc. Intel then released its first 16 bit microcontroller in 1982, under name MCS-96

Note:- Read the Story and History about Intel – the making of first Micro processor and more!

8051 Microcontroller Packaging

There is no need of explaining what each package means, you already know it. So I will skim through mainly used packaging for 8051. See, availability of various packages change from device to device. The most commonly used is Dual Inline Package (40 pins) – known popularly



Get Daily Updates via Email

Enter your email

Subscribe

22893 readers

Categories

101-Announcements	(25)
555 Timer IC	(14)
8051	(24)
8051 projects	(19)
Amplifier Circuits	(39)
Arduino	(37)
ARM	(3)
Audio Circuits	(104)
Automotive Circuits	(28)


as DIP. 8051 is also available in QFP (Quad Flat Package), TQFP (Thin Quad Flat Package), PQFP (Plastic Quad Flat Package) etc. For explaining the pin diagram, we have used a 40 pin DIP IC as model.

8051 Microcontroller Architecture

Its possible to explain microcontroller architecture to a great detail, but we are limiting scope of this article to internal architecture, pin configuration, program memory and data memory organization. The basic architecture remains same for the MCS-51 family. In general all microcontrollers in MCS-51 family are represented by XX51, where XX can take values like 80, 89 etc.

Schematic and Features

XX51 schematic Inputs and Outputs




The general schematic diagram of 8051 microcontroller is shown above. We can see 3 system inputs, 3 control signals and 4 ports (for external interfacing). A Vcc power supply and ground is also shown. Now lets explain and go through each in detail. System inputs are necessary to make the micro controller functional. So the first and most important of this is power, marked as Vcc with a GND (ground potential). Without proper power supply, no electronic system would work. XTAL 1 and XTAL 2 are for the system clock inputs from crystal clock circuit. RESET input is required to initialize microcontroller to default/desired values and to make a new start.

There are 3 control signals, EA,PSEN and ALE. These signals known as External Access (EA), Program Store Enable (PSEN), and Address Latch Enable (ALE) are used for external memory interfacing.

Take a look at the **schematic diagram below** (a functional microcontroller)

Schematic System Inputs for Stand Alone Operation



www.CircuitsToday.com

As mentioned above, control signals are used for external memory interfacing. If there is no requirement of external memory interfacing then, EA pin is pulled high (connected to Vcc)


AVR	(15)
Basic Electricity	(1)
Basic Electronics	(6)
Battery Circuits	(23)
C plus plus	(7)
C Programming	(14)
Cable TV Circuits	(1)
Camera Technology	(5)
Clipping and Clamping Circuits	(7)
Clocking & Timer Circuits	(2)
Conversion Circuits	(10)
Counter Circuits	(2)
Counters	(2)
Digital Electronics	(11)
Education & Training	(6)
Electronic Components	(31)
Electronic Keys & Locks	(3)
Electronics Books	(10)
Electronics Jobs	(4)
Embedded Systems	(7)
Equipment Reviews	(1)
Events	(3)
Fan Circuits	(1)
Filter Circuits	(16)
Fire Alarm	(3)
Fun & Game Circuits	(14)
Gadget Reviews	(6)
Ham Radio Circuits	(2)
High Voltage Circuits	(1)
History	(26)
Home Circuits	(35)
Industrial Circuits	(15)
Instruments	(13)
Integrated Circuits	(20)
Inverters	(5)
Lab Manuals	(20)
LED related	(3)
Light Related	(14)
Lighting Circuits	(43)
MATLAB	(3)
Microcontrollers	(7)
Mobile Phone Related	(1)
Motor Related	(14)
Nanotechnology	(14)
Oscillators	(25)
Peripheral Interface Controller	(29) (PIC)
Power Controller Circuits	(8)
Power Electronics	(2)

and two others PSEN and ALE are left alone. You can also see a 0.1 micro farad decoupling capacitor connected to Vcc (to avoid HF oscillations at input).

There are four ports numbered 0,1,2,3 and called as Port 0, Port 1, Port 2 and Port 3 which are used for external interfacing of devices like DAC, ADC, 7 segment display, LED etc. Each port has 8 I/O lines and they all are bit programmable.

8051 Pin Diagram & Description

Pin-Wise Signal Assignment of XX51



www.CircuitsToday.com

For describing pin diagram and pin configuration of 8051, we are taking into consideration a 40 pin DIP (Dual inline package). Now lets go through pin configuration in detail.

Pin-40: Named as Vcc is the main power source. Usually its +5V DC.

You may note some pins are designated with two signals (shown in brackets).

Pins 32-39: Known as Port 0 (P0.0 to P0.7) – In addition to serving as I/O port, lower order address and data bus signals are multiplexed with this port (to serve the purpose of external memory interfacing). This is a bi directional I/O port (the only one in 8051) and external pull up resistors are required to function this port as I/O.

Pin-31:- ALE aka Address Latch Enable is used to demultiplex the address-data signal of port 0 (for external memory interfacing.) 2 ALE pulses are available for each machine cycle.

Pin-30:- EA/ External Access input is used to enable or disallow external memory interfacing. If there is no external memory requirement, this pin is pulled high by connecting it to Vcc.

Pin- 29:- PSEN or Program Store Enable is used to read signal from external program memory.

Pins- 21-28:- Known as Port 2 (P 2.0 to P 2.7) – in addition to serving as I/O port, higher order address bus signals are multiplexed with this quasi bi directional port.

Pin 20:- Named as Vss – it represents ground (0 V) connection.

Pins 18 and 19:- Used for interfacing an external crystal to provide system clock.

Power Supplies	(72)
Product Reviews	(2)
Project Ideas	(1)
Projects	(7)
Proteus	(5)
Proximity Detectors	(3)
Radio Circuits	(30)
Radio Transmitters	(19)
Raspberry Pi	(1)
Relays	(3)
Remote Circuits	(12)
Reviews	(5)
Robotics	(6)
RTOS	(2)
Security & Saftey	(16)
Sensor Circuits	(16)
Signal Conditioners	(11)
Signal Generators	(13)
Speed Controller Circuits	(1)
State space analysis	(2)
Switching Circuits	(6)
Tech News	(87)
Telephone Related	(9)
Television Related	(4)
Temperature Related	(3)
Test & Measurement Circuits	(38)
Testing Components	(9)
Three phase circuits	(1)
Timer Circuits	(3)
Tone generator circuits	(20)
Tools and Softwares	(6)
Transmitters	(7)
Tutorials	(158)
UPS	(2)
USB Circuits	(3)
Videos	(5)
VLSI	(36)
Voltage Regulators	(15)



Latest Articles


Pins 10 – 17:- Known as Port 3. This port also serves some other functions like interrupts, timer input, control signals for external memory interfacing RD and WR, serial communication signals RxD and TxD etc. This is a quasi bi directional port with internal pull up.

Pin 9:- As explained before RESET pin is used to set the 8051 microcontroller to its initial values, while the microcontroller is working or at the initial start of application. The RESET pin must be set high for 2 machine cycles.

Pins 1 – 8:- Known as Port 1. Unlike other ports, this port does not serve any other functions. Port 1 is an internally pulled up, quasi bi directional I/O port.

8051 Internal Architecture

Simplified Internal Architecture of XX51



There is no need of any detailed explanation to understand internal architecture of 8051 micro controller. Just look at the diagram above and you observer it carefully. The system bus connects all the support devices with the central processing unit. 8051 system bus composes of an 8 bit data bus and a 16 bit address bus and bus control signals. From the figure you can understand that all other devices like program memory, ports, data memory, serial interface, interrupt control, timers, and the central processing unit are all interfaced together through the system bus. RxD and TxD (serial port input and output) are interfaced with port 3.

8051 Memory Organization

Before going deep into the memory architecture of 8051, lets talk a little bit about two variations available for the same. They are Princeton architecture and Harvard architecture. Princeton architecture treats address memory and data memory as a single unit (does not distinguish between two) where as Harvard architecture treats program memory and data memory as separate entities. Thus Harvard architecture demands address, data and control bus for accessing them separately where as Princeton architecture does not demand any such separate bus.

Example:- 8051 micro controller is based on Harvard architecture and 8085 micro processor is based on Princeton architecture.

Thus 8051 has two memories :- Program memory and Data memory

Program memory organization

Drag and Drop IoT Project Builder myDevices partner with Arduino

Analog Oscilloscopes/CRO Online Buying Guide

GSM and GPRS Modem/Module – Price and Buying Guide

How is ARM Programming Different?

Proteus Tutorial – Using Dot Matrix Displays

How to Make an LED Scrollbar

Heart rate monitor with sms alert.

Proteus Tutorial – Using Single and Multiple Digit Segment Displays

Proteus Tutorial – Light Emitting Diode (LED) and Bar Graph Display

How to Install and Setup Compiler with Development Environment for ARM7

Like Us on Facebook





Recent Comments

AB on Few LM317 voltage regulator circuits

Shanjedul Hassan on Digital Code Lock using Arduino with LCD Display and User Defined Password

Mark Harder on How is ARM Programming Different?

jojo on Burglar Alarm using Arduino and PIR Sensor- with SMS Alarm using GSM Module


jojo on Burglar Alarm using Arduino and PIR Sensor- with SMS Alarm using GSM Module

jojo on Burglar Alarm using Arduino and PIR Sensor- with SMS Alarm using GSM Module

jojo on GSM and GPRS Modem/Module – Price and Buying Guide

mohanraj on GSM and GPRS Modem/Module
- Price and Buying Guide

Program Memory Arrangement



Now lets dive into the program memory organization 0f 8051. It has an internal program of 4K size and if needed an external memory can be added (by interfacing) of size 60K maximum. So in total 64K size memory is available for 8051 micro controller. By default, the External Access (EA) pin should be connected Vcc so that instructions are fetched from internal memory initially. When the limit of internal memory (4K) is crossed, control will automatically move to external memory to fetch remaining instructions. If the programmer wants to fetch instruction from external memory only (bypassing the internal memory), then he must connect External Access (EA) pin to ground (GND).

You may already know that 8051 has a special feature of locking the program memory (internal) and hence protecting against software piracy. This feature is enable by program lock bits. Once these bits are programmed, contents of internal memory can not be accessed using an external circuitry. How ever locking the software is not possible if external memory is also used to store the software code. Only internal memory can be locked and protected. Once locked, these bits can be unlocked only by a memory-erase operation, which in turn will erase the programs in internal memory too.

8051 is capable of pipelining. Pipelining makes a processor capable of fetching the next instruction while executing previous instruction. Its some thing like multi tasking, doing more than one operation at a time. 8051 is capable of fetching first byte of the next instruction while executing the previous instruction.

Data memory organization

Noel on Burglar Alarm using Arduino and PIR Sensor- with SMS Alarm using GSM Module

kay xaveriuz on How to Make an LED Scrollbar

Karthikeyan on Digital Door Lock – Password based Electronic Code Lock using 8051

Guru on Digital Count Down Timer using PIC Microcontroller

jane on How to Interface GSM Module to Arduino-Send and Receive SMS

suresh on Digital voltmeter using ICL7107

msdava on Car battery charger

Pages

About

Advertise With Us

Authors

Buy Project Kits

CT Home

Datasheets

Disclaimer

Electronic Circuit Symbols

Lab Manuals

- Electronic Circuits Lab
- Microcontroller lab
- Microprocessor Lab

Privacy Policy

Project Contests

Recent Posts


Resistor Color Code Calculator

Sitemap

Testing Components


Write For Us

Internal and External Data Memory of 8051



In the MCS-51 family, 8051 has 128 bytes of internal data memory and it allows interfacing external data memory of maximum size up to 64K. So the total size of data memory in 8051 can be upto 64K (external) + 128 bytes (internal). Observe the diagram carefully to get more understanding. So there are 3 separations/divisions of the data memory:- 1) Register banks 2) Bit addressable area 3) Scratch pad area.

Lower 128 Bytes of Internal RAM 8051



Register banks form the lowest 32 bytes on internal memory and there are 4 register banks designated bank #0,#1, #2 and #3. Each bank has 8 registers which are designated as R0,R1... R7. At a time only one register bank is selected for operations and the registers inside the selected bank are accessed using mnemonics R0..R1.. etc. Other registers can be accessed simultaneously only by direct addressing. Registers are used to store data or operands during executions. By default register bank #0 is selected (after a system reset).


The bit addressable ares of 8051 is usually used to store bit variables. The bit addressable area is formed by the 16 bytes next to register banks. They are designated from address 20H to 2FH (total 128 bits). Each bits can be accessed from 00H to 7FH within this 128 bits from 20H to 2FH. Bit addressable area is mainly used to store bit variables from application program, like status of an output device like LED or Motor (ON/OFF) etc. We need only a bit to

store this status and using a complete byte addressable area for storing this is really bad programming practice, since it results in wastage of memory.

The scratch pad area is the upper 80 bytes which is used for general purpose storage. Scratch pad area is from 30H to 7FH and this includes stack too.

8051 System Clock


8051 Clock Circuit



www.CircuitsToday.com


An 8051 clock circuit is shown above. In general cases, a quartz crystal is used to make the clock circuit. The connection is shown in figure (a) and note the connections to XTAL 1 and XTAL 2. In some cases external clock sources are used and you can see the various connections above. Clock frequency limits (maximum and minimum) may change from device to device. Standard practice is to use 12MHz frequency. If serial communications are involved then its best to use 11.0592 MHz frequency.

System Clock



Okay, take a look at the above machine cycle waveform. One complete oscillation of the clock source is called a pulse. Two pulses forms a state and six states forms one machine cycle. Also note that, two pulses of ALE are available for 1 machine cycle.

8051 Reset Circuit



(1) Power-on Reset Circuit and (2) With Manual Reset Option

www.CircuitsToday.com

8051 can be reset in two ways 1) is power-on reset – which resets the 8051 when power is turned ON and 2) manual reset – in which a reset happens only when a push button is pressed manually. Two different reset circuits are shown above. A reset doesn't affect contents of internal RAM. For reset to happen, the reset input pin (pin 9) must be active high for atleast 2 machine cycles. During a reset operation: Program counter is cleared and it starts from 00H, register bank #0 is selected as default, Stack pointer is initialized to 07H, all ports are written with FFH.

Pcb testing

Professional optical precision AOI. China leading Manufacturers.ISO.CE.





Fastest PCB design tool - EasyEDA

A free online tool with schematic capture, Spice simulation, PCB Layout

You may also like:

- DIY Digital Clock with Temperature Display using PIC Controller
- Digital Voltmeter using Micro Controller PIC16F73A
- 8051 Special Function Registers and Ports
- 8051 Addressing modes
- Microprocessor and Microcontroller The difference

We recommend:

- Touch switch using CD4011.
- Battery eliminator circuit
- 2x5 W Stereo power amplifier circuit based on BA5417.
- IC Packages
- 5V transformer less power supply



47 thoughts on "8051 Microcontroller"

shalu October 5, 2015 at 5:51 am its good. thank u

Reply

GAURI August 21, 2015 at 2:00 am

It is a very nice explaination for understanding the 8051.

Thanks. waiting for the explainations of other controller PIC and Arm as well as rasberry pie

Reply

Namrata August 5, 2015 at 6:49 am

Awesome article sir. Hoping for some more article of this kind.

Reply

Bilal Malik June 3, 2015 at 3:19 am

very well written article

Reply

joseph gregoraci May 18, 2015 at 12:53 pm

Hi guys

i am student, and i am doing final year project. I wish to know what is the minimum voltage that you can give at the input port of the 8051, and the ideal voltage, so the 8051 can read it as a high(1) input.

Thanks Joseph

Reply

jojo May 19, 2015 at 3:22 am

Post author

@Joseph – it depends! You read the manufacturers datasheet to know about that. It varies with manufacturer. An idea is to condition the feeble voltage from sensor/input signal using Opamps and raise its level to 5V.

Reply

pendo stephen June 9, 2015 at 10:13 pm

am third year student am doing project using 8051 micro controller basic stamp 2. please advise me how can i connect to the circut

Reply

lalith February 28, 2015 at 9:16 am

why the bit addressable memory in 8051 micro contoller is restricted to 16 bytes

Reply

Bhaskar Sure January 5, 2015 at 4:05 am

helpful,thanks

Reply

bhavin July 17, 2014 at 2:51 am

i am doing project using 8051.so please tell me about the how to use 8051.my project is energy maximum demand contoller

Reply

P. jesal June 29, 2014 at 7:45 pm

hello,

I am making a solar inverter using 8051, please give me some guidance and circuitry.

I also build a solar tracker .. so now i am moving one step to build an inverter.

Reply

P. sushma March 31, 2014 at 8:21 am

Superab explanation .. it is really good one can easily understand the concept we need more like pentinum features can u provide?

Reply

megana March 25, 2014 at 11:14 am

It's was nice explaination

Why the bus control used in 8051 microcontroller

Reply

Krishna Chaitanya May 23, 2015 at 7:24 pm

Bus is a place where every block in the 8051 is interconnected. So when ever we used to send data from one block to another, we need to use the bus. but when more than one blocks are used to transfer the data then there exists problem, this problem can be eradicated by bus control logic.

bus control logic plays an key role in transfer of data.

Reply

megana March 25, 2014 at 11:08 am

It's was nice answer

Why the bus control used in 8051 microcontroller

Reply

Frank Donald December 29, 2013 at 6:58 pm

Nice one....Post in about various programming concepts of the MC..lt will be great if you explain Embedded C programming

Reply

lahiru December 15, 2013 at 6:11 am

I need to add IC8051 to a pic c program.

I am using reg51.h file there.

in that I should set device name.

What is the name I should use?

Reply

Pradeepkumar October 4, 2013 at 3:57 am

nice explanation. it has vital informations to read an 8051 core and its architecture. thanks for building this article.

It II be more helpful, still more concepts are to be explained like configuring timers ,counters, interrupts...

thanks again

Reply

nidhi rathi September 22, 2013 at 3:10 am

timing diagrm ni h vo b daldo plzzz ar uski explaintation b...

Reply

govind September 20, 2013 at 10:05 am

why the capacitor is placed in between vcc and reset in 8051 microcontroller

Reply

bhushan waghmare July 11, 2013 at 9:21 am

wow its excellent

Reply

gopal May 24, 2013 at 12:36 pm

superb explanation in lucid language.keep going.....

Reply

jeesha modi April 17, 2013 at 8:52 pm

my question is that why capacitors are used in crystal ckt of 8051 & value are 33pf why???

Reply

Gurmukh singh May 29, 2013 at 12:13 am

Capacitors are used with oscillators because output of oscillator is clock pulse having some frequency along with noise (harmonic distortion) having very much heigher frequency, now by using these ceramic cpacitors the high frequency noise will be grounded and clock pulse having comparitively low frequency is supplied to MC that is almost free of distortion.

Reply

dali naidu January 29, 2013 at 9:10 pm

nice explanation

Reply

prabhakar November 22, 2012 at 12:19 am

i want to know.why keep the name of 8052 microcontroller.and what is the logic behind it

Reply

Anurag October 18, 2012 at 7:19 am

Nicely explained, with easy language

Reply

goutam singh October 1, 2012 at 7:27 pm

i want to purchase microcontroller 8051,so please provide me address of manufacturer

Reply

jojo October 1, 2012 at 7:56 pm

You may buy AT89S51 - from Atmel

Post author

Reply

nikhil September 22, 2012 at 3:25 am

hello sir.

i want to know about 16 bit 80286 processor and 32 bit 80486 processor architecture.... plz help me $\,$

Reply

jojo September 22, 2012 at 6:33 pm

Post author

Hello Nikhil, Please keep waiting. We will definitely come up with articles on 16 bit and 32 bit architectures.

Reply Abhijeet July 2, 2012 at 8:34 am if there is internal pullups to port 1, 2, 3... then why we connect external 10 k pull ups to it? there is necessary??? and what happend if pull ups are ubsent to port 1, 2, 3? Reply Sumir Kumar Jha June 6, 2012 at 9:34 am Good Explanation Sir, It Helped me a Lot !!!! Reply neethukumaran February 12, 2012 at 5:51 pm very helpful post for students.. Reply harika January 28, 2012 at 9:02 am sir, what is the difference between timer and counter Reply amit September 3, 2012 at 7:15 am Counter: Counts and indicates the number of signals (events) input at any interval. Timer: Counts the number of signals input at a constant interval to indicate the elapsed time. Reply Lycon January 5, 2015 at 12:31 pm In simple words counter counts the no of event is being exicuted while timer are basically used for time delay generation. Reply Kani January 20, 2012 at 3:20 am Easily understandable Reply Kani January 20, 2012 at 3:19 am Very useful for students... Reply jojo January 4, 2012 at 9:05 pm Post author Hello Sameer, Can you point me an example? Reply

sameer gupta January 4, 2012 at 7:00 pm

Sir,

in most of the programs of 8051 microcontroller,I see "0*85,0*AF etc." what is it's mean?

				Reply
u al	<i>KSH YADAV</i> July 8, 2012 lwyas c such notaion in	c language programm	ning of uc	
this	s means to ir OAF AS A F	EX NUMBER		Reply
s <i>aiteja</i> Deceml	ber 24, 2011 at 1:28 am			
good informati	on for technical studen	S.		Reply
your explanasio	16, 2011 at 10:08 am on is easylyunderstanda my email id dhupamsai		we wantmore information froi	m you
				Reply
	ber 14, 2011 at 12:02 a		phone jack	
	J			Reply
	ber 13, 2011 at 6:24 am			
very nice one fo	or students 😇			Reply
	cember 13, 2011 at 4:52 nanks for sharing. this.	2 am		
				Reply
Leave a Reply Your email address will Comment	not be published. R	equired fields are।	marked *	
Name *				
- 14				
Email *				
Website				

Post Comment

Popular Tags

2N2222 555 IC 555 timer 8085 lab manual arduino circuits Audio Amplifier Circuits Audio circuits circuit design circuit diagram Digital Electronics Electronic Circuits Electronic Components Electronic Instruments Electronic Projects

Filter Circuits FM transmitter History of Electronics hobby circuits hobby projects Home Circuits IC IC Audio Amplifier Integrated Circuits Invention Stories Light Related microprocessor lab manual Most Popular Circuits Nanotechnology

NE555 timer Oscillators PIC PLL Power Amplifiers Power Supplies Radio Circuits Robotics SCR Simple Electronics Projects

Tech News Thyristors Timer IC Tutorials VLSI voltage converter Voltage Regulators

© 2015 CircuitsToday. All rights reserved.

Latest Electronic Circuits