



This is NOT the case when using an RS232 level shifter such as the MAX232, which is simply translating the signals to RS-232 levels.