TENTATIVE TOSHIBA MOS DIGITAL INTEGRATED CIRCUIT SILICON GATE CMOS

8 GBIT (1G \times 8 BIT) CMOS NAND E²PROM

DESCRIPTION

The TC58DVG3S0E is a single 3.3V 8 Gbit (8,858,370,048 bits) NAND Electrically Erasable and Programmable Read-Only Memory (NAND E^2PROM) organized as (4096 + 128) bytes \times 64 pages \times 4096blocks.

The device has two 4224-byte static registers which allow program and read data to be transferred between the register and the memory cell array in 4224-byte increments. The Erase operation is implemented in a single block unit (256 Kbytes + 8 Kbytes: 4224 bytes \times 64 pages).

The TC58DVG3S0E is a serial-type memory device which utilizes the I/O pins for both address and data input/output as well as for command inputs. The Erase and Program operations are automatically executed making the device most suitable for applications such as solid-state file storage, voice recording, image file memory for still cameras and other systems which require high-density non-volatile memory data storage.

FEATURES

Organization

 $\begin{array}{ccc} & x8 \\ \text{Memory cell array} & 4224 \times 256 \text{K} \times 8 \\ \text{Register} & 4224 \times 8 \\ \text{Page size} & 4224 \text{ bytes} \\ \text{Block size} & (256 \text{K} + 8 \text{K}) \text{ bytes} \end{array}$

Modes

Read, Reset, Auto Page Program, Auto Block Erase, Status Read, Page Copy, Multi Page Program, Multi Block Erase, Multi Page Copy, Multi Page Read

Mode control

Serial input/output Command control

· Number of valid blocks

Min 4016 blocks Max 4096 blocks

Power supply

 $V_{CC} = 2.7V \text{ to } 3.6V$

Access time

Cell array to register 30 µs max

Serial Read Cycle 25 ns min (CL=50pF)

• Program/Erase time

Auto Page Program $350 \mu \text{s/page typ.}$ Auto Block Erase 3 ms/block typ.

Operating current

Read (25 ns cycle) 30 mA max. Program (avg.) 30 mA max Erase (avg.) 30 mA max Standby 50 µA max


Package

TSOP I 48-P-1220-0.50 (Weight: 0.53 g typ.)

• TBD bit ECC for each 528Byte is required.



PIN ASSIGNMENT (TOP VIEW)




PINNAMES

I/O1 to I/O8	I/O port
CE	Chip enable
WE	Write enable
RE	Read enable
CLE	Command latch enable
ALE	Address latch enable
PSL	Power on select
WP	Write protect
RY/ BY	Ready/Busy
V _{CC}	Power supply
V _{SS}	Ground

2

BLOCK DIAGRAM



ABSOLUTE MAXIMUM RATINGS

SYMBOL	RATING	VALUE	UNIT
V _C C	Power Supply Voltage	-0.6 to 4.6	V
VIN	Input Voltage	-0.6 to 4.6	V
V _{I/O}	Input /Output Voltage	$-0.6 \text{ to V}_{CC} + 0.3 (\le 4.6 \text{ V})$	V
P _D	Power Dissipation	0.3	W
T _{SOLDER}	Soldering Temperature (10 s)	260	°C
T _{STG}	Storage Temperature	–55 to 150	°C
T _{OPR}	Operating Temperature	0 to 70	°C

CAPACITANCE *(Ta = 25°C, f = 1 MHz)

SYMB0L	PARAMETER	CONDITION	MIN	MAX	UNIT
C _{IN}	Input	$V_{IN} = 0 V$	_	10	pF
C _{OUT}	Output	V _{OUT} = 0 V		10	pF

This parameter is periodically sampled and is not tested for every device.

VALID BLOCKS

SYMBOL	PARAMETER	MIN	TYP.	MAX	UNIT
N _{VB}	Number of Valid Blocks		_	4096	Blocks

NOTE: The device occasionally contains unusable blocks. Refer to Application Note (13) toward the end of this document.

The first block (Block 0) is guaranteed to be a valid block at the time of shipment.

The specification for the minimum number of valid blocks is applicable over lifetime

The number of valid blocks is on the basis of single plane operations, and this may be decreased with two plane operations.

RECOMMENDED DC OPERATING CONDITIONS

SYMBOL	PAR	MIN	TYP.	MAX	UNIT	
V _{CC}	Power Supply Voltage	2.7	_	3.6	V	
V _{IH}	High Level input Voltage	2.7 V ≤ V _{CC} ≤ 3.6 V	Vcc x 0.8	_	V _{CC} + 0.3	V
V _{IL}	Low Level Input Voltage	2.7 V ≤ V _{CC} ≤ 3.6 V	-0.3*	_	Vcc x 0.2	V

^{* -2} V (pulse width lower than 20 ns)

DC CHARACTERISTICS (Ta = 0 to 70 , $V_{CC} = 2.7$ to 3.6V)

SYMBOL	PARAMETER	CONDITION	MIN	TYP.	MAX	UNIT
I _{IL}	Input Leakage Current	$V_{IN} = 0 V \text{ to } V_{CC}$	_	_	±10	μА
I _{LO}	Output Leakage Current	V _{OUT} = 0 V to V _{CC}	_	_	±10	μА
		PSL = GND or NU	_	_	30	
I _{CCO0} *	Power On Reset Current	PSL = V _{CC} , FFh command input after Power On	_	_	30	mA
I _{CCO1}	Serial Read Current	$\overline{CE} = V_{IL}$, $I_{OUT} = 0$ mA, tcycle = 50 ns	_	_	30	mA
I _{CCO2}	Programming Current	_	_	_	30	mA
I _{CCO3}	Erasing Current	_			30	mA
Iccs	Standby Current	$\overline{\text{CE}} = V_{\text{CC}} - 0.2 \text{ V}, \ \overline{\text{WP}} = 0 \text{ V/V}_{\text{CC}},$ $PSL = 0 \text{ V/V}_{\text{CC}}/\text{NU}$	_	_	50	μА
Voн	High Level Output Voltage	I _{OH} = -0.1 mA	Vcc - 0.2	_	_	V
V _{OL}	Low Level Output Voltage	I _{OL} = 0.1 mA	_	_	0.2	V
I _{OL} (RY/BY)	Output current of RY/BY pin	V _{OL} = 0.2 V	_	4	_	mA

^{*} Refer to application note (2) for detail



$\frac{AC\ CHARACTERISTICS\ AND\ RECOMMENDED\ OPERATING\ CONDITIONS}{(Ta=0\ to\ 70\quad,\ V_{CC}=2.7\ to\ 3.6V)}$

SYMBOL	PARAMETER	MIN	MAX	UNIT
tCLS	CLE Setup Time	12	_	ns
t _{CLH}	CLE Hold Time	5	_	ns
tcs	CE Setup Time	20	_	ns
tCH	CE Hold Time	5	_	ns
t _{WP}	Write Pulse Width	12	_	ns
t _{ALS}	ALE Setup Time	12	_	ns
t _{ALH}	ALE Hold Time	5	_	ns
t _{DS}	Data Setup Time	12	_	ns
t _{DH}	Data Hold Time	5	_	ns
t _{WC}	Write Cycle Time	25	_	ns
t _{WH}	WE High Hold Time	10	_	ns
t _{WW}	WP High to WE Low	100	_	ns
t _{RR}	Ready to RE Falling Edge	20	_	ns
t _{RW}	Ready to WE Falling Edge	20	_	ns
t _{RP}	Read Pulse Width	12	_	ns
t _{RC}	Read Cycle Time	25	_	ns
t _{REA}	RE Access Time	_	20	ns
tCEA	CE Access Time	_	25	ns
t _{CLR}	CLE Low to RE Low	10	_	ns
t _{AR}	ALE Low to RE Low	10	_	ns
t _{RHOH}	RE High to Output Hold Time	25	_	ns
t _{RLOH}	RE Low to Output Hold Time	5	_	ns
t _{RHZ}	RE High to Output High Impedance	_	60	ns
tсон	CE High to Output Hold Time	15	_	ns
t _{CHZ}	CE High to Output High Impedance	_	30	ns
t _{CSD}	CE High to ALE or CLE Don't Care	0	_	ns
t _{REH}	RE High Hold Time	10	_	ns
t _{IR}	Output-High-impedance-to- RE Falling Edge	0	_	ns
t _{RHW}	RE High to WE Low	30	_	ns
twhc	WE High to CE Low	30	_	ns
t _{WHR}	WE High to RE Low	60	_	ns
t _R	Memory Cell Array to Starting Address	_	30	μS
tDCBSYR1	Data Cache Busy in Read Cache (following 31h and 3Fh)	_	30	μ\$
t _{DCBSYR2}	Data Cache Busy in Page Copy (following 3Ah)	_	35	μS
t _{WB}	WE High to Busy	_	100	ns
t _{RST}	Device Reset Time (Ready/Read/Program/Erase)	_	10/10/30/500	μS

^{*1:} tCLS and tALS can not be shorter than tWP

^{*2:} tCS should be longer than tWP + 8ns.

AC TEST CONDITIONS

PARAMETER -	CONDITION
TANAMETER	V _{CC} : 2.7 to 3.6V
Input level	V _{CC} – 0.2 V, 0.2 V
Input pulse rise and fall time	3 ns
Input comparison level	Vcc/2
Output data comparison level	Vcc/2
Output load	C _L (50 pF) + 1 TTL

TOSHIBA CONFIDENTIAL

Note: Busy to ready time depends on the pull-up resistor tied to the RY/BY pin. (Refer to Application Note (9) toward the end of this document.)

PROGRAMMING AND ERASING CHARACTERISTICS

 $(Ta = 0 \text{ to } 70 \text{ , } V_{CC} = 2.7 \text{ to } 3.6V)$

SYMBOL	PARAMETER	MIN	TYP.	MAX	UNIT	NOTES
t _{PROG}	Average Programming Time	_	350	700	μS	
t _{DCBSYW1}	Data Cache Busy Time in Write Cache (following 11h)	_	0.5	1	μS	
t _{DCBSYW2}	Data Cache Busy Time in Write Cache (following 15h)			700	μS	(2)
N	Number of Partial Program Cycles in the Same Page	_	_	4		(1)
t _{BERASE}	Block Erasing Time		3	10	ms	

⁽¹⁾ Refer to Application Note (12) toward the end of this document.

Data Output

When tREH is long, output buffers are disabled by /RE=High, and the hold time of data output depend on tRHOH (25ns MIN). On this condition, waveforms look like normal serial read mode.

When tREH is short, output buffers are not disabled by $\mbox{RE=High}$, and the hold time of data output depend on tRLOH (5ns MIN). On this condition, output buffers are disabled by the rising edge of CLE,ALE,/CE or falling edge of \mbox{WE} , and waveforms look like Extended Data Output Mode.


6

⁽²⁾ t_{DCBSYW2} depends on the timing between internal programming time and data in time.




TIMING DIAGRAMS


Latch Timing Diagram for Command/Address/Data




Command Input Cycle Timing Diagram




Address Input Cycle Timing Diagram




Data Input Cycle Timing Diagram



Serial Read Cycle Timing Diagram




Status Read Cycle Timing Diagram




^{*: 70}h represents the hexadecimal number




Read Cycle Timing Diagram



Read Cycle Timing Diagram: When Interrupted by CE




Read Cycle with Data Cache Timing Diagram (1/2)



11 2009-03-09C


Read Cycle with Data Cache Timing Diagram (2/2)



Continues from 1 of last page


12 2009-03-09C

Column Address Change in Read Cycle Timing Diagram (1/2)




Continues from 1 of next page

Column Address Change in Read Cycle Timing Diagram (2/2)




Continues from 1 of last page

Data Output Timing Diagram



Auto-Program Operation Timing Diagram




: Do not input data while data is being output.


: V_{IH} or V_{IL}

*) M: up to 4223 (byte input data for $\times 8$ device).

Auto-Program Operation with Data Cache Timing Diagram (1/3)



Auto-Program Operation with Data Cache Timing Diagram (2/3)




Continued from 1 of last page

: Do not input data while data is being output.

: V_{IH} or V_{IL}

Auto-Program Operation with Data Cache Timing Diagram (3/3)



tpROG = tpROG of the last page + tpROG of the previous page - A
A = (command input cycle + address input cycle + data input cycle time of the last page)


If "A" exceeds the tpROG of previous page, tpROG of the last page is tpROG max.

(Note) Make sure to terminate the operation with 80h-10h- command sequence.


If the operation is terminated by 80h-15h command sequence, monitor I/O 6 (Ready / Busy) by issuing Status Read command (70h) and make sure the previous page program operation is completed. If the page program operation is completed issue FFh reset before next operation.

TOSHIBA

Multi-Page Program Operation with Data Cache Timing Diagram (1/4)



Multi-Page Program Operation with Data Cache Timing Diagram (2/4)




Continued from 1 of last page


: Do not input data while data is being output.

: V_{IH} or V_{IL}

Multi-Page Program Operation with Data Cache Timing Diagram (3/4)



Multi-Page Program Operation with Data Cache Timing Diagram (4/4)



(*1) t_{PROG} : Since the last page programming by 10h command is initiated after the previous cache program, the t_{PROG} during cache programming is given by the following equation.


 $t_{PROG} = t_{PROG} \ of \ the \ last \ page + t_{PROG} \ of \ the \ previous \ page - A$ $A = (command \ input \ cycle + \ address \ input \ cycle + \ data \ input \ cycle \ time \ of \ the \ last \ page)$

If "A" exceeds the t_{PROG} of previous page, t_{PROG} of the last page is t_{PROG} max.


(Note) Make sure to terminate the operation with 80h-10h- command sequence.


If the operation is terminated by 81h-15h command sequence, monitor I/O 6 (Ready / Busy) by issuing Status Read command (70h) and make sure the previous page program operation is completed. If the page program operation is completed issue FFh reset before next operation.

Auto Block Erase Timing Diagram




Multi Block Erase Timing Diagram





NOTES:
1. For EDC operation, only one time random data input is possible at the same address.

ID Read Operation Timing Diagram



PIN FUNCTIONS

The device is a serial access memory which utilizes time-sharing input of address information.

Command Latch Enable: CLE

The CLE input signal is used to control loading of the operation mode command into the internal command register. The command is latched into the command register from the I/O port on the rising edge of the \overline{WE} signal while CLE is High.

Address Latch Enable: ALE

The ALE signal is used to control loading address information into the internal address register. Address information is latched into the address register from the I/O port on the rising edge of \overline{WE} while ALE is High.

Chip Enable: CE

The device goes into a low-power Standby mode when \overline{CE} goes High during the device is in Ready state. The \overline{CE} signal is ignored when device is in Busy state (RY/ \overline{BY} = L), such as during a Program or Erase or Read operation, and will not enter Standby mode even if the \overline{CE} input goes High.

Write Enable: WE

The WE signal is used to control the acquisition of data from the I/O port.

Read Enable: RE

The \overline{RE} signal controls serial data output. Data is available t_{REA} after the falling edge of \overline{RE} . The internal column address counter is also incremented (Address = Address + l) on this falling edge.

I/O Port: I/O1 to 8

The I/O1 to 8 pins are used as a port for transferring address, command and input/output data to and from the device.

Write Protect: WP

The \overline{WP} signal is used to protect the device from accidental programming or erasing. The internal voltage regulator is reset when \overline{WP} is Low. This signal is usually used for protecting the data during the power-on/off sequence when input signals are invalid.

Ready/Busy: RY/BY

The RY/\overline{BY} output signal is used to indicate the operating condition of the device. The RY/\overline{BY} signal is in Busy state ($RY/\overline{BY}=L$) during the Program, Erase and Read operations and will return to Ready state ($RY/\overline{BY}=H$) after completion of the operation. The output buffer for this signal is an open drain and has to be pulled-up to Vccq with an appropriate resister.


Power on Select: PSL

The PSL signal is used to select whether the device initialization should take place during the device power on or during the first Reset. Please refer to the application note (2) for details.

28

Schematic Cell Layout and Address Assignment

The Program operation works on page units while the Erase operation works on block units.



4224

A page consists of 4224 bytes in which 4096 bytes are used for main memory storage and 128 bytes are for redundancy or for other uses.

1 page = 4224 bytes

 $1\ block = 4224\ bytes \times 64\ pages = (256K + 8K)\ bytes$

Capacity = 4224 bytes \times 64pages \times 4096 blocks

An address is read in via the I/O port over five consecutive clock cycles, as shown in Table 1.

Table 1. Addressing

	I/O8	1/07	1/06	I/O5	I/O4	I/O3	I/O2	I/O1
First cycle	CA7	CA6	CA5	CA4	CA3	CA2	CA1	CA0
Second cycle	L	L	L	CA12	CA11	CA10	CA9	CA8
Third cycle	PA7	PA6	PA5	PA4	PA3	PA2	PA1	PA0
Fourth cycle	PA15	PA14	PA13	PA12	PA11	PA10	PA9	PA8
Fifth cycle	L	L	L	L	L	L	PA17	PA16

CA0 to CA12: Column address PA0 to PA17: Page address

PA6 to PA17: Block address
PA0 to PA5: NAND address in block

Operation Mode: Logic and Command Tables

The operation modes such as Program, Erase, Read and Reset are controlled by command operations shown in Table 3. Address input, command input and data input/output are controlled by the CLE, ALE, $\overline{\text{CE}}$, $\overline{\text{WE}}$, $\overline{\text{RE}}$, $\overline{\text{WP}}$ and PSL signals, as shown in Table 2.

Table 2. Logic Table

	CLE	ALE	CE	WE	RE	₩P *1	PSL ^{*3}
Command Input	Н	L	L	7	Н	*	0V/V _{CC} /NU
Data Input	L	L	L	7	Н	Н	0V/V _{CC} /NU
Address input	L	Н	L	7	Н	*	0V/V _{CC} /NU
Serial Data Output	L	L	L	Н	7	*	0V/V _{CC} /NU
During Program (Busy)	*	*	*	*	*	Н	0V/V _{CC} /NU
During Erase (Busy)	*	*	*	*	*	Н	0V/V _{CC} /NU
During Dead (Dury)	*	*	Н	*	*	*	0V/V _{CC} /NU
During Read (Busy)	*	*	L	H (*2)	H (*2)	*	0V/V _{CC} /NU
Program, Erase Inhibit	*	*	*	*	*	L	0V/V _{CC} /NU
Standby	*	*	Н	*	*	0 V/V _{CC}	0V/V _{CC} /NU

H: VIH, L: VIL, *: VIH or VIL

30

^{*1:} Refer to Application Note (10) toward the end of this document regarding the WP signal when Program or Erase Inhibit

^{*2:} If \overline{CE} is low during read busy, \overline{WE} and \overline{RE} must be held High to avoid unintended command/address input to the device or read to device. Reset or Status Read command can be input during Read Busy.

^{*3:} PSL must be tied to either 0V or V_{CC} or left unconnected(NU).

Table 3. Command table (HEX)

	First Set	Second Set	Acceptable while Busy
Serial Data Input	80	_	
Read	00	30	
Column Address Change in Serial Data Output	05	E0	
Read with Data Cache	31	_	
Read Start for Last Page in Read Cycle with Data Cache	3F	_	
Auto Page Program	80	10	
Column Address Change in Serial Data Input	85	_	
Auto Program with Data Cache	80	15	
	80	11	
Multi Page Program	81	15	
	81	10	
Read for Page Copy (2) with Data Out	00	3A	
Read for Copy-Back without Data Out	00	35	
Copy-Back Program without Data Out	85	10	
Auto Program with Data Cache during Page Copy (2)	8C	15	
Auto Program for last page during Page Copy (2)	8C	10	
Auto Block Erase	60	D0	
Page Program with 2KB Data	80 – 11	80 - 10	
Copy-Back Program with 2KB Data	85 - 11	85 - 10	
ID Read	90	_	
Status Read	70	_	0
Status Read2	F1	_	0
Status Read for Multi-Page Program or Multi Block Erase	71	_	0
Status Read for EDC *	7B	_	0
Reset	FF	_	0

^{*:} Status Read for EDC is only available on Copy Back operation.

HEX data bit assignment (Example) Serial Data Input: 80h

Table 4. Read mode operation states


	CLE	ALE	CE	WE	RE	I/O1 to I/O8	Power
Output select	L	L	L	Н	L	Data output	Active
Output Deselect	L	L	L	Н	Н	High impedance	Active

H: V_{IH}, L: V_{IL}

DEVICE OPERATION


Read Mode

Read mode is set when the "00h" and "30h" commands are issued to the Command register. Between the two commands, a start address for the Read mode needs to be issued. After initial power on sequence, "00h" command is latched into the internal command register. Therefore read operation after power on sequence is excuted by the setting of only five address cycles and "30h" command. Refer to the figures below for the sequence and the block diagram (Refer to the detailed timing chart.).




Random Column Address Change in Read Cycle

I/O1 to 8: m = 4223



Read Operation with Read Cache

The device has a Read operation with Data Cache that enables the high speed read operation shown below. When the block address changes, this sequence has to be started from the beginning.



If the 31h command is issued to the device, the data content of the next page is transferred to the Page Buffer during serial data out from the Data Cache, and therefore the tR (Data transfer from memory cell to data register) will be reduced.

- Normal read. Data is transferred from Page N to Data Cache through Page Buffer. During this time period, the device outputs Busy state for tR max.
- After the Ready/Busy returns to Ready, 31h command is issued and data is transferred to Data Cache from Page Buffer again. This data transfer takes tDCBSYR1 max and the completion of this time period can be detected by Ready/Busy signal.
- 3 Data of Page N + 1 is transferred to Page Buffer from cell while the data of Page N in Data cache can be read out by /RE clock simultaneously.
- The 31h command makes data of Page N + 1 transfer to Data Cache from Page Buffer after the completion of the transfer from cell to Page Buffer. The device outputs Busy state for tDCBSYR1 max..

 This Busy period depends on the combination of the internal data transfer time from cell to Page buffer and the serial data out time.
- 5 Data of Page N + 2 is transferred to Page Buffer from cell while the data of Page N + 1 in Data cache can be read out by /RE clock simultaneously
- The 3Fh command makes the data of Page N + 2 transfer to the Data Cache from the Page Buffer after the completion of the transfer from cell to Page Buffer. The device outputs Busy state for tDCBSYR1 max. This Busy period depends on the combination of the internal data transfer time from cell to Page buffer and the serial data out time.
- 7 Data of Page N + 2 in Data Cache can be read out, but since the 3Fh command does not transfer the data from the memory cell to Page Buffer, the device can accept new command input immediately after the completion of serial data out.

33 2009-03-09C


Multi Page Read Operation


The device has a Multi Page Read operation and Multi Page Read with Data Cache operation..

(1) Multi Page Read without Data Cache

The sequence of command and address input is shown below.

Same page address (PA0 to PA5) within each district has to be selected.





The data transfer operation from the cell array to the Data Cache via Page Buffer starts on the rising edge of WE in the 30h command input cycle (after the 2 Districts address information has been latched). The device will be in the Busy state during this transfer period.


After the transfer period, the device returns to Ready state. Serial data can be output synchronously with the RE clock from the start address designated in the address input cycle.

(2) Multi Page Read with Data Cache

When the block address changes (increments) this sequenced has to be started from the beginning.

The sequence of command and address input is shown below.

Same page address (PA0 to PA5) within each district has to be selected.



35

(3) Notes

(a) Internal addressing in relation with the Districts

To use Multi Page Read operation, the internal addressing should be considered in relation with the District.

- The device consists from 2 Districts.
- Each District consists from 2048 erase blocks.
- The allocation rule is follows.

```
District 0: Block 0, Block 2, Block 4, Block 6,..., Block 4094
District 1: Block 1, Block 3, Block 5, Block 7,..., Block 4095
```

(b) Address input restriction for the Multi Page Read operation

There are following restrictions in using Multi Page Read;

(Restriction)

Maximum one block should be selected from each District.

Same page address (PA0 to PA5) within two districts has to be selected.

For example;

```
(60) [District 0, Page Address 0x00000] (60) [District 1, Page Address 0x00040] (30)
```

(60) [District 0, Page Address 0x00001] (60) [District 1, Page Address 0x00041] (30)

(Acceptance)

There is no order limitation of the District for the address input.

For example, following operation is accepted;

```
(60) [District 0] (60) [District 1] (30)
```

(60) [District 1] (60) [District 0] (30)

It requires no mutual address relation between the selected blocks from each District.


(c) WP signal

Make sure WP is held to High level when Multi Page Read operation is performed

36

Auto Page Program Operation


The device carries out an Automatic Page Program operation when it receives a "10h" Program command after the address and data have been input. The sequence of command, address and data input is shown below. (Refer to the detailed timing chart.)



Random Column Address Change in Auto Page Program Operation

The column address can be changed by the 85h command during the data input sequence of the Auto Page Program operation.

Two address input cycles after the 85h command are recognized as a new column address for the data input. After the new data is input to the new column address, the 10h command initiates the actual data program into the selected page automatically. The Random Column Address Change operation can be repeated multiple times within the same page.




Multi Page Program


The device has a Multi Page Program, which enables even higher speed program operation compared to Auto Page Program. The sequence of command, address and data input is shown bellow. (Refer to the detailed timing chart.)

Although two planes are programmed simultaneously, pass/fail is not available for each page when the program operation completes. Status bit of I/O 1 is set to "1" when any of the pages fails. Limitation in addressing with Multi Page Program is shown below.

Multi Page Program




NOTE: Any command between 11h and 81h is prohibited except 70h/F1h and FFh.



Auto Page Program Operation with Data Cache

The device has an Auto Page Program with Data Cache operation enabling the high speed program operation shown below. When the block address changes this sequenced has to be started from the beginning.



Issuing the 15h command to the device after serial data input initiates the program operation with Data Cache

- 1 Data for Page N is input to Data Cache.
- 2 Data is transferred to the Page Buffer by the 15h command. During the transfer the Ready/Busy outputs Busy State (t_{DCBSYW2}).
- 3 Data is programmed to the selected page while the data for page N + 1 is input to the Data Cache.
- By the 15h command, the data in the Data Cache is transferred to the Page Buffer after the programming of page N is completed. The device output busy state from the 15h command until the Data Cache becomes empty. The duration of this period depends on timing between the internal programming of page N and serial data input for Page N + 1 (t_{DCBSYW2}).
- 5 Data for Page N + P is input to the Data Cache while the data of the Page N + P 1 is being programmed.
- The programming with Data Cache is terminated by the 10h command. When the device becomes Ready, it shows that the internal programming of the Page N + P is completed. NOTE: Since the last page programming by the 10h command is initiated after the previous cache program, the tPROG during cache programming is given by the following; tPROG = tPROG for the last page + tPROG of the previous page (command input cycle + address input cycle + data input cycle time of the previous page)

39 2009-03-09C


Pass/fail status for each page programmed by the Auto Page Programming with Data Cache operation can be detected by the Status Read operation.

- I/O1 : Pass/fail of the current page program operation.
- I/O2 : Pass/fail of the previous page program operation.

The Pass/Fail status on I/O1 and I/O2 are valid under the following conditions.

- Status on I/O1: Page Buffer Ready/Busy is Ready State.
 - The Page Buffer Ready/Busy is output on I/O6 by Status Read operation or RY/\overline{BY} pin after the 10h command
- Status on I/O2: Data Cache Read/Busy is Ready State.

The Data Cache Ready/Busy is output on I/O7 by Status Read operation or RY/BY pin after the 15h command.




If the Page Buffer Busy returns to Ready before the next 80h command input, and if Status Read is done during this Ready period, the Status Read provides pass/fail for Page 2 on I/O1 and pass/fail result for Page1 on I/O2


Multi Page Program with Data Cache

The device has a Multi Page Program with Data Cache operation, which enables even higher speed program operation compared to Auto Page Program with Data Cache as shown below. When the block address changes (increments) this sequenced has to be started from the beginning.

The sequence of command, address and data input is shown below. (Refer to the detailed timing chart.)




After "15h" or "10h" Program command is input to device, physical programing starts as follows. For details of Auto Program with Data Cache, refer to "Auto Page Program with Data Cache".




The data is transferred (programmed) from the page buffer to the selected page on the rising edge of /WE following input of the "15h" or "10h" command. After programming, the programmed data is transferred back to the register to be automatically verified by the device. If the programming does not succeed, the Program/Verify operation is repeated by the device until success is achieved or until the maximum loop number set in the device is reached.

Starting the above operation from 1st page of the selected erase blocks, and then repeating the operation total 64 times with incrementing the page address in the blocks, and then input the last page data of the blocks, "10h" command executes final programming. Make sure to terminate with 81h-10h- command sequence.

In this full sequence, the command sequence is following.



After the "15h" or "10h" command, the results of the above operation is shown through the "71h" Status Read command.



The 71h command Status description is as below.

	STATUS	OI	JTPUT
I/O1	Chip Status1 : Pass/Fail	Pass: 0	Fail: 1
I/O2	District 0 Chip Status1 : Pass/Fail	Pass: 0	Fail: 1
I/O3	District 1 Chip Status1 : Pass/Fail	Pass: 0	Fail: 1
I/O4	District 0 Chip Status2 : Pass/Fail	Pass: 0	Fail: 1
I/O5	District 1 Chip Status2 : Pass/Fail	Pass: 0	Fail: 1
I/O6	Ready/Busy	Ready: 1	Busy: 0
1/07	Data Cache Ready/Busy	Ready: 1	Busy: 0
I/O8	Write Protect	Protect: 0	Not Protect: 1

I/O1 describes Pass/Fail condition of district 0 and 1(OR data of I/O2 and I/O3). If one of the districts fails during multi page program operation, it shows "Fail".

I/O2 to 5 shows the Pass/Fail condition of each district. For details on "Chip Status1" and "Chip Status2", refer to section "Status Read".

Internal addressing in relation with the Districts

To use Multi Page Program operation, the internal addressing should be considered in relation with the District.

- The device consists from 2 Districts.
- Each District consists from 2048 erase blocks.
- The allocation rule is follows.

```
District 0: Block 0, Block 2, Block 4, Block 6,..., Block 4094
District 1: Block 1, Block 3, Block 5, Block 7,..., Block 4095
```

Address input restriction for the Multi Page Program with Data Cache operation

There are following restrictions in using Multi Page Program with Data Cache;

(Restriction)

Maximum one block should be selected from each District.

Same page address (PA0 to PA5) within two districts has to be selected.

For example;

```
(80) [District 0, Page Address 0x00000] (11) (81) [District 1, Page Address 0x00040] (15 or 10) (80) [District 0, Page Address 0x00001] (11) (81) [District 1, Page Address 0x00041] (15 or 10)
```

(Acceptance)

There is no order limitation of the District for the address input.

For example, following operation is accepted;

```
(80) [District 0] (11) (81) [District 1] (15 or 10)
```

(80) [District 1] (11) (81) [District 0] (15 or 10)

It requires no mutual address relation between the selected blocks from each District.

Operating restriction during the Multi Page Program with Data Cache operation

(Restriction)


The operation has to be terminated with "10h" command.


Once the operation is started, no commands other than the commands shown in the timing diagram is allowed to be input except for Status Read command and reset command.



Page Copy (2)

By using Page Copy (2), data in a page can be copied to another page after the data has been read out. When the block address changes (increments) this sequenced has to be started from the beginning.







Page Copy (2) operation is as following.

- 1 Data for Page N is transferred to the Data Cache.
- 2 Data for Page N is read out.
- 3 Copy Page address M is input and if the data needs to be changed, changed data is input.
- 4 Data Cache for Page M is transferred to the Page Buffer.
- 5 After the Ready state, Data for Page N + P1 is output from the Data Cache while the data of Page M is being programmed.


44 2009-03-09C






- 6 Copy Page address (M + R1) is input and if the data needs to be changed, changed data is input.
- 7 After programming of page M is completed, Data Cache for Page M + R1 is transferred to the Page Buffer.
- 8 By the 15h command, the data in the Page Buffer is programmed to Page M + R1. Data for Page N + P2 is transferred to the Data cache.
- 9 The data in the Page Buffer is programmed to Page M + Rn 1. Data for Page N + Pn is transferred to the Data Cache.

45 2009-03-09C





- 10 Copy Page address (M + Rn) is input and if the data needs to be changed, changed data is input.
- 11 By issuing the 10h command, the data in the Page Buffer is programmed to Page M + Rn.
- (*1) Since the last page programming by the 10h command is initiated after the previous cache program, the tpROG here will be expected as the following, tpROG = tpROG of the last page + tPROG of the previous page (command input cycle + address input cycle + data output/input cycle time of the last page)

NOTE) This operation needs to be executed within District-0 or District-1.

Data input is required only if previous data output needs to be altered.

If the data has to be changed, locate the desired address with the column and page address input after the 8Ch command, and change only the data that needs be changed. If the data does not have to be changed, data input cycles are not required.


Make sure WP is held to High level when Page Copy (2) operation is performed.

Also make sure the Page Copy operation is terminated with 8Ch-10h command sequence




Multi Page Copy (2)

By using Multi Page Copy (2), data in two pages can be copied to another pages after the data has been read out. When the each block address changes (increments) this sequenced has to be started from the beginning. Same page address (PA0 to PA5) within two districts has to be selected.



47 2009-03-09C



(*1) tpROG: Since the last page programming by 10h command is initiated after the previous cache program, the tpROG* during cache programming is given by the following equation.

tPROG (*1)

tprog = tprog of the last page + tprog of the previous page-A

Address

CA0 to CA12, PA0 to PA17 (Page N63; District 1)

G

A = (command input cycle + address input cycle + data output/input cycle time of the last page) If "A" exceeds the tpROG of previous page, tpROG of the last page is tpROG max.

Note)

This operation needs to be executed within each District.

Data input is required only if previous data output needs to be altered.


If the data has to be changed, locate the desired address with the column and page address input after the 8Ch command, and change only the data that needs be changed.

If the data does not have to be changed, data input cycles are not required.

Make sure $\overline{\text{WP}}$ is held to High level when Multi Page Copy (2) operation is performed. Also make sure the Multi Page Copy operation is terminated with 8Ch-10h command sequence


Auto Block Erase

The Auto Block Erase operation starts on the rising edge of \overline{WE} after the Erase Start command "D0h" which follows the Erase Setup command "60h". This two-cycle process for Erase operations acts as an extra layer of protection from accidental erasure of data due to external noise. The device automatically executes the Erase and Verify operations.



Multi Block Erase

The Multi Block Erase operation starts by selecting two block addresses before D0h command as in below diagram. The device automatically executes the Erase and Verify operations and the result can be monitored by checking the status by 71h status read command. For details on 71h status read command, refer to section "Multi Page Program with Data Cache".



Internal addressing in relation with the Districts

To use Multi Block Erase operation, the internal addressing should be considered in relation with the District.

- The device consists from 2 Districts.
- Each District consists from 2048 erase blocks.
- The allocation rule is follows.

District 0: Block 0, Block 2, Block 4, Block 6,..., Block 4094 District 1: Block 1, Block 3, Block 5, Block 7,..., Block 4095

Address input restriction for the Multi Block Erase

There are following restrictions in using Multi Block Erase

(Restriction)

Maximum one block should be selected from each District.

For example;

(60) [District 0] (60) [District 1] (D0)

(Acceptance)

There is no order limitation of the District for the address input.

For example, following operation is accepted;

(60) [District 1] (60) [District 0] (D0)

It requires no mutual address relation between the selected blocks from each District.

Make sure to terminate the operation with D0h command. If the operation needs to be terminated before D0h command input, input the FFh reset command to terminate the operation.


Copy Back Program without Data Out

By using Copy Back Program, data in a page can be copied to another page without serial data output. The device executes EDC of itself during tPROG. After the start of program process, the Status Read command (70h/F1h) or Read EDC Status command (7Bh) may be entered to read out the device status. When the Copy Back Program operation is complete, Bits (I/O $2\sim$ I/O 3) for EDC Status may be checked. The internal EDC can check whether there is only 1-bit error for each 528-byte sector of the source page. More than 2-bit error detection is not utilizable for each 528-byte sector.

During Copy Back Program, data modification is possible by using random data input command (85h). But EDC status bits are not utilizable during copy back program for some bits or bytes modified by Random Data Input operation.


However, EDC status bits are available in case of the 528 byte sector unit modification.

Copy Back Program Operation



NOTE: 1. Copy Back program operation is allowed only within the same district.

Copy Back Program Operation with Random Data Input




NOTE: 1. For EDC operation, only one time random data input is available at the same address.


EDC Operation

Note that for the user who use Copy-Back with EDC mode, only one time random data input is available at the same address during Copy-Back program or page program mode. For the user who Copy-Back without EDC, there is no limitation for the random data input at the same address.

Copy-Back Program Operation with EDC & Read EDC Status




Multi Page Copy-Back Program Operation with EDC & Read EDC Status



2KB Program Operation Timing Guide


The device is designed also to support the program operation with 2KByte data to offer the backward compatibility to the controller which uses the NAND Flash with 2KByte page. The sequence of command, address and data input is shown below.

(2KBx2) Program Operation



NOTE: 1. Any command between 11h and 81h is prohibited except 70h/F1h and FFh


(2KBx2) Copy-Back



NOTE: 1. Copy-Back is allowed only within the same memory district.

2. Any command between 11h and 81h is prohibited except 70h/F1h and FFh.

(2KBx2) Copy-Back with Random Data Input




NOTE: 1. Copy-Back is allowed only within the same memory district.


2. Any command between 11h and 81h is prohibited except 70h/F1h and FFh.

Multi Page Copy-Back using 4KB Buffer RAM

The deveice consists of 4KB pages and can support Multi Plane program operation. The internal RAM requirement for a controller is 8KB, but for those controllers which support less than 8KB RAM, the sequence of command, address and data input is shown below for Multi Plane program operation.



Multi Page Copy-Back with Random Data Input



NOTE: 1. Copy-Back is allowed only within the same memory district.



ID Read

The device contains ID codes which can be used to identify the device type, the manufacturer, and features of the device. The ID codes can be read out under the following timing conditions:

TOSHIBA CONFIDENTIAL




Table 5. Code table

	Description	I/O8	1/07	I/O6	I/O5	I/O4	I/O3	I/O2	I/O1	Hex Data
1st Data	Maker Code	1	0	0	1	1	0	0	0	98h
2nd Data	Device Code	1	1	0	1	0	0	1	1	D3h
3rd Data	Chip Number, Cell Type	_	_	_	_	_	_	_	_	See table
4th Data	Page Size, Block Size	—	_		_	—	_	_	_	See table
5th Data	Plane Number			_			_	_	_	See table

3rd Data

	Description	I/O8	1/07	I/O6	I/O5	I/O4	I/O3	I/O2	I/O1
Internal Chip Number	1 2 4 8							0 0 1 1	0 1 0 1
Cell Type	2 level cell 4 level cell 8 level cell 16 level cell					0 0 1 1	0 1 0 1		

TOSHIBA CONFIDENTIAL

4th Data

	Description	I/O8	1/07	1/06	I/O5	I/O4	I/O3	1/02	I/O1
Page Size (without redundant area)	1 KB 2 KB 4 KB 8 KB							0 0 1 1	0 1 0 1
Block Size (without redundant area)	64 KB 126 KB 256 KB 512 KB			0 0 1 1	0 1 0 1				

5th Data

	Description	I/O8	1/07	I/O6	I/O5	I/O4	I/O3	I/O2	I/O1
Plane Number	1 Plane 2 Plane 4 Plane 8 Plane					0 0 1 1	0 1 0 1		



Status Read

The device automatically implements the execution and verification of the Program and Erase operations. The Status Read function is used to monitor the Ready/Busy status of the device, determine the result (pass /fail) of a Program or Erase operation, and determine whether the device is in Protect mode. The device status is output via the I/O port using $\overline{\text{RE}}$ or $\overline{\text{CE}}$ after a "70h" or "F1h" command input. This two signal control allows the system to poll the progress of each device in multiple memory connections even when Ready/Busy pins are common-wired. The Status Read can also be used during a Read operation to find out the Ready/Busy status. The resulting information is outlined in Table 6 and Tabel 7.

Table 6. Status output table

	Definition	Page Program Block Erase	Cache Program	Read Cache Read
I/O1	Chip Status1 Pass: 0 Fail: 1	Pass/Fail	Pass/Fail	Invalid
I/O2	Chip Status 2 Pass: 0 Fail: 1	Invalid	Pass/Fail	Invalid
I/O3	Not Used	0	0	0
1/04	Not Used	0	0	0
I/O5	Not Used	0	0	0
1/06	Page Buffer Ready/Busy Ready: 1 Busy: 0	Ready/Busy	Ready/Busy	Ready/Busy
1/07	Data Cache Ready/Busy Ready: 1 Busy: 0	Ready/Busy	Ready/Busy	Ready/Busy
I/O8	Write Protect Not Protected :1 Protected: 0	Write Protect	Write Protect	Write Protect

The Pass/Fail status on I/O1 and I/O2 is only valid during a Program/Erase operation when the device is in the Ready state.

Chip Status 1:

During a Auto Page Program or Auto Block Erase operation this bit indicates the pass/fail result. During a Auto Page Programming with Data Cache operation, this bit shows the pass/fail results of the current page program operation, and therefore this bit is only valid when I/O6 shows the Ready state.

Chip Status 2:


This bit shows the pass/fail result of the previous page program operation during Auto Page Programming with Data Cache. This status is valid when I/O7 shows the Ready State.

The status output on the I/O6 is the same as that of I/O7 if the command input just before the 70h is not 15h or 31h.

Tabel 7: F1h Read Status Register Definition

	Definition	Page Program	Block Erase	Read
I/O 1	Pass : "0", Fail : "1"	Pass/Fail	Pass/Fail	Not use
I/O 2	Pass : "0", Fail : "1"	Plane0 Pass/Fail	Plane0 Pass/Fail	Not use
I/O 3	Pass : "0", Fail : "1"	Plane1 Pass/Fail	Plane1 Pass/Fail	Not use
I/O 4	Don't-cared	Not use	Not use	Not use
I/O 5	Don't-cared	Not use	Not use	Not use
I/O 6	Don't-cared	Not use	Not use	Not use
I/O 7	Busy : "0", Ready : "1"	Ready/Busy	Ready/Busy	Ready/Busy
I/O 8	Protected: "0", Not Protected: "1"	Write Protect	Write Protect	Write Protect

An application example with multiple devices is shown in the figure below.



System Design Note: If the RY/\overline{BY} pin signals from multiple devices are wired together as shown in the diagram, the Status Read function can be used to determine the status of each individual device.


Reset

The Reset mode stops all operations. For example, in case of a Program or Erase operation, the internally generated voltage is discharged to 0 volt and the device enters the Wait state.


Reset during a Cache Program/Page Copy may not just stop the most recent page program but it may also stop the previous program to a page depending on when the FF reset is input.

The response to a "FFh" Reset command input during the various device operations is as follows:


When a Reset (FFh) command is input during programming




When a Reset (FFh) command is input during erasing




When a Reset (FFh) command is input during Read operation




When a Reset (FFh) command is input during Ready



When a Status Read command (70h) is input after a Reset



When two or more Reset commands are input in succession



59

Read EDC Status

Read EDC status operation is only utilizable on 'Copy Back Program'. The device contains an EDC Status Register which may be read to find out whether there is error during 'Read for Copy Back Program'. The device status is output via the I/O port using $\overline{\text{RE}}$ or $\overline{\text{CE}}$ after a "7Bh" command input. This two signal control allows the system to poll the progress of each device in multiple memory connections even when Ready/Busy pins are common-wired. The status Read can also be used during a Read operation to find out the Ready/Busy status.

The resulting information is shown in the figure below.

Status Register Definition for 7Bh Command

I/O	Copy-Back	Page Program	Block Erase	Read	Definition
I/O 1	Pass/Fail of Copy-Back	Pass/Fail	Pass/Fail	Not use	Pass : "0", Fail : "1"
I/O 2	EDC Status	Not use	Not use	Not use	No Error : "0", Error : "1"
I/O 3	Validity of EDC Status	Not use	Not use	Not use	Valid : "1", Invalid : "0"
I/O 4	Not use	Not use	Not use	Not use	Don't-cared
I/O 5	Not use	Not use	Not use	Not use	Don't-cared
I/O 6	Not use	Not use	Not use	Not use	Don't-cared
I/O 7	Ready/Busy of Copy-Back	Ready/Busy	Ready/Busy	Ready/Busy	Busy : "0", Ready : "1"
I/O 8	Write Protect of Copy-Back	Write Protect	Write Protect	Write Protect	Protected: "0", Not Protected: "1"

Only 1-bit error detection is available for each 528 Byte sector

More than 2-bit error detection isn't available for each 528 Byte sector.

Copy-Back Operation with EDC and Sector Definition for EDC

In general, copy-back program is powerful to move data stored in a page without using any external memory. But, if the source page has one bit error, then without EDC, the copy-back program operation could also accumulate bit errors.

This device supports copy-back with EDC to prevent cumulative bit errors. In order to make EDC valid, the page program operation should be performed on either whole page (4224byte) or sector (528byte). Modifying the data of a sector by Random Data Input before copy-back program must be performed for the whole sector and is allowed only once per each sector. Any partial modification smaller than a sector corrupts the on-chip EDC codes.

A 4224byte page consists of 8 sectors of 528byte and each 528byte sector consists of 512byte main area and 16byte spare area.

ŀ	Main Area (4096byte)							Spare Area (128byte) ▶ ✓						→		
	area "A" (1st)	area "B" (2nd)	area "C" (3rd)	area "D" (4th)	area "E" (5th)	area "F" (6th)	area "G" (7th)	area "F" (8th)	"I" 1st	"J" 2nd	"K" 3rd	"L" 4th	"M" 5th	"N" 6th	"O" 7th	"P" 8th
	512B	16B														

Definition of the 528Byte Sector

Demintion of the 020B	J					
Sector	Main Area (Co	olumn 0 – 4095)	Spare Area (Column 4096 – 4223)			
Sector	Area Name	Area Name Column Number		Column Number		
1st 528Byte sector	"A"	0 - 511	"I"	4096 - 4111		
2nd 528Byte sector	"B"	512 - 1023	"J"	4112 - 4127		
3rd 528Byte sector	"C"	1024 - 1535	"K"	4128 - 4143		
4th 528Byte sector	"D"	1536 - 2047	"L"	4144 – 4159		
5th 528Byte sector	"E"	2048 - 2559	"M"	4160 - 4175		
6th 528Byte sector	"F"	2560 - 3071	"N"	4176 - 4191		
7th 528Byte sector	"G"	3072 - 3583	"O"	4192 - 4207		
8th 528Byte sector	"H"	3584 - 4095	"P"	4208 - 4223		


APPLICATION NOTES AND COMMENTS

(1) Power-on/off sequence:

The timing sequence shown in the figure below is necessary for the power-on/off sequence.

The device internal initialization starts after the power supply reaches an appropriate level in the power on sequence. During the initialization the device Ready/Busy signal indicates the Busy state as shown in the figure below. In this time period, the acceptable commands are FFh or 70h/F1h.

The WP signal is useful for protecting against data corruption at power-on/off.



(2) Power-on Reset

The device goes into automatic self-initialization during power on if PSL is tied either to GND or NU. During the initialization process, the device consumes a maximum current of 30mA (I_{CCO0}). If PSL is tied to V_{CC} , the device will not complete its self-initialization during power on and will not consume I_{CCO0} , and completes the initialization process with the first Reset command input after power on. During the first FFh reset Busy period, the device consumes a maximum current of 30mA (I_{CCO0}). In either case (PSL = GND/NU or V_{CC}), The following sequence is necessary because some input signals may not be stable at power-on.



(3) Prohibition of unspecified commands


The operation commands are listed in Table 3. Input of a command other than those specified in Table 3 is prohibited. Stored data may be corrupted if an unknown command is entered during the command cycle.

(4) Restriction of commands while in the Busy state


During the Busy state, do not input any command except 70h(71h, F1h) and FFh.

(5) Acceptable commands after Serial Input command "80h"

Once the Serial Input command "80h" has been input, do not input any command other than the Column Address Change in Serial Data Input command "85h", Auto Program command "10h", Multi Page Program command "11h", Auto Program with Data Cache Command "15h", or the Reset command "FFh".





If a command other than "85h", "10h", "11h", "15h" or "FFh" is input, the Program operation is not performed and the device operation is set to the mode which the input command specifies.




(6) Addressing for program operation

Within a block, the pages must be programmed consecutively from the LSB (least significant bit) page of the block to MSB (most significant bit) page of the block. Random page address programming is prohibited.






Status Read during a Read operation




The device status can be read out by inputting the Status Read command "70h" in Read mode. Once the device has been set to Status Read mode by a "70h" command, the device will not return to Read mode unless the Read command "00h" is inputted during [A]. If the Read command "00h" is inputted during [A], Status Read mode is reset, and the device returns to Read mode. In this case, data output starts automatically from address N and address input is unnecessary

(8)Auto programming failure



RY/\overline{BY} : termination for the Ready/Busy pin (RY/\overline{BY}) (9)


A pull-up resistor needs to be used for termination because the RY/\overline{BY} buffer consists of an open drain circuit.




(10) Note regarding the \overline{WP} signal

The Erase and Program operations are automatically reset when \overline{WP} goes Low. The operations are enabled and disabled as follows:


Enable Programming




Disable Programming



Enable Erasing




Disable Erasing



(11) When six address cycles are input

Although the device may read in a sixth address, it is ignored inside the chip.




(12) Several programming cycles on the same page (Partial Page Program)

Each segment can be programmed individually as follows:

1st programming	Data Pattern 1		All 1 s		
2nd programming	All 1 s	Data Pattern 2		All 1 s	
			I !		
			İ		
4th programming		All 1 s	5		Data Pattern 4
Result	Data Pattern 1	Data Pattern 2			Data Pattern 4

(13) Invalid blocks (bad blocks)

The device occasionally contains unusable blocks. Therefore, the following issues must be recognized:



Please do not perform an erase operation to bad blocks. It may be impossible to recover the bad block information if the information is erased.

Check if the device has any bad blocks after installation into the system. Refer to the test flow for bad block detection. Bad blocks which are detected by the test flow must be managed as unusable blocks by the system.


A bad block does not affect the performance of good blocks because it is isolated from the bit lines by select gates.

The number of valid blocks over the device lifetime is as follows:

	MIN	TYP.	MAX	UNIT
Valid (Good) Block Number	4016	_	4096	Block

Bad Block Test Flow

Regarding invalid blocks, bad block mark is in either the 1st or the 2nd page.



*1: No erase operation is allowed to detected bad blocks

(14) Failure phenomena for Program and Erase operations


The device may fail during a Program or Erase operation.

The following possible failure modes should be considered when implementing a highly reliable system.

FAILURE MODE		DETECTION AND COUNTERMEASURE SEQUENCE
Block	Erase Failure	Status Read after Erase → Block Replacement
Page	Programming Failure	Status Read after Program → Block Replacement
Single Bit	Programming Failure "1 to 0"	ECC

- ECC: Error Correction Code. TBD bit correction per 528Bytes is necessary.
- Block Replacement

Program



When an error happens in Block A, try to reprogram the data into another Block (Block B) by loading from an external buffer. Then, prevent further system accesses to Block A (by creating a bad block table or by using another appropriate scheme).

Erase

When an error occurs during an Erase operation, prevent future accesses to this bad block (again by creating a table within the system or by using another appropriate scheme).

- (15) Do not turn off the power before write/erase operation is complete. Avoid using the device when the battery is low. Power shortage and/or power failure before write/erase operation is complete will cause loss of data and/or damage to data.
- (16) The number of valid blocks is on the basis of single plane operations, and this may be decreased with two plane operations.

(17) Reliability Guidance

This reliability guidance is intended to notify some guidance related to using NAND flash with TBD bit ECC for each 512 bytes. For detailed reliability data, please refer to TOSHIBA's reliability note. Although random bit errors may occur during use, it does not necessarily mean that a block is bad. Generally, a block should be marked as bad when a program status failure or erase status failure is detected. The other failure modes may be recovered by a block erase.

ECC treatment for read data is mandatory due to the following Data Retention and Read Disturb failures.

Write/Erase Endurance

Write/Erase endurance failures may occur in a cell, page, or block, and are detected by doing a status read after either an auto program or auto block erase operation. The cumulative bad block count will increase along with the number of write/erase cycles.

• Data Retention

Read Disturb


The data in memory may change after a certain amount of storage time. This is due to charge loss or charge gain. After block erasure and reprogramming, the block may become usable again.

Here is the combined characteristics image of Write/Erase Endurance and Data Retention.



A read operation may disturb the data in memory. The data may change due to charge gain. Usually, bit errors occur on other pages in the block, not the page being read. After a large number of read cycles (between block erases), a tiny charge may build up and can cause a cell to be soft programmed to another state. After block erasure and reprogramming, the block may become usable again.

Package Dimensions



Weight: 0.53g (typ.)



Revision History

Date	Rev.	Description
2008-11-27	1.00	Original version
2009-01-07	1.01	Description for PSL is added.
2009-02-03	1.02	tCOH is added and tCHZ is changed from 20ns to 30ns.
2009-03-09	1.03	Descriptions of APPLICATION NOTES AND COMMENTS (5) and (7) are changed.
		Part Number is changed from TC58NVG3S0ETA00 to TC58DVG3S0ETA00.

RESTRICTIONS ON PRODUCT USE

060915EBA R6

- The information contained herein is subject to change without notice. 021023_D
- TOSHIBA is continually working to improve the quality and reliability of its products. Nevertheless, semiconductor devices in general can malfunction or fail due to their inherent electrical sensitivity and vulnerability to physical stress. It is the responsibility of the buyer, when utilizing TOSHIBA products, to comply with the standards of safety in making a safe design for the entire system, and to avoid situations in which a malfunction or failure of such TOSHIBA products could cause loss of human life, bodily injury or damage to property. In developing your designs, please ensure that TOSHIBA products are used within specified operating ranges as set forth in the most recent TOSHIBA products specifications. Also, please keep in mind the precautions and conditions set forth in the "Handling Guide for Semiconductor Devices," or "TOSHIBA Semiconductor Reliability Handbook" etc. 021023_A
- The TOSHIBA products listed in this document are intended for usage in general electronics applications (computer, personal equipment, office equipment, measuring equipment, industrial robotics, domestic appliances, etc.). These TOSHIBA products are neither intended nor warranted for usage in equipment that requires extraordinarily high quality and/or reliability or a malfunction or failure of which may cause loss of human life or bodily injury ("Unintended Usage"). Unintended Usage include atomic energy control instruments, airplane or spaceship instruments, transportation instruments, traffic signal instruments, combustion control instruments, medical instruments, all types of safety devices, etc. Unintended Usage of TOSHIBA products listed in this document shall be made at the customer's own risk. 021023_B
- The products described in this document shall not be used or embedded to any downstream products of which manufacture, use and/or sale are prohibited under any applicable laws and regulations. 060106_Q
- The information contained herein is presented only as a guide for the applications of our products. No responsibility is assumed by TOSHIBA for any infringements of patents or other rights of the third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of TOSHIBA or others. 021023_C
- Please use this product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances.
 - Toshiba assumes no liability for damage or losses occurring as a result of noncompliance with applicable laws and regulations. 060819_AF
- The products described in this document are subject to the foreign exchange and foreign trade laws. 021023_E

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Toshiba:

```
TH58NVG3S0HBAI4 TH58BVG3S0HTAI0 TH58BYG3S0HBAI6 TC58NYG2S3EBAI5 TC58NYG2S0HBAI4

TC58DVG3S0ETA00 TH58BVG2S3HBAI4 TH58NYG2S3HBAI4 TH58DVG5S0ETA2 THGBMHG9C4LBAIR

THGBMHG8C2LBAIL THGBMHG6C1LBAIL THGBMDG5D1LBAIT THGBMHG7C1LBAIL TC58CVG1S3HQAIE

THGBMHG7C2LBAU7 THGBMFT0C8LBAIG THGAF4G9N4LBAIR THGBMGT0T8LBAIG THGBMHG9C8LBAU8

TC58CVG1S3HRAIG THGBMDG5D1LBAIL THGAF4T0N8LBAIR TC58CVG2S0HQAIE TH58NVG4S0HTAK0

TC58CVG0S3HQAIE THGAF4G8N2LBAIR TC58CVG0S3HRAIG TC58CVG2S0HRAIG THGBMFG6C1LBAIL

THGBMFG7C1LBAIL TC58CYG0S3HQAIE THGBMHG8C4LBAU7 TC58CYG0S3HRAIG THGBMHG6C1LBAU6

THGBMFG9C4LBAIR TC58CYG1S3HRAIG
```