

## VIDEO MOD 32


PLEASE NOTE: Any modification to your system will void your factory warranty.

Please read the instructions over and check the diagrams. If you are not sure that you are capable of making the necessary changes please do not attempt to do so. For a few dollars more you can send your board in to the dealer listed in the catalog and be assured of having the changes done correctly.

Use sockets on all chips for ease of repair.

Use insulated jumpers only.

If you do not have a crystal with the correct frequency, a 12.0 Mhz crystal can be used with an adjustable capacitor across it to lower the frequency to 11.8 Mhz or as close to it as possible. Another way of doing it is to replace the 7400 chip 'U58' with a 7414 hex schmitt trigger. You can also use this chip to replace the 7404 'U72' chip. The pin outs are the same for both 7414 and 7404 so you can connect to the same pins. Make sure you cut the foil between pins 12 & 13 and pins 9 & 10 & 11 and between pins 1 & 2 & 8 where the 7400 chip 'U58' used to be. Hook in the connections that used to go to 'U72' 7404 chip. Then add this circuit and adjust C and L to give you 11.8 Mhz.



This oscillator circuit should be stable within  $\pm 2\%$  which should give a stable display.


Copyright: Progressive Computing.

I recommend that you make the 32 chr/line Mod. first and then see if you wish to go to 64 chr/line.

NOTE: For 64 chr/line you must add an extra 1K of video memory. The easiest way is to piggy back it to the original 1K. You can solder them pin for pin EXCEPT for the chip select pin. This must be bent out and hooked to CE1 output of U55 pin 12. I do not recommend 64 chr/line because this will not be compatible with the C1P video format.

PLEASE NOTE: Keep referring to the circuit diagrams. Check to make sure that ALL +5 and ground connections have been made on the added components.

1. It is necessary to remove U59 and U56. On the component side, make a foil cut between pin 1 and pin 9 of U59. Make a foil cut between the foil that connects pins 9, 10 and 12 to isolate pin 12 of U56.



Replace U59 and U56 using sockets. Cut foil on U59 between pin 1 and the 1K resistor. Put a jumper between the 1K resistor and pin 9 on the foil side. Also hook a jumper from the 1K resistor to pin 1 of U60.

2. Solder in the sockets for U26, U27, U28, U29 and U44.

- PIGGY BACK 3. CAREFULLY bend out pins 10 through 15 of a 74163 on a right angle. Then solder pins 1 through 9 and pin 16 to U59. In other words pin 1 of U71 to pin 1 of U59 etc. Jumper pin 15 of U59 to pin 10 of U71. **MAKE SURE THERE ARE NO SHORTS!** This will be U71. See below.\*

- PIGGY BACK 4. Bend pins 1 through 6, and 8 through 13 of a 7404 at a right angle. Solder pin 7 to pin 7 of U18 and pin 14 to pin 14 of U18. This will be U72.




5. Replace X1 with a 11.8 Mhz crystal.

6. MAKE ALL POWER (+5V) and ground connections to U26, U27, U28 and U44.

	+5 pin	Ground pin
7420 U26	14	7
7474 U27	14	7
74163 U28	16	8
7493 U44	5	10

Then make the rest of the ground and +5 VCC connections as shown in the diagrams.


Remember when working on the foil side, pin locations are flipped like so:




\* Bend pin on a right angle.

7. Lets make the rest of the foil cuts. On the component side cut the foil that goes under the 0.1  $\mu$ f. capacitor between U61 and U62.

This foil goes to pins 7 of U61 and U60 and U59.




Turn the board over and make the following cuts:




Underneath the R58 5K variable resistor cut where marked. This will isolate pin 9 of U65.

Between U30 and U19 cut where indicated. This isolates  $\phi_0$  in (CPU Clock)




Between U61 and U55 cut two places as shown:

One cuts the lead to pin 2 of U61 and U60.  
The other cuts pin 2 of U57 (baud rate).




Under U30 cut as shown to free pin 1 of U30:

NOTE: Some boards may need to be cut where circled. Then JUMPER as marked.



Under U59:



Cut foil to free pin 1  
Cut foil to free pin 2  
Cut foil to free pin 15  
Cut foil to free pin 10 but keep pins 10 and 7 connected.

All foil cutting is now done.

8. Now for the rest of the wiring. FROM THE FOIL SIDE UNLESS INDICATED! Hook up the rest of the connections as shown on the Addition diagrams for the signal paths. - Pin 8 of U29 to pin 14 of U44.

- Pin 9 of U44 to pin 2 of U28 and to pin 2 of U60.

NOTE: Pin 2 of U60 and U61 should still be connected together.

You should have hooked up the column clock addition when you piggy backed U71 on top of U59. Connect pin 1 of U44 to pin 12 of U44.

- Hook pin 2 of U30 to pin 2 of U59.

For the blanking circuit: Finish wiring the signal paths.

- Pin 11 of U28 to pin 1 of U72 --from the component side.

- Pin 12 of U28 to pin 3 of U72 --from the component side.

- Pin 13 of U28 to pin 4 of U26.

- Pin 14 of U28 to pin 5 of U26.

- Pin 2 of U72 to pin 1 of U26 --from the component side.

- Pin 4 of U72 to pin 2 of U26 --from the component side.

- Pin 6 of U26 to pin 4 of U27.

- Pin 5 of U27 to pin 12 of U56.

- Pin 6 of U27 to pin 10 of U27.

- Pin 14 of U71 to pins 9&10 of U26 --from the component side.

- Pin 11 of U30 to pin 12&13 of U26.

- Pin 8 of U26 to pin 1 of U27.

- Pin 12 of U65 to pin 13 of U27.

- Pin 8 of U27 to pin 5 of U72 --from the component side.

- Pin 6 of U72 to pin 1 of U30 and to pin 1 of U59 --from the comp. side.

- Pin 1 of U71 should automatically be hooked.

- Make sure pins 2 & 3 & 11 & 12 of U27 are grounded.

- Make sure of the other ground and +5V connections on the other IC's.

#### NOW TO FINISH THE JOB:

If you plan to use rotary switches to be able to change CPU clock rates and also baud rates then do the following:



Make sure you use non-shorting rotary switches:

**SPDT** - Hook pin 8 of U29 to one of the outside contacts.

- Hook pin 9 of U29 to the next contact.

~~Hook pin 11 of U29 to the next contact.~~

- Hook a wire from the center contact (common) of the switch to the foil as marked between U29 and U18.




- Jumper pin 1 of U29 to pin 12 of U29.

If you do not want to switch CPU clocks then jumper in pin 8 or pin 9 of U29 to the foil as marked.

For baud rate: If you use a switch then hook in pin 14 of U44, pin 12 of U44, pin 9 of U44 and pin 8 of U44 to the switch. Hook a wire from the common center terminal of the switch to pin 2 of U57. If you don't use a switch, hook pin 8 of U44 to pin 2 of U57. It will give you 300 baud.

**SP4T** - Jumper as shown and connect jumper to pin 15 of U28.



- Connect pin 7 of U59 to pin 15 of U30.

- Jumper pin 11 of U28 to pin 9 of U65 to give you horizontal sync.

To be safe go back over your wiring. Make sure of your connections and check to make sure you have no shorts between foils anywhere.

Now hook the board to power and connect the J2 connector and turn on the power. You should see random characters on the screen, 32 per line. When you break you will see D/C/W/M? but it will not be on the edge of the screen. Note: You may have to adjust your horizontal hold. If you do not get a stable picture but you do get something on the screen but it seems to be random dots then the column clear circuit is not hooked in properly and/or you have a problem in the horizontal sync circuit. If all you get is a clear screen then the blanking circuit is not working properly.

The CRT driver routine in basic will only allow 24 chr/line so this routine would require changes to allow 32 chr/line. Also the cursor can be lowered 2 lines and its home brought out to the edge of the screen. If you ordered the video mod. kit then you received a cassette with the necessary routines to allow all this plus backspace and rapid screen erase etc. All you have to do is load in the tape, type RUN then type NEW when the cursor moves out to the edge of the screen and 2 lines down. The program is loaded into the first 3 pages of memory so it will not take up any basic memory. The program will work so long as you don't hit the break key. If you do break then the I/O vectors will have to be reloaded to point to this program. If you use poke statements to generate your video screen then no CRT driver is needed.

Enjoy your new video. The new ROM MONITOR which should be ready in late July /80 should allow all the new features of your video as well as have an auto-load routine for saving machine code as well as a disassembler so you can have them without having to load tapes.

#### PARTS LIST

1-7400

2-74163 or 74161

1-7404

1-11.8 Mhz crystal

1-7420

5-14 pin sockets

1-7474

2-16 pin sockets

1-7492

1-7493

Single strand hook up wire (insulated). (not supplied)

For 64 chr/line the memory chips are not supplied.


NOTE: IT IS PREFERABLE THAT YOU USE 74LS series chips to reduce power consumption.

Also if 74LS163 are not available 74LS161 can be used. Your Radio Shack store should have these. If you don't use a crystal then replace 74LS04 with a 74LS14 hex schmitt trigger IC and refer to the instructions for hooking up.

6  
64 CHARACTER MODIFICATION ADDITION TO VIDEO MOD.

IF YOU ARE GOING TO USE THE SWITCHABLE 32 AND 64 CHR/LINE THEN MAKE THE FOIL CUTS AND JUMPER CONNECTION SHOWN BELOW.


- Make sure pin 1 of U29 is hooked to pin 12 of U29.



USE A DPDT SWITCH TO SWITCH BETWEEN 32 AND 64 CHARACTERS PER LINE.



- PIN 12 of U29
- PIN 2 of U30
- PIN 14 of U29

**Foil Side**






- Remove the jumper that goes from pin 14 of U71 to pin 9 of U26.

- YOU MUST ADD ONE MORE CHIP A 7400 CALL IT U73 THIS CHIP CAN BE ADDED BY PIGGY BACKING IT TO U58 START BY BENDING ALL PINS AT A RIGHT ANGLE EXCEPT PINS SEVEN AND FOURTEEN (7 & 14) THESE YOU CAN SOLDER TO PINS SEVEN AND FOURTEEN OF U58 REFER TO AN EARLIER DIAGRAM IN THE INSTRUCTIONS ON THE 32 CHARACTER VIDEO MOD. IF YOU ARE NOT SURE OF HOW TO BEND THESE PINS CUT THE FOIL GOING TO PIN 11 OF U55 THIS IS THE NOT #2 LINE WHEN YOU HAVE THIS CHIP MOUNTED REFER TO THE DIAGRAM Below AND MAKE THESE CONNECTIONS:




- ON U20 CUT ADDRESS LINE NOT A10 GOING TO PIN 2 AND SOLDER PIN 1 AND 2 TOGETHER.
- ON U56 CUT ADDRESS LINE NOT A10 GOING TO PIN 2 AND SOLDER PIN 1 AND 2 TOGETHER.
- CUT FOILS GOING TO PINS 6,10 AND 13 OF U54.
- CUT FOILS GOING TO PINS 3,6 and 10 of U55.
- HOOK PIN 14 OF U71 TO PIN 6 OF U54
- HOOK PIN 11 OF U60 TO PIN 10 OF U54
- HOOK PIN 14 OF U61 TO PIN 13 OF U54
- HOOK PIN 13 OF U61 TO PIN 3 OF U55
- HOOK PIN 12 OF U61 TO PIN 6 OF U55
- HOOK PIN 11 OF U61 TO PIN 10 OF U55
- ALSO HOOK IT TO PIN 9 OF U72
- HOOK PIN 8 OF U72 TO PIN 13 OF U55
- Hook pin 12 of U55 to pin 8 of the 2nd K of the Video RAM.  
This is the chip enable for it.







ADD TO ROW CLOCKS


5.9 MHz. 2400 BD. 1200 BD.




ADD TO COL.  
CLOCKS



BLANKING  
ADD FOR



PIN 12 U56  
BLANKING




CLEAR  
PIN 1 OF  
U30, U59  
U71

0 100

0 21

J1 J12 J14 J15 J16



1400 REM" VIDEO MOD.32  
1450 REM  
1480 REM"COPYRIGHT 1979 PROGRESSIVE COMPUTING.  
1490 REM  
1500 REM"TO USE LOAD PROGRAM THEN RUN  
1510 REM"TYPE NEW TO ERASE PROGRAM AFTER CURSOR HAS MOVED  
1520 REM"OUT TO THE EDGE OF THE SCREEN. IT SHOULD ALSO  
1530 REM"BE 2 LINES FURTHER DOWN ON THE SCREEN.  
2002 FOR IN = 546 TO 767  
2004 READ OP :POKE IN,OP  
2006 NEXT IN  
2008 POKE538,34:POKE539,2  
2010 DATA 141 , 2 , 2 , 72 , 138 , 72 , 152  
2020 DATA 72 , 173 , 2 , 2 , 240 , 66 , 172  
2030 DATA 6 , 2 , 240 , 8 , 162 , 32 , 202  
2040 DATA 208 , 253 , 136 , 208 , 248 , 201 , 10  
2050 DATA 240 , 61 , 201 , 13 , 208 , 6 , 32  
2060 DATA 204 , 2 , 76 , 113 , 2 , 141 , 1  
2070 DATA 2 , 201 , 95 , 208 , 13 , 169 , 32  
2080 DATA 141 , 1 , 2 , 32 , 194 , 2 , 206  
2090 DATA 0 , 2 , 208 , 6 , 32 , 194 , 2  
2100 DATA 238 , 0 , 2 , 169 , 31 , 24 , 105  
2110 DATA 160 , 205 , 0 , 2 , 48 , 12 , 32  
2120 DATA 212 , 2 , 104 , 168 , 104 , 170 , 104  
2130 DATA 32 , 108 , 255 , 96 , 32 , 207 , 2  
2140 DATA 32 , 194 , 2 , 169 , 160 , 41 , 224  
2150 DATA 141 , 2 , 2 , 162 , 7 , 182 , 225  
2160 DATA 2 , 157 , 7 , 2 , 202 , 16 , 247  
2170 DATA 190 , 233 , 2 , 169 , 32 , 160 , 31  
2180 DATA 141 , 8 , 2 , 160 , 0 , 32 , 7  
2190 DATA 2 , 208 , 251 , 238 , 9 , 2 , 238  
2200 DATA 12 , 2 , 236 , 9 , 2 , 208 , 240  
2210 DATA 32 , 7 , 2 , 204 , 2 , 2 , 208  
2220 DATA 248 , 169 , 32 , 32 , 10 , 2 , 206  
2230 DATA 8 , 2 , 208 , 248 , 240 , 172 , 174  
2240 DATA 0 , 2 , 173 , 1 , 2 , 157 , 0  
2250 DATA 211 , 96 , 32 , 194 , 2 , 169 , 160  
2260 DATA 141 , 0 , 2 , 174 , 0 , 2 , 189  
2270 DATA 0 , 211 , 141 , 1 , 2 , 169 , 95  
2280 DATA 208 , 231 , 185 , 0 , 208 , 153 , 0  
2290 DATA 208 , 200 , 96 , 211 , 72 , 169 , 32  
2300 DATA 162 , 0 , 157 , 0 , 208 , 157 , 0  
2310 DATA 209 , 157 , 0 , 210 , 157 , 0 , 211  
2320 DATA 232 , 208 , 241 , 104 , 96  
2350 FORIN=224TO234:READOP:POKEIN,OP:NEXT  
2360 DATA32,186,255,201,127,208,3,76,234,2,96  
2370 POKE536,224:POKE537,0

OK

Note: Backspace = Shift '0'  
Screen Clear = Rubout

```
2000 REM THIS SUB POKEs CRT64CHR INTO MACHINE LANGUAGE
2002 FOR IN= 546 TO 765
2004 READ OP :POKE IN,OP
2006 NEXT IN
2010 DATA 32, 186, 255, 201, 127, 208, 3, 76, 220, 2, 96, 240
2020 DATA 72, 141, 2, 2, 72, 138, 72, 152, 72, 173, 2, 2
2030 DATA 201, 10, 240, 61, 201, 13, 208, 6, 32, 199, 2, 76
2040 DATA 111, 2, 141, 1, 2, 201, 95, 208, 13, 169, 32, 141
2050 DATA 1, 2, 32, 189, 2, 206, 0, 2, 208, 6, 32, 189
2060 DATA 2, 238, 0, 2, 169, 63, 24, 105, 64, 205, 0, 2
2070 DATA 240, 12, 32, 207, 2, 104, 168, 104, 170, 104, 32, 108
2080 DATA 255, 96, 32, 202, 2, 32, 189, 2, 169, 64, 141, 2
2090 DATA 2, 162, 7, 189, 243, 191, 157, 7, 2, 202, 16, 247
2100 DATA 162, 215, 169, 64, 141, 8, 2, 160, 0, 32, 7, 2
2110 DATA 208, 251, 238, 9, 2, 238, 12, 2, 236, 9, 2, 208
2120 DATA 240, 32, 7, 2, 204, 2, 2, 208, 248, 169, 32, 32
2130 DATA 10, 2, 206, 8, 2, 208, 248, 240, 177, 208, 178, 174
2140 DATA 0, 2, 173, 1, 2, 157, 0, 215, 96, 32, 189, 2
2150 DATA 169, 64, 141, 0, 2, 174, 0, 2, 189, 0, 215, 141
2160 DATA 1, 2, 169, 171, 208, 231, 72, 169, 32, 162, 0, 157
2170 DATA 0, 208, 157, 0, 209, 157, 0, 210, 157, 0, 211, 157
2180 DATA 0, 212, 157, 0, 213, 157, 0, 214, 157, 0, 215, 232
2190 DATA 208, 229, 104, 96
2200 POKE536,34:POKE537,2:POKE538,45:POKE539,2
```

OK

Note: Backspace = Shift 'O'  
Screen Clear = Rubout

4599 98	TYA	4601 00	BRK
459A 48	PHA	4602 00	BRK
459B AC5B26	LDY \$265B	4603 00	BRK
459E AD6323	LDA \$2363	4604 00	BRK
45A1 297F	AND #\$7F	4605 00	BRK
45A3 A240	LDX #\$40	4606 00	BRK
45A5 C90D	CMP #\$0D	4607 00	BRK
45A7 F078	BEQ \$4621	4608 00	BRK
45A9 C908	CMP #\$08	4609 00	BRK
45AB F066	BEQ \$4613	460A 00	BRK
45AD C910	CMP #\$10	460B 00	BRK
45AF F069	BEQ \$461A	460C 00	BRK
45B1 C90C	CMP #\$0C	460D 00	BRK
45B3 F065	BEQ \$461A	460E 00	BRK
45B5 C90A	CMP #\$0A	460F 00	BRK
45B7 F074	BEQ \$462D	4610 00	BRK
45B9 C920	CMP #\$20	4611 00	BRK
45BB 301C	BMI \$45D9	4612 00	BRK
45BD C97B	CMP #\$7B	4613 98	TYA
45BF 1018	BPL \$45D9	4614 9D00D7	STA \$D700,X
45C1 9D00D7	STA \$D700,X	4617 CA	DEX
45C4 E8	INX	4618 B0B1	BCS \$45CB
45C5 E080	CPX #\$80	461A 98	TYA
45C7 F060	BEQ \$4629	461B 9D00D7	STA \$D700,X
45C9 EA	NOP	461E E8	INX
45CA EA	NOP	461F B0AA	BCS \$45CB
45CB 8C5B26	STY \$265B	4621 98	TYA
45D1 A9AB	LDA #\$AB	4622 9D00D7	STA \$D700,X
45D3 9D00D7	STA \$D700,X	4625 A240	LDX #\$40
45D6 8EA425	STX \$25A4	4627 D0A2	BNE \$45CB
45D9 68	PLA	4629 A240	LDX #\$40
45DA A8	TAY	462B D004	BNE \$4631
45DB AD6323	LDA \$2363	462D 98	TYA
45DE 48	PHA	462E 9D00D7	STA \$D700,X
45DF A901	LDA #\$01	4631 8E5726	STX \$2657
45E1 209F24	JSR \$249F	4634 A920	LDA #\$20
45E4 500E	BVC \$45F4	4636 A280	LDX #\$80
45E6 A908	LDA #\$08	4638 9D00D7	STA \$D700,X
45EB 209F24	JSR \$249F	463B E8	INX
45EB 1007	BPL \$45F4	463C D0FA	BNE \$4638
45ED 202B25	JSR \$252B	463E A0CF	LDY #\$CF
45F0 C911	CMP #\$11	4640 C8	INY
45F2 D0F9	BNE \$45E0	4641 8C4926	STY \$2649
45F4 4CF124	JMP \$24F1	4644 8C4C26	STY \$264C
45F7 00	BRK	4647 BD40D0	LDA \$D040,X
45F8 00	BRK	464A 9D00D0	STA \$D000,X
45F9 00	BRK	464D E8	INX
45FA 00	BRK	464E F0F0	BEO \$4640
45FB 00	BRK	4650 10F5	BPL \$4647
45FC 00	BRK	4652 C0D7	CPY #\$D7
45FD 00	BRK	4654 90F1	BCC \$4647
45FE 00	BRK	4656 A240	LDX #\$40
45FF 00	BRK	4658 4CCB25	JMP \$25CB
4600 00	BRK	465B 200100	JSR \$0001

65 D CIP  
64 CHR. / LINE

OFF SET TO

:Q4599

4599 98	TYA	4600 00	BRK
459A 48	PHA	4601 00	BRK
459B AC5B26	LDY \$265B	4602 00	BRK
459E AD6323	LDA \$2363	4603 00	BRK
45A1 297F	AND #\$7F	4604 00	BRK
45A3 A265	LDX #\$65	4605 00	BRK
45A5 C90D	CMP #\$0D	4606 00	BRK
45A7 F078	BEQ \$4621	4607 00	BRK
45A9 C908	CMP #\$08	4608 00	BRK
45AB F066	BEQ \$4613	4609 00	BRK
45AD C910	CMP #\$10	460A 00	BRK
45AF F069	BEQ \$461A	460B 00	BRK
45B1 C90C	CMP #\$0C	460C 00	BRK
45B3 F065	BEQ \$461A	460D 00	BRK
45B5 C90A	CMP #\$0A	460E 00	BRK
45B7 F074	BEQ \$4620	460F 00	BRK
45B9 C920	CMP #\$20	4610 00	BRK
45BB 301C	BMI \$45D9	4611 00	BRK
45BD C97B	CMP #\$7B	4612 00	BRK
45BF 1018	BPL \$45D9	4613 98	TYA
45C1 9D00D3	STA \$D300,X	4614 9D00D3	STA \$D300,X
45C4 E8	INX	4617 CA	DEX
45C5 E080	CPX #\$80	4618 B0B1	BCS \$45CB
		461A 98	TYA
45C7 F060	BEQ \$4629	461B 9D00D3	STA \$D300,X
45C9 EA	NOP	461E E8	INX
45CA EA	NOP	461F B0AA	BCS \$45CB
45CB BC00D3	LDY \$D300,X	4621 98	TYA
45CE BC5B26	STY \$265B	4622 9D00D3	STA \$D300,X
45D1 A95F	LDA #\$5F	4625 A260	LDX #\$60
45D3 9D00D3	STA \$D300,X	4627 D0A2	BNE \$45CB
45D6 BEA425	STX \$25A4	4629 A260	LDX #\$60
45D9 68	PLA	462B D004	BNE \$4631
45DA A8	TAY	462D 98	TYA
45DB AD6323	LDA \$2363	462E 9D00D3	STA \$D300,X
45DE 48	PHA	4631 8E5726	STX \$2657
45DF A901	LDA #\$01	4634 A920	LDA #\$20
45E1 209F24	JSR \$249F	4636 A280	LDX #\$80
45E4 500E	BVC \$45F4	4638 9D00D3	STA \$D300,X
45E6 A908	LDA #\$08	463B E8	INX
45E8 209F24	JSR \$249F	463C D0FA	BNE \$4638
45EB 1007	BPL \$45F4	463E A0CF	LDY #\$CF
45ED 202B25	JSR \$252B	4640 C8	INY
45F0 C911	CMP #\$11	4641 8C4926	STY \$2649
45F2 D0F9	BNE \$45ED	4644 8C4C26	STY \$264C
45F4 4CF124	JMP \$24F1	4647 BD20D0	LDA \$D020,X
45F7 00	BRK	464A 9D00D0	STA \$D000,X
45F8 00	BRK	464D E8	INX
45F9 00	BRK	464E F0F0	BEQ \$4640
45FA 00	BRK	4650 10F5	BPL \$4647
45FB 00	BRK	4652 C0D3	CPY #\$D3
45FC 00	BRK	4654 90F1	BCC \$4647
45FD 00	BRK	4656 A260	LDX #\$60
45FE 00	BRK	4658 4CCB25	JMP \$25CB
45FF 00	BRK	465B 200100	JSR \$0001

65D 32 chrs/line