






MODIFICATION FOR SERIAL SYSTEMS
REAR VIEW
DETAIL L-4












SERIAL SYSTEM MODIFICATIONS
REAR VIEW
DETAIL C - 1



# Ohio Scientific BASIC for the 6502, ax vorcion 27

## Commands

CONT LIST NEW NULL RUN

# **Statements**

CLEAR DATA DEF DIM END FOR
GOTO GOSUB IF...GOTO IF...THEN INPUT LET

NEXT ON...GOTO ON...GOSUB POKE PRINT READ

REM RESTORE RETURN STOP

# Expressions

# Operators

-, +, +, /,↑, NOT, AND, OR,>,<,<>, >=,<=,= RANGE 10-32 to 10+32

### Variables

A. B. C. . . . Z and two letter variables

The above can all be subscripted when used in an array

String variables use above names plus \$, eg. A\$

### **Functions**

ABS(X)	ATN(X)	COS(X)	EXP(X)	FRE(X)	INT(X)
LOG(X)	PEEK(I)	POS(I)	RND(X)	SGN(X)	SIN(X)
SPC(I)	SQR(X)	TAB(I)	TAN/Y	HERM	

### String Functions

ASC(X\$)	CHR\$(1)	FRE(X\$)	LEFT\$(X\$,I)	LEN(X\$)	MID\$(X\$, I, J)
RIGHT\$(X\$,I)		STR\$(X)	•	VAL(X\$).	

# **Special Characters**

- Erases line being typed, then provides carriage return, line feed.
- Erases last character typed.
- CR Carriage Return must be at the end of each line
- : Separates statements on a line.
- CONTROL/C Execution or printing of a list is interrupted at the end of a line. "BREAK IN LINE XXXX" is printed, indicating line number of next statement to be executed or printed.
- CONTROL/O No outputs occur until return made to command mode. If an Input statement is encountered, either another CONTROL/O is typed, or an error occurs. 
  ? Equ' sient to PRINT