
## Funktionsbeschreibung

- # Verbindung Pin 6 Pin 13: Pin 6 (B+) liegt auf 12 V Dauerplus (Versorgungsspannung), die Verbindung zu Pin 13 (SW B+) schaltet das Gerät ein.
- # Verbindung Pin 7 Pin 19: Pin 9 liefert 9,6 U (über 2k2). Pin 7 benötigt 4,7 U 10 U um den Prozessor in den Programmiermodes zu schalten (über 0714). !!! SPANNUNGEN > 10 U AN PIN 7 ÜBERSCHREITEN U\_eb\_max VON 0714 !!

# R1: Pullup Widerstand, wird aufgrund des 'open collector' Ausgangs von Pin 15 (trx Datenausgang) benötigt.

# R2: Dieser Widerstand stellt sicher, dass U\_eb\_max von 0710 nicht überschritten wird wenn die RS232 Datenleitung auf logisch 1 (negative Spannung) liegt.



## Functional Description:

# Connection 6 - 13: Pin 6 (B+) provides continous 12 V (input power), connecting it to Pin 13 (SW B+) 'switches' the radio on.

# Connection 7 - 19:
Pin 9 provides 9.6 U (via 2k2).
Pin 7 requires 4.7 U - 10 U to suitch CPU into programming mode (via Q714).
!!! UOLTAGES > 10 U ON Pin 7 WILL EXCEED U\_eb\_max OF Q714 !!

 $\mbox{\tt\#}$  R1: Pullup resistor, required due to open collector output of Pin 15 (trx data output).

# R2: This resistor ensures U\_eb of Q710 stays within permissible limits when RS232 data line is logically 1 (negative).

Programmieradapter für MCmega Adapterplatine in Command Boards: Programming cable for MCmega board attached to command boards:

GLN6984A (PL) GLN6628B (Select 5) (both ususally found in EZA9 models)

> MCmega Programmieradapter (DG1YFE / 2014) MCmega programming cable TITLE: mcmega\_prog REV: Document Number: 1.0 Date: 06.04.2014 18:23:59 Sheet: 1/1