

Echols Spec

Install fully adhered TPO membrane over the canopy. Provide gutters and downspouts.