

Module-4 (Assignment Day 5)

1.A user reports their laptop won't power on even when plugged in. List 5 troubleshooting steps you would take to diagnose the cause, and for each step, explain what you are checking for.



Step	Troubleshooting Step	What You Are Checking
1	Check the power adapter and cable.	Check for loose connections, cuts, or damage and confirm the charger is working.
2	Try a different power outlet.	Check whether the wall socket is providing power.
3	Remove the battery (if removable) and connect the charger.	Check if the battery is faulty or preventing the laptop from starting.
4	Perform a power reset.	Disconnect the charger, remove the battery if possible, hold the power button for 15–20 seconds, then reconnect power. This clears residual power.
5	Check for power/charging lights and try an external display.	Check whether the laptop is receiving power and whether the problem is a display issue rather than a complete power failure.

2. You receive a helpdesk ticket: 'My monitor is showing a blank screen, but the CPU seems to be running.' Write a step-by-step troubleshooting flow you would follow to identify and resolve the issue.

Hint: Consider checking both hardware connections and basic display settings.



Blank Monitor Troubleshooting Flow :-

1. **Check the monitor power** – Make sure the monitor is switched on and the power cable is firmly connected.
2. **Check the display cable** – Check the HDMI/DisplayPort/VGA cable at both ends. Reconnect it or try another cable.
3. **Check the correct input source** – Use the monitor buttons to select the correct input, such as HDMI or DisplayPort.
4. **Check the PC connection** – If a dedicated graphics card is installed, make sure the display cable is connected to the graphics card, not the motherboard port.
5. **Check brightness and display settings** – Increase brightness and press Windows + P to select the correct display mode.
6. **Test with another monitor** – Connect another working monitor to determine whether the problem is with the monitor or the PC.
7. **Check the graphics card/RAM** – Power off the PC and check that the GPU and RAM are properly seated.
8. **Restart and verify** – Restart the computer and check whether the display appears. If it still stays blank, the GPU, RAM, monitor, or motherboard may need further testing.

3. A user complains that their wireless mouse is unresponsive, but the keyboard works fine. Describe how you would isolate whether the issue is with the mouse, the USB port, or the system settings.



Wireless Mouse Troubleshooting

1. **Check the mouse power** – Replace the batteries or charge the mouse and make sure it is switched on.
2. **Check the wireless receiver** – Remove and reconnect the USB receiver. Check if the mouse works.
3. **Try another USB port** – Connect the receiver to a different USB port. If it works there, the original USB port may have a problem.
4. **Test another mouse** – Connect a working mouse to the same USB port. If the second mouse works, the original mouse or receiver may be faulty.
5. **Check system settings** – Open Device Manager and check under *Mice and other pointing devices* for driver errors. Update or reinstall the mouse driver if needed.
6. **Test the mouse on another computer** – If it still does not work, the mouse/receiver is likely faulty. If it works, the issue is likely with the original computer's USB port, driver, or settings.

4. Imagine you are working on a helpdesk team for a gaming cafe. One system is overheating and shutting down during use. List 3 possible hardware causes and describe how you would check each one.

Hint: Think about fans, dust, and thermal paste.



Gaming PC Overheating – Troubleshooting

Possible Hardware Cause	How to Check
1. Faulty or stopped fan	Open the case and check whether the CPU, GPU, and case fans are spinning properly. Replace a faulty fan.
2. Dust buildup	Inspect the CPU heatsink, GPU heatsink, and case vents for dust. Clean them carefully using compressed air.
3. Dried or poorly applied thermal paste	Check the thermal paste between the CPU and heatsink. If it is dried out or insufficient, clean the old paste and apply new thermal paste.