

## THE HOME EXPERTS

Smarter Appliances Ltd T/A D&S Corporate

Tel: 0203 488 0344

2nd Floor Standon House 21 Mansell Street London E1 8AA

Direct Line: 07849566474

Direct Fax:

Instructed By:

Email: LatusN@hamptons.co.uk

Natalie Latus

Home: www.hamptons.co.uk

## **WORKS ORDER**

Client: Mr Kiok Sinn Teh

Client No: C68487

**Property:** 45 Rainsborough House, 5 Stamford Square,

London, SW15 2BP

**Date**: 05/09/2024 **Works ref**: W557955

Purchase order: 1630837Supplier a/c no: C985023

Instruction:

The dishwasher has not been washing items fully and often finishes before the end of the cycle. The dishwasher fills with water and the 'brush' icon flashes. This usually indicates a blockage and we have tried to fix this on our side, though we presume there is a blockage further down the pipes which we can't reach. This has been going on for a while now and we now need help.[Appliance type: Dishwasher] [Appliance make: Siemens] [Appliance model: SI6P1S] Free parking not available.Pet information - No petsNote: The

tenant would like to be present when the work is carried out.

Access: TT

Tenant / Occupant: Joseph Carlo Jenkins & Katherine Elizabeth Lower

Contact details: Mobile: 07500770007

Phone:

Email: joecjenks@gmail.com, katherine.lower@yahoo.co.uk

IT IS IMPORTANT THAT YOU DO NOT CARRY OUT FURTHER WORKS THAN INSTRUCTED ABOVE WITHOUT THE FULL AUTHORISATION OF THE INSTRUCTOR NAMED ABOVE OR OTHER AUTHORISED STAFF WITHIN THIS OFFICE.

Please Charge To: Mr Kiok Sinn Teh

c/o Hamptons International. pminvoices@hamptons-int.com

All invoices should be presented in .pdf format and include the purchase order number to the above email address for prompt payment