

Installation & Field Guide

RoadLenz Intelligent Mobility | Powered by Bigfox Engineering Private Limited

Scope

This document covers the standard field installation procedure for RoadLenz hardware. Always follow vehicle manufacturer guidance and local electrical safety rules.

Before you begin

- â€¢ Confirm the part number against the packing list and order.
- â€¢ Verify vehicle make, model, year and battery rating.
- â€¢ Prepare the toolkit: wire strippers, crimpers, multimeter, zip ties, heat shrink.
- â€¢ Confirm network coverage at the installation site.

Procedure

1. Identify the MDVR terminal block: BAT, IGN, GND, ACC-12, GPS+, GPS-.
2. Connect BAT to the vehicle battery positive through a 5 A fuse (10 cm max lead).
3. Connect GND to a clean chassis ground away from EMI sources.
4. Connect ACC-12 to an ignition-switched 12 V feed for start/stop detection.
5. Route the GPS antenna cable to the roof location; keep it away from the 4G antenna (min. 15 cm).
6. Connect camera channels 1â€”8 per the channel map: 1 front, 2 rear, 3â€”4 sides, 5â€”8 cargo.
7. Verify all channels show live video in the app before closing the enclosure.
8. Tie and dress all wiring with zip ties every 15 cm; no dangling cables near pedals.

Demo sample content â€” replace with verified documentation before launch.

support@roadlenz.in | www.roadlenz.in